

# CONTENTS

1. PREPARATION .....	6
1.1 Precautions .....	6
1.2 Appearance .....	8
1.3 Unpacking and Storage of the Instrument.....	9
1.4 Instrument Set Up.....	10
1.5 Battery Removal & Insertion - Information and Recharging.....	11
1.6 Reflector Prisms .....	13
1.7 Mounting and Dismounting the Instrument from the Tribrach .....	14
1.8 Eyepiece Adjustment and Object Sighting.....	15
1.9 Turning the Instrument On and Off .....	15
1.10 How To Enter Alphanumeric Characters .....	16
2. FUNCTION KEY AND DISPLAY .....	18
2.1 Operating Key .....	18
2.2 Function Key .....	20
2.3 Star-key Mode .....	22
2.4 Dot-key Mode.....	24
3. INITIAL SETTINGS .....	25
3.1 Setting the Temperature and Atmospheric .....	25
3.2 Setting of the Atmospheric Correction .....	27
3.3 Setting of the Prism Constant .....	29
3.4 Setting of the Vertical Angle Tilt Correction .....	30
4 . ANGLE MEASUREMENT.....	31
4.1 Measuring Horizontal Angle Right and Vertical Angles .....	29
4.2 Switching Horizontal Angle Right/Left .....	31
4.3 Setting of the Horizontal Angle .....	32
4.3.1 Setting by Holding the Angle .....	32

4.3.2 Setting the Horizontal Angle from the Keypad.....	34
4.4 Vertical Angle Percent Grade (%) Mode.....	35
4.5 Setting the Initial Zenith Angle.....	36
5. DISTANCE MEASUREMENT.....	37
5.1 Setting of the Atmospheric Correction .....	37
5.2 Setting of the Correction for Prism Constant.....	37
5.3 Distance Measurement (Continuous Measurement) .....	38
5.4 Changing the Distance Measurement Mode .....	39
5.5 Stake Out (S.O.) .....	41
5.6 Offset Measurement .....	41
5.6.1 Angle Offset .....	43
5.6.2 Distance Offset Measurement .....	45
5.6.3 Plane Offset Measurement.....	48
5.6.4 Column Offset Measurement.....	51
6. COORDINATE MEASUREMENT.....	52
6.1 Execution of Coordinate Measurement .....	53
6.2 Setting Coordinate Values of Occupied Point.....	55
6.3 Setting Height of the Instrument.....	57
6.4 Setting Height of Target (Prism Height) .....	58
7. SURVEYING PROGRAM .....	59
7.1 Remote Elevation Measurement ( REM ) .....	59
7.2 Missing Line Measurement (MLM) .....	64
7.3 Area Calculation .....	69
7.4 Setting Z Coordinate of Occupied Point .....	72
7.5 Point to Line Measurement.....	77
7.6 Road Construction .....	80
7.6.1 Design: Horizontal Alignment.....	80
7.6.2 Editing Horizontal Alignment Data .....	89
7.6.3 Receiving Horizontal Alignment .....	90
7.6.4 Deleting Horizontal Alignment Data .....	93
7.6.5 Design: Vertical Curve .....	94
7.6.6 Editing Vertical Alignment Data.....	96

7.6.7 Receiving Vertical Alignment Data .....	97
7.6.8 Deleting Vertical Alignment Data.....	98
7.6.9 Generating a Road Coordinate File .....	98
7.6.10 Road Setting Out Procedures.....	99
7.6.11 Slope Setting-out .....	106
7.7 Stake Out .....	108
7.8 Resection .....	108
8. DATA COLLECTION .....	108
8.1 Operation Procedure .....	109
8.2 Preparation.....	110
8.2.1 Selecting a File for Data Collection.....	110
8.2.2 Selecting a Coordinate File for Data Collection .....	111
8.2.3 Occupied Point and Backsight Point .....	112
8.2.4 Measuring and Storing the Data .....	117
8.3 Data Collect Offset Measurement Mode .....	121
8.3.1 Angle Offset .....	122
8.3.2 Distance Offset Measurement .....	124
8.3.3 Plane Offset Measurement.....	127
8.3.4 Column Offset Measurement.....	130
8.4 Editing PCODE Library [PCODE INPUT] .....	133
8.5 Setting the Data Collection Parameters .....	134
9. LAYOUT .....	135
9.1 Setting the Parameters of Data Collection .....	136
9.2 Preparation.....	136
9.2.1 Setting the GRID FACTOR.....	136
9.2.2 Selecting Coordinate Data File.....	136
9.2.3 Setting Occupied Point.....	138
9.2.4 Setting Backsight Point .....	140
9.3 Executing A Layout .....	142
9.4 Setting A New Point .....	145
9.4.1 Side Shot Method .....	145
9.4.2 Resection Method.....	148

10. MEMORY MANAGEMENT MODE .....	154
10.1 Choose Storage Medium.....	156
10.2 Display Internal Memory Status .....	157
10.3 Searching Data.....	157
10.3.1 Measured Data Searching .....	158
10.3.2 Coordinate Data Searching.....	161
10.3.3 PCODE LIBRARY Searching.....	162
10.3.4 Plotting Points .....	164
10.4 File Maintenance .....	165
10.4.1 Renaming a File .....	166
10.4.2 Deleting a File .....	167
10.5 Coordinate Data Direct Key Input .....	168
10.6 Deleting a Coordinate Data From a File .....	169
10.7 Editing PCODE Library .....	171
10.8 Data Communication.....	172
10.8.1 Data Communication with RS-232.....	172
10.8.2 Data Conversion By USB.....	178
10.9 File Operation.....	180
10.9.1 Copy File From SD Card To Memory Of The Instrument.....	180
10.9.2 Copy The File From Memory To SD Card. ....	181
10.10 Initialization.....	182
11. BASIC SETTINGS .....	184
11.1 Unit Settings .....	184
11.2 parameter Settings .....	185
11.2.1 Setting of the Tilt Sensor .....	186
11.2.2 Setting of the W-Correction.....	187
11.2.3 Setting the GRID FACTOR.....	188
11.2.4 Setting of the Minimum Angle Reading .....	190
11.2.5 Setting the Vertical Angle Display.....	191
11.2.6 Setting of Plotting Points Number .....	192
11.2.7 Setting the Distance Range Mode.....	192
11.2.8 Automatic Compensation For Temperature And Air Pressure .....	193

11.3 Setting the Measure Mode Display.....	194
11.4 Setting the Shortcut Keys .....	194
11.5 Other Settings .....	195
11.5.1 Auto Power Off.....	195
11.5.2 Choosing Battery Type .....	196
11.5.3 Renew to Factory Configuration.....	197
11.5.4 Selecting a Language.....	197
11.6 Date and Time.....	198
11.7 Adjusting the Contrast of the LCD .....	199
12. CHECK AND ADJUSTMENT.....	200
12.1 Plate Vial .....	200
12.2 Circular Vial .....	201
12.3 Inclination of Reticle .....	200
12.4 Perpendicularity of Line of Sight to Horizontal Axis (2c) .....	203
12.5 Vertical Index Difference Compensation .....	204
12.6 Adjustment of Vertical Index Difference ( Iangle) and Vertical Angle0 Datum..	205
12.7 Optical Plummet.....	207
12.8 Laser Plummet.....	208
12.9 Instrument Constant (K) .....	208
12.10 Parallel between Line of Sight and Emitting Photoelectric Axis.....	209
12.11 Tribrach Leveling Screw.....	210
13. SPECIFICATIONS .....	211
14. ERROR DISPLAYS .....	215
15. SAFETY INSTRUCTIONS.....	217
15.1 Integrated EDM ( Visible Laser ) .....	217
15.2 Laser Plummet.....	219

# 1. PREPARATION

## 1.1 Precautions

1. Never point the instrument at the sun without a filter.
2. Never store the instrument in extreme temperatures and avoid sudden changes of temperature.
3. When not using the instrument, place it in the case to avoid shock, dust, and humidity.
4. If there is a great difference in temperature between the work site and the instrument storage location, leaving the instrument in the case until it adjusts to the surrounding temperature.
5. Please remove the battery for separate storage if the instrument is to be storage for an extended time. The battery should be charged once a month during storage.
6. The instrument should be placed in its carrying case during transportation. It is recommended that the original packing case be used for cushioning during extended transportation.
7. Be sure to secure the instrument with one hand when mounting or removing from the tripod.
8. Clean exposed optical parts with degreased cotton or lens tissue only.
9. Clean the instrument's surface with a woolen cloth when finished to use it. Dry it immediately if it gets wet.
10. Check the battery, functions, and indications of the instrument as well as its initial setting and correction parameters before operating.


11. Unless you were a maintenance specialist do not attempt to disassemble the instrument for any reason. Unauthorized disassembly of the instrument can result in a void warranty.

12. The total stations emit a laser during operation. DO NOT stare into the beam or laser source when instrument is operated.

## 1.2 Appearance







## 1.3 Unpacking and Storage of the Instrument

### Unpacking of the Instrument

Place the case lightly with the cover upward, unlock the case and take out the instrument.

### Storage of the Instrument

Replace the cover on the telescope lens, place the instrument into the case with the vertical clamp screw and circular vial upward (objective lens toward the tribrach), tighten the vertical clamp screw, close and lock the case.

## 1.4 Instrument Set Up

Mount the instrument onto the tripod and secure firmly. Level and center the instrument precisely to ensure the best performance. Use the tripod with a 5/8" tripod screw.

Operation Reference: Leveling and Centering the Instrument

### **1). Setting up the tripod**

First extend the extension legs to suitable length and tighten the screws, firmly plant the tripod in the ground over the point of beginning.

### **2). Attaching the instrument to the tripod**

Secure the instrument carefully on the tripod and slide the instrument by loosening the tripod mounting screw. If the optical plumb site is positioned over the center of the point tighten the mounting screw.

### **3). Roughly leveling the instrument by using the circular vial**

Turn the leveling screw A and B to move the bubble in the circular vial, in which case

the bubble is located on a line perpendicular to a line running through the centers of the two leveling screw being adjusted. Turn the leveling screw C to move the bubble to the center of the circular vial. Recheck the position of the instrument over the point and adjust if needed.

#### **4). Leveling by using the plate vial**

Rotate the instrument horizontally by loosening the Horizontal Clamp Screw and place the plate vial parallel with the line connecting leveling screws A and B, then bring the bubble to the center of the plate vial by turning the leveling screws A and B.

Rotate the instrument  $90^{\circ}$  (100g) around its vertical axis and turn the remaining leveling screw or leveling C to center the bubble once more.

Repeat the procedures for each  $90^{\circ}$  (100g) rotation of the instrument and check whether the bubble is correctly centered in all directions.

#### **5). Centering by using the optical plummet(or laser plummet)**

Adjust the eyepiece of the optical plummet telescope to your eyesight. Slide the instrument by loosening the tripod screw; place the point on the center mark of the optical plummet. Sliding the instrument carefully as to not rotate the axis will allow you to get the least dislocation of the bubble.(Place star-key after power on, then press F4(LASER)key, press F1(ON)key to turn on the laser plummet. Slide the instrument by loosening the tripod screw; Place laser facular on the occupied pointing, Sliding the instrument carefully as to not rotate the axis will allow you to get the least dislocation of the bubble. The last, press ESC key, and laser plummet turn off automatically.)

#### **6). Complete leveling the instrument**

Level the instrument precisely as in Step 4. Rotate the instrument and check to see that the bubble is in the center of the plate level regardless of the telescope direction then tighten the tripod screw firmly.


# 1.5 Battery Removal & Insertion - Information and Recharging

## Battery removal & insertion

Insert the battery into the battery slot and push the battery until it clicks.

Press the right and left buttons of the battery compartment to remove the battery.

## Battery information



----- Indicates that battery is fully charged



----- Indicates that the battery can only be used for about 1 hour.

Recharge the battery or prepare a recharged battery for use.



----- Recharge the battery or prepare a recharged battery for use.

Note: The working time of the battery is determined by environment conditions, recharging time, and other factors.

## Battery Recharging

Battery should be recharged only with the charger supplied with the instrument.

Remove the on-board battery from instrument as instructed and connect to the battery charger.

## Battery Removal Caution

▲ Before you take the battery out of the instrument, make sure that the power is turned

off. Otherwise the instrument would be damaged.

**Recharging Caution:**

▲ The charger has built-in circuitry for protection from overcharging. However, do not leave the charger plugged into the power outlet after recharging is completed.

▲ Be sure to recharge the battery at a temperature of 0°C ~ 45°C, recharging may be abnormal beyond the specified temperature range.

▲ When the indicator lamp does not light after connecting the battery and charger the battery or the charger may be damaged.

**Storage Caution:**

▲ The rechargeable battery can be repeatedly recharged 300-500 times. Complete discharge of the battery may shorten its service life.

▲ In order to get the maximum service life be sure to recharge the battery at least once a month.

## 1.6 Reflector Prisms

When doing distance measuring in prism mode a reflector prism needs to be placed as the target. Reflector systems can be single or multiple prisms which can be mounted with a tripod/tribrach system or mounted on a prism pole. Unique mini prism systems allow setups at corners that are hard to reach. Reflectorless targets extend the range of the instrument when used in reflectorless mode.


Illustrated are some prisms and a reflector compatible with instruments:



## 1.7 Mounting and Dismounting the Instrument from the Tribrach

### Dismounting

When necessary the instrument can be dismounted from the tribrach. Loosen the tribrach locking screw in the locking knob with a screwdriver if necessary. Turn the locking knob 180 degrees counter-clockwise to disengage anchor jaws and remove the instrument from the tribrach.



## Mounting

Insert three anchor jaws into holes in tribrach and line up the directing stub on the instrument with the directing slot of the tribrach. Turn the locking knob 180 degrees clockwise and tighten the locking screw with a screwdriver.

## 1.8 Eyepiece Adjustment and Object Sighting

Method of Object Sighting (for reference)

1. Sight the telescope to the sky and rotate the eyepiece tube to make the reticule clear.
2. Collimate the target point with top of the triangle mark in the collimator. (keep a certain distance between eye and the collimator).
3. Make the target image clear with the telescope focusing screw.

If there is parallax when your eye moves up and down or left and right this indicates the diopter of the eyepiece lens or focus is not adjusted well and accuracy will be effected. You should readjust the eyepiece tube carefully to eliminate the parallax.

## 1.9 Turning the Instrument On and Off

Power on

1. Be sure that the instrument is leveled.
2. Press and momentarily hold the power (POWER) key.
3. Rotate the EDM head in an upwards direction to initialize.
4. To turn OFF press and hold the power key until instrument powers down.

Be sure there is sufficient battery power. If 'Battery Empty' is shown on the display, the battery should be recharged or replaced.


\*\*\* DO NOT remove the battery during measuring, otherwise the data will be lost and the instrument would be harmed!! \*\*\*

## 1.10 How To Enter Alphanumeric Characters

### \*How to select an item

[Example 1] Select INS.HT (instrument height) in the data collection mode (first press the MENU button then F1:DATA COLLECT and then select the data file desired. Press F2 to list, the arrow keys to choose and then F4 to select). Press F1 again for OCC.PT# INPUT.


The arrow (→) indicates an item to enter. Press [▲] [▼] key to move the arrow line up or down



PT# :  
PCODE:  
INS.HT: 0.000 m

INPT SRCH OCC NOTE

Press [▼] move->R..HT



INPUT PT#

PT# :  
PCODE:  
R.HT → 0.000 m

INPT MEAS ALL

Press **F1** INPUT then **1** to input "1"



Press **[.]** to input “.”


Press **[5]** to input “5”, press **[ENT]**

Then R. HT = 1.5 m


### \*How to enter characters

[Example 2] Input the code “ABC1” of instrument point in Data Collection Mode.


- 1 . Move the arrow to PCODE using the **[▲]** or **[▼]** key

INPUT OCC.			
PT# :			
PCODE →			
R.HT :	0.000		m
<b>INPT</b>	<b>SRCH</b>	<b>MEAS</b>	<b>ALL</b>

- 2 . Press **[F1]** (input) key

INPUT OCC.			
PT# :			
PCODE →			
R.HT :	0.000		m
<b>BACK</b>	<b>RETN</b>	<b>NUMB</b>	

- 3 . Press **[F1]** key once

INPUT OCC.			
PT# :			
PCODE	ABC1		
R.HT :	0.000		m
<b>BACK</b>	<b>RETN</b>	<b>NUMB</b>	

Press **[7]** key once for “A”

Press **[7]** key twice for “B”

Press **[7]** key three times for “C”


Press **F3** to switch to NUMB Input mode first

Press **[1]** key once for “1”







Press enter key to finish input

## 2. FUNCTION KEY AND DISPLAY

### 2.1 Operating Key



Keys	Names	Function
	Angle meas. key	Angle measurement mode
	Distance meas. key	Distance measurement mode
	Coordinate meas. key	Coordinate measurement mode (▲Up)
	Layout key	Layout measurement mode (▼ Down)
	Quick key1	User-defined quick key 1(◀ Left)
	Quick key 2	User-defined quick key 2(▶ Right)
	Escape key	Return to the measurement mode or previous layer mode.
	Enter key	Press after confirmation of inputting values
	Menu key	Switches menu mode and normal mode
	Shift key	Shift distance measuring key


	Star key	Press once to adjust contrast or twice for illumination of keypad
	Power key	On / Off key press and hold
	Soft key ( Function key)	Responds to the message displayed
	Number key	Input numbers
	Minus key	Input minus sign, displays electronic bubble
	Point key	On / Off laser pointing function

Display marks :

Display	Content
V	Vertical angle
V%	Vertical angle as a percentage (Gradient display)
HR	Horizontal angle (right)
HL	Horizontal angle (left)
HD	Horizontal distance
VD	Elevation difference
SD	Slope distance
N	North coordinate
E	East coordinate
Z	Z or elevation coordinate
*	EDM working
m/ft	Switches units between meters and feet
m	Meter unit
S/A	Sets temperature, air pressure, prism constant
PSM	Prism constant (unit:mm)
PPM	Atmospheric correction


# 2.2 Function Key

Angle measurement mode (three-page menu)




Page	Keys	Display marks	Function
P1	<span>F1</span>	0SET	Horizontal angle is set to 0°0'0"
	<span>F2</span>	HOLD	Hold the horizontal angle
	<span>F3</span>	HSET	Set a required horizontal angle by entering numbers
	<span>F4</span>	P1↓	Scroll to the next page (P2)
P2	<span>F1</span>	TILT	Tilt correction screen. If the correction is turned on the display will show the tilt correction value.
	<span>F2</span>		
	<span>F3</span>	V%	Vertical angle percent grade (%) mode
	<span>F4</span>	P2↓	Scroll to the next page (P3)
P3	<span>F1</span>	R/L	Switches Right/Left rotation of horizontal angle
	<span>F2</span>		
	<span>F3</span>	CMPS	Switches vertical angle "0" position
	<span>F4</span>	P3↓	Scroll to the next page (P1)

Distance measurement mode (two-page menu)



Page	Keys	Display marks	Function
P1	<div>F1</div>	MEAS	Begin measuring
	<div>F2</div>	MODE	Sets measuring mode from: Fine[1]/ Fine[N]/Tracking
	<div>F3</div>	S/A	Sets temperature, air pressure, prism constant
	<div>F4</div>	P1↓	Scroll to the next page (P2)
P2	<div>F1</div>	OFFSET	Selects Off-set measurement mode
	<div>F2</div>	S.O.	Selects Stake Out measurement mode
	<div>F3</div>	m / ft	Switches units between meters and feet
	<div>F4</div>	P2↓	Scroll to the next page (P1)

## Coordinate measurement mode ( three-page menu )




Page	Keys	Display marks	Function
P1	F1	MEAS	Start measuring
	F2	MODE	Sets a measuring mode, Fine/Tracking
	F3	S/A	Sets temperature, air pressure, prism constant
	F4	P1↓	The function of soft keys is shown on next page (P2)
P2	F1	R.HT	Sets prism height
	F2	INSHT	Sets instrument height
	F3	OCC	Sets instrument coordinate.
	F4	P2↓	Shows the function of soft keys on page 3
P3	F1	OFSET	Off-set measurement mode
	F2	BACKSIGHT	Setting a direction angle for back sight orientation
	F3	m / ft	Switches meter and feet unit.
	F4	P3↓	Shows the function of soft keys on page1

## 2.3 Star-key Mode

The total station(non-reflectorless) :


Press the star key , following is displayed:




1. Contrast adjustment: After pressing star key, adjust the display contrast by pressing [▲] or [▼] key.
  2. Illumination: After pressing star key, select [Illumination] by pressing F1(LAMP) key or press star key.
  3. Tilt: After pressing star key, select [tilt] by pressing F2 (TILT) key, and select ON or OFF by pressing F1 or F3 key, press F4 (ENT) key.
  4. S/A: After pressing star key, select [S/A] by pressing F3 (S/A) key, then you can set Prism contrast, air pressure and temperature.
  5. Laser plummet: If total station has this function, after pressing star key, select [laser] by pressing F4 (LASR) key, and select ON or OFF by pressing F1 or F2 key.
- \*In some interface, you can turn on or turn off panel backlight by press star key directly.

The total station(reflectorless) :

Press the star key , following is displayed:



1 . Mode: Press the **F1** (mode) key, the following is displayed :



You can select the type of measure mode by pressing the **F1**—**F3** keys.

2 . You can turn on the lamp by pressing the star key once more or by pressing twice from any menu.

## 2.4 Dot-key Mode

The total station can function as a laser pointer

The laser pointer can be turned on or off by pressing the (.) dot key.



### 3. INITIAL SETTINGS

The series total station can be reset to the instruments original factory settings.  
See Section 11 “Basic Settings”





#### 3.1 Setting the Temperature and Atmospheric









Before manually set the Temperature and Atmospheric, you need to turn off the Auto T-P sensor option.

Press [M] key, press [F4] CONFIG, Press [F2] PARAMETER SET, Press[▼] to second page, press [F3] T-P Sensor, Press [F2] NO to turn off the Auto T-P Sensor.

#### Pressure

Measure the surrounding temperature and air pressure in advance. Example:  
temperature +25 °, air pressure 1017.5 hPa

Procedur e	Operation	Operating procedure	Display
		Enter the Distance Measurement Mode	<div><div>PSM -30</div><div>PPM 0.0</div><div></div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>HD : 235.641 m</div><div>VD : 0.029 m</div><div>MEAS</div><div>MODE</div><div>S/A</div><div>P1↓</div></div>

		Press F3 to enter the S/A screen	
Temp. Settings		Press  to enter temperature section, enter the correct temperature, press the ENT key to set	
Atms. Pressure		Press  key and enter the air pressure, press the ENT key to confirm	
Remarks	<p>Temperature operating range : -30 °~ +60°C or -22 ~ +140°F</p> <p>Air pressure : 560 ~ 1066 hPa or 420 ~ 800 mmHg or 16.5 ~ 31.5 inHg</p> <p>If the atmospheric correction value calculated from the temperature and air pressure exceeds the range of ±999.9PPM , the operation will return to step 4 automatically, and you should enter the data again.</p>		

### 3.2 Setting of the Atmospheric Correction

The infrared emitted by the Total Station varies with the air temperature and pressure. Once the atmospheric correction value is set the instrument will correct the distance measuring result automatically.

Air pressure : 1013hPa

Temperature : 20°C

The calculation of atmospheric correction :

$$\Delta S = 273.8 - 0.2900 P / ( 1 + 0.00366T ) \text{ (ppm)}$$

$\Delta S$  : Correction Coefficient ( Unit ppm )

P: Air Pressure ( Unit : hPa If the unit is mmHg , please convert using

1hPa = 0.75mmHg

T: temperature ( unit°C )

Direct Setting Method of Atmosphere Correction Value

After measuring the temperature and air pressure the atmosphere correction value can be obtained from an atmospheric correction chart or correction formula (PPM).

Procedure	Operation	Operation Procedure	Display
	<b>F3</b>	Press <b>F3</b> Key in distance measurement or coordinate measurement mode	<div><div>SET AUDIO MODE</div><div>PSM 0</div><div>PPM 6.4</div><div>TEMP. 27.0 ℃</div><div>APRE. 1013.0 hPa</div><div>PSM PPM TEMP PRES</div></div>
	<b>F2</b>	Press <b>F2</b> [ppm] key , which shows the current setting value	<div><div>SET AUDIO MODE</div><div>PSM 0</div><div>PPM 6.4</div><div>TEMP. 27.0 ℃</div><div>APRE. 1013.0 hPa</div><div>BACK RETN</div></div>
	Enter value	Enter atmospheric correction and press ENT	<div><div>SET AUDIO MODE</div><div>PSM 0</div><div>PPM 7.8</div><div>TEMP. 27.0 ℃</div><div>APRE. 1013.0 hPa</div><div>BACK RETN</div></div>
<p>*1 ) See 2.10“How to Enter Alphanumeric Characters”</p> <p>Input range : -999.9PPM to +999.9 Step length: 0.1PPM</p> <p>*2 ) If Temperature and Atmospheric Pressure are reset, the PPM will be recalculated automatically.</p>			

3.3 Setting of the Prism Constant

In the factory the prism constant for the total station is set at -30mm. If the constant of the prism used is not -30mm, you must change this setting. Once the prism constant is set it will become the new default value until changed.

Procedure	Operation	Operation Procedure	Display
	<div>F3</div>	Press <div>F3</div> ( S/A ) Key in Distance Measurement Mode or Coord. Measurement Mode.	<div>SET AUDIO MODE</div> <div>PSM 0</div> <div>PPM 6.4</div> <div>TEMP. 27.0 °C</div> <div>APRE. 1013.0 hPa</div> <div>PSM PPM TEMP PRES</div>
②	<div>F1</div>	② Press <div>F1</div> ( PRISM ) key	<div>SET AUDIO MODE</div> <div>PSM 0</div> <div>PPM 6.4</div> <div>TEMP. 27.0 °C</div> <div>APRE. 1013.0 hPa</div> <div>RETN BACK</div>
③	Enter data	Press <div>F1</div> (INPUT) key to enter the Prism Constant correction value. *1, press <div>F4</div> to confirm and return to the Setting Mode.	<div>SET AUDIO MODE</div> <div>PSM -30 _</div> <div>PPM 6.4</div> <div>TEMP. 27.0 °C</div> <div>APRE. 1013.0 hPa</div> <div>RETN BACK</div>
Input range : -99. 9mm to +99. 9mm Step length 0. 1mm			

\*The total station in reflectorless measuring mode sets the prism constant to 0 automatically.

### 3.4 Setting of the Vertical Angle Tilt Correction

When the tilt sensor is activated the instrument automatically corrects the vertical angle for mislevel. To ensure a precise angle measurement the tilt sensor must be turned on. The tilt sensor display can also be used to fine level the instrument. If the ("X TILT OVER") display appears the instrument is out of the automatic compensation range and must be leveled manually to within tolerances.

The instruments compensates the vertical angle reading due to inclination of the standing axis in the X direction.

When the instrument is on an unstable footing or used during a windy day the display of vertical angle can be unstable. You can turn off the auto tilt correction function in this case.

#### Setting the tilt correction

The instrument memorizes the last setting for this feature. To insure the compensator is on check this setting before operating the instrument.

For operation procedures refer to 11.2.1.

# 4 . ANGLE MEASUREMENT

## 4.1 Measuring Horizontal Angle Right and Vertical Angles

Make sure the angle measurement mode is selected.

Operation procedure	Operation	Display
① Collimate the first target (A)	Collimate A	<div><div>PSM -30PPM 0.0</div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>OSETHOLDHSETP1↓</div></div>
To set horizontal angle of target A at 0°  00°00" press the <div>F1</div> (OSET) key and then press the <div>F4</div> (YES) key	<div>F1</div>  <div>F4</div>	<div><div>PSM -30PPM 0.0</div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>OSETHOLDHSETP1↓</div></div> <div><div>PSM -30PPM 0.0</div><div>H ANGLE 0 SET</div><div>&gt;OK? [NO] [YES]</div></div>
③ Collimate the second target (B)  The required V/H angle to target B will be displayed	Collimate B	<div><div>PSM -30PPM 0.0</div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>OSETHOLDHSETP1↓</div></div>

Note : The horizon angle will be saved when the instrument is powered off and displayed when powered on.

**Reference: How to Collimate**

Point the telescope toward a light surface or sky. Turn the diopter ring and adjust the diopter so that the cross hairs are clearly observed.

Aim the target at the peak of the triangle mark of the sighting collimator. Allow a certain space between the sighting collimator and yourself for collimating.

Focus the target with the focusing knob.

If parallax is created between the cross hairs and the target when viewing vertically or horizontally while looking into the telescope, focusing is incorrect or diopter adjustment is poor.

This adversely affects precision in measurement please eliminate the parallax by carefully focusing and using the diopter adjustment.

**4.2 Switching Horizontal Angle Right/Left**

Make sure the angle measurement mode is selected.

Operation procedure	Operation	Display
Press the <b>F4</b> Key twice to get the menu to page 3. (P3)	<b>F4</b> twice	<div><div>PSM-30PPM0.0</div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>OSETHOLDHSETP1↓</div><div>TILT V% P2↓</div><div>R/L CMPS P3↓</div></div>
Press the <b>F1</b> ( R/L ) key. The Horizontal Right angle mode	<b>F1</b>	<div><div>PSM-30PPM0.0</div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>R/L CMPS P3↓</div></div>




(HR) Switches to Horizontal Left mode (HL)		
Measure as HL mode		
*Each time the <b>F2</b> (R/L) key is pressed the HR/HL mode switches		

### 4.3 Setting of the Horizontal Angle

#### 4.3.1 Setting by Holding the Angle



Make sure the angle measurement mode is selected.







Operation procedure	Operation	Display
① Set the required horizontal angle using the horizontal tangent screw	Display angle	<div> <div> PSM -30 PPM 0.0 </div> <div> V : 95° 30' 55" </div> <div> HR : 65° 45' 30" </div> <div> OSET HOLD HSET P1↓ </div> </div>
② Press the <b>F2</b> (HOLD)key	<b>F2</b>	<div> <div> PSM -30 PPM 0.0 </div> <div> H ANGLE HOLD </div> <div> HR : 65° 45' 30" </div> <div> &gt;SET? [NO] [YES] </div> </div>
③ Collimate the target	Collimate	

④Press the <b>F4</b> (YES) key to finish holding the horizontal angle, the display turns back to the normal angle measurement mode	<b>F4</b>	
*To return to the previous mode, press the ESC key.		

4.3.2 Setting the Horizontal Angle from the Keypad







Make sure the angle measurement mode is selected.

Operation procedure	Operation	Display
①Collimate the target	Collimate	
②Press the <b>F3</b> (HSET) key	<b>F3</b>	

<p>③Input the required horizontal angle by using the keys, for example : 150°10'20", inputs 150.1020(Not to input [.] between minute and second)</p> <p>Press <b>ENT</b></p> <p>Carry on normal measurement after entering the required horizontal angle</p>	<p>150.1020</p> <p><b>ENT</b></p>	<div> <div> PSM -30 PPM 0.0    </div> <div> H ANGLE SET  HR = 150.1201 </div> <div> BACK </div> </div> <div> <div> PSM -30 PPM 0.0    </div> <div> V : 95° 30' 55"  HR : 65° 45' 30" </div> <div> OSET HOLD HSET P1↓ </div> </div>
--	-----------------------------------	--

4.4 Vertical Angle Percent Grade (%) Mode

Make sure the angle measurement mode is selected.



Operation procedure	Operation	Display
Press <b>F4</b> key to get the function on menu page P2	<b>F4</b>	<div> <div> PSM -30 PPM 0.0    </div> <div> V : 95° 30' 55"  HR : 65° 45' 30" </div> <div> OSET HOLD HSET P1↓ </div> </div> <div> TILT V% P2↓ </div>
Press the <b>F3</b> ( V% ) key *	<b>F3</b>	<div> <div> PSM -30 PPM 0.0    </div> <div> V : -11.70 %  HR : 65° 45' 30" </div> <div> TILT V% P2↓ </div> </div>

\*Each time the **F3** ( V% ) key is pressed the display mode switches.

When the angle measured is over 45 ° ( 100% ) from the horizontal <OVERTOP> is displayed.


## 4.5 Setting the Initial Zenith Angle

Vertical angle is displayed as shown below:



Make sure the angle measurement mode is selected.

Operation procedure	Operation	Display
Press <b>F4</b> key twice to get the menu on page 3 (P3) :	<b>F4</b> twice	<div> <div> PSM -30 PPM 0.0 </div> <div> V : 95° 30' 55" HR : 65° 45' 30" </div> <div> OSET HOLD HSET P1↓ </div> <div> R/L CMPS P3↓ </div> </div>

Press the <b>F3</b> ( CMPS ) key *	<b>F3</b>	 <p>The screenshot shows the following information on the LCD:</p> <ul style="list-style-type: none"> <li>Top row: <b>PSM</b> -30, <b>PTM</b> 0.0, a signal icon, a battery icon, and a full bar icon.</li> <li>Second row: <b>V</b> : 95° 30' 55"</li> <li>Third row: <b>HR</b> : 65° 45' 30"</li> <li>Bottom row: <b>R/L</b>, a black box, <b>CMPS</b>, and <b>P3↓</b>.</li> </ul>
* Each time the <b>F3</b> key is pressed the display mode switches.		

## 5. DISTANCE MEASUREMENT

When setting the atmospheric correction obtain the correction value by measuring the temperature and pressure.

### 5.1 Setting of the Atmospheric Correction

When setting the atmospheric correction obtain the correction value by measuring the temperature and pressure. Refer to Section 3.2 “Setting of the Atmospheric Correction”.





### 5.2 Setting of the Correction for Prism Constant

The instrument is preset for a Prism Constant value of -30mm at the factory. If the prism is of another constant the instrument needs to be updated with this constant. Refer to

Chapter 3.3 “Setting of the Prism Constant”. The updated value is kept in the instrument memory after the power is shut off.

5.3 Distance Measurement (Continuous Measurement)

Make sure the angle measurement mode is selected.




Operation procedure	Operation	Display
Collimate the center of prism *1	Collimate	<div><div>PSM -30PPM 0.0</div><div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div></div><div>OSETHOLDHSETP1↓</div></div>
Press the  key, distance measurement starts *2 *3;		<div><div>PSM -30PPM 0.0</div><div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>SD : [N]m</div></div><div>MEASMODES/AP1↓</div></div>
③The measured distances are shown (*4,*7) By pressing the  key again the display changes to horizontal (HR), vertical (V) angle, vertical distance (VD) and slope distance (SD)		<div><div>PSM -30PPM 0.0</div><div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>HD : [N]m</div><div>VD : [N]m</div></div><div>MEASMODES/AP1↓</div></div>


















- \*1 ) The total station prism mode collimate center of prism when measuring ;
- \*2 ) When EDM is working, the “\*” mark appears in the display. The total stations will display “weak signal” when measuring if the signal is weak.
- \*3 ) To change the mode from Fine to Tracking, refer to section 5.4 “Fine mode / Tracking Mode”. To set the distance measurement on when the instrument is powered up, refer to Chapter 11 “Basic Settings”.
- \*4 ) The distance unit indicator "m" (for meter) or “ft” (for feet) appears and disappears alternatively with a buzzer sounding at every renewal of distance data.
- \*5 ) Measurement may repeat automatically in the instrument if the result is affected by external factors\*.
- \*6 ) To return to the angle measuring angle mode from the distance-measuring mode, press the **ANG** key.
- \*7 ) It is possible to choose the display order (HR,HD,VD) or (V, HR,SD) for initial measuring mode. Refer to Chapter 11 "Basic Settings".

## 5.4 Changing the Distance Measurement Mode

(Repeat Measurement / Single Measurement/  
Track Measurement)

Make sure the angle measurement mode is selected.

Operation procedure	Operation	Display
Collimate the center of the prism	Collimate	<div> <div>FSM -30</div> <div>PPM 0.0</div> <div>    </div> <div>V : 95° 30' 55"</div> <div>HR : 65° 45' 30"</div> <div> <div>OSET</div> <div>HOLD</div> <div>HSET</div> <div>P1↓</div> </div> </div>

<p>Press the  key ,Continuous Measurement begins *1 ;</p>		<div> <div> PSM -30 PPM 0.0    </div> <div> V : 95° 30' 55" </div> <div> HR : 65° 45' 30" </div> <div> SD : [N] m </div> <div> MEAS MODE S/A P1↓ </div> </div>
<p>Press the  (MODE) key to switch between Repeat Measurement, Single Measurement and Tracking Measurement. [N], [1], [T]</p>	 	<div> <div> PSM -30 PPM 0.0    </div> <div> V : 95° 30' 55" </div> <div> HR : 65° 45' 30" </div> <div> SD : [N] m </div> <div> MEAS MODE S/A P1↓ </div> </div> <div> <div> PSM -30 PPM 0.0    </div> <div> V : 95° 30' 55" </div> <div> HR : 65° 45' 30" </div> <div> SD : [1] m </div> <div> MEAS MODE S/A P1↓ </div> </div> <div> <div> PSM -30 PPM 0.0    </div> <div> V : 95° 30' 55" </div> <div> HR : 65° 45' 30" </div> <div> SD : [T] m </div> <div> MEAS MODE S/A P1↓ </div> </div>












## 5.5 Stake Out (S.O.)

The difference between the measured distance and the input stake out distance is displayed.

Measured distance - Stake out distance = Displayed value

In a stake out operation you can select either horizontal distance (HD), relative elevation (VD), and slope distance (SD.)

Operation procedure	Operation	Display
Press the <b>F4</b> (↓) key in the distance measuring mode to menu P2	<b>F4</b>	<p>PSM -30 PPM 0.0 0.0 0.0 0.0 0.0 0.0</p> <p>V : 95° 30' 55"</p> <p>HR : 65° 45' 30"</p> <p>SD : 156.320 m</p> <p>MEAS MODE S/A P1↓</p> <p>ORSET S.O m/ft P2↓</p>
Press the <b>F2</b> (S.O) key The data previously set is shown	<b>F2</b>	<p>PSM -30 PPM 0.0 0.0 0.0 0.0 0.0 0.0</p> <p>STAKE OUT</p> <p>HD: 0.000 m</p> <p>BACK HD VD SD</p>
Select the measuring mode by pressing the <b>F2</b> to <b>F4</b> keys. F2:HD, F3:VD, F4:SD	<b>F1</b>	<p>PSM -30 PPM 0.0 0.0 0.0 0.0 0.0 0.0</p> <p>STAKE OUT</p> <p>SD: 0.000 m</p> <p>BACK HD VD SD</p>

Enter the distance 350 , press <b>F4</b>	Enter 350 <b>F4</b>	<div> <div> PSM -30 PPM 0.0    </div> <div>STAKE OUT</div> <div>SD: 350 m</div> <div> BACK HD VD SD </div> </div>
Collimate the target (Prism), measurement starts. The difference between the measured distance and the stake out distance is displayed.	Collimate Prism	<div> <div> PSM -30 PPM 0.0    </div> <div> V : 95° 30' 55"  HR : 65° 45' 30"  SD : 10.250 m </div> <div> MEAS MODE S/A P1↓ </div> </div>
Move the target until the difference becomes 0.		<div> <div> PSM -30 PPM 0.0    </div> <div> V : 95° 30' 55"  HR : 65° 45' 30"  SD : 0.000 m </div> <div> MEAS MODE S/A P1↓ </div> </div>
To return to normal distance measurement mode, stake out distance to “0” or switch to other measurement mode.		

## 5.6 Offset Measurement

There are four offset measurement modes:


1. Angle offset
2. Distance offset
3. Plane offset
4. Column offset

### 5.6.1 Angle Offset

This mode is useful when it is difficult to set up the prism directly on target; for example at the center of a tree. Place the prism at the same horizontal distance from the instrument as that of point A0 to measure. To measure the coordinates of the center position use the offset measurement after setting the instrument height/prism height.





When measuring coordinates of ground point A1: Set the instrument height/Prism height

















When measuring coordinates of point A0: Set the instrument height only (Set the prism height to 0)



Set the instrument height/prism height before proceeding to the offset measurement mode.


When setting the coordinate value for the occupied station, refer to Section 6.2 “Setting Coordinate Values of an Occupied Point”.

Operation procedure	Operation	Display
Press the <b>[F4]</b> (↓) key from distance measuring mode to get the function on menu P2	<b>[F4]</b>	
Press <b>[F1]</b> (OFFSET) key	<b>[F1]</b>	
Press <b>[F1]</b> (ANG.OFFSET) key	<b>[F1]</b>	
Collimate prism P, and press the <b>[F1]</b> (MEAS) key.  The horizontal distance from the instrument to the prism will be measured.	Collimate  <b>[P]</b>  <b>[F1]</b>	

Collimate point AO using the horizontal motion clamp and horizontal tangent screw.	Collimate AO	<div> COLLIMATE OBJECT     HR : 65° 45' 30"  HD : 265.332 m  VD : 1.230 m  SD : 265.325 m     NEXT </div>
Show the north coordinate, east coordinate and z coordinate of waited measuring point by pressing  key.		<div> COLLIMATE OBJECT     N : 365.332 m  E : 15.300 m  Z : 1.230 m     NEXT </div>
<p>To return to procedure 3, press  (NEXT) key</p> <p>To return to the previous mode, press  key</p>		





## 5.6.2 Distance Offset Measurement

Measuring the distance and coordinate of a pond or a tree of which the radius is known. Measuring the distance or coordinate to P0 point, input oHD value as an offset value and measure P1 point as shown in the drawing. The display shows distance or coordinate value to P0 point.



When setting the coordinate value for the occupied station, refer to Section 6.2 ‘Setting Coordinate of Occupied Point’


Operation procedure	Operation	Display
① Press the <b>F4</b> (↓) key from distance measuring mode to get the function on menu P2	<b>F4</b>	<p>PSM -30 PPM 0.0</p> <p>V : 95° 30' 55"</p> <p>HR : 65° 45' 30"</p> <p>SD : 155.326 m</p> <p>MEAS MOD S/A P1↓</p> <p>OFST S.O m/ft P2↓</p>
② Press <b>F1</b> (OFSET) key.	<b>F1</b>	<p>OFFSET MEAS</p> <p>F1 : ANGLE OFFSET</p> <p>F2 : DISTANCE OFFSET</p> <p>F3 : PLANE OFFSET</p> <p>F4 : COLUMN OFFSET</p>
③ Press <b>F2</b> (DIST OFFSET) key, enter the measurement of DIST.OFFSET	<b>F2</b>	<p>DISTANCE OFFSET</p> <p>INPUT L OR RHD</p> <p>oHD: 0.000 m</p> <p>BACK</p>
④ Enter R HD, press <b>ENT</b> key *1	Enter R HD <b>ENT</b>	<p>DISTANCE OFFSET</p> <p>ENTER R HD</p> <p>oHD: m</p>

<p>⑤Enter forward HD , press <b>ENT</b> key *2</p>	<p>Enter forward HD <b>ENT</b></p>	
<p>⑥Collimate Prism P1, and press <b>F1</b> (MEAS) key.  Measuring will start.  After measuring, the result added offset value will be show.</p>	<p>Collimate  P1  <b>F1</b></p>	
<p>⑦Show the coordinate of Point P0</p>		
<p>To return to procedure 4,press <b>F1</b> (NEXT) key  To return to the previous mode, press <b>ESC</b> key  *1 ) *2 ) refer to section 8.3.2 “Distance Offset Measurement”</p>		

5.6.3 Plane Offset Measurement

Used to facilitate distance or coordinate measuring for a given plane.

Three random prism points (P1, P2, P3) on a plane will be measured at first in the plane-offset measurement to determine the measured plane. Collimate the measuring target point (P0) then the instrument will calculate and display coordinate and distance values of the cross point between collimation axis and the plane.








When setting the coordinate value for the occupied station, refer to Section 7.2 ‘Setting Coordinate Value of Occupied Point’.

Operation procedure	Operation	Display
① Press the <b>F4</b> (↓) key from distance measuring mode to get the function on page 2.	<b>F4</b>	<div><div><div>PSM -30</div><div>PPM 0.0</div><div></div><div></div></div><div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>SD : 226.306 m</div></div><div><div>MEAS</div><div>MODE</div><div>S/A</div><div>P1↓</div></div><div><div>OFST</div><div>S.O</div><div>m/ft</div><div>P2↓</div></div></div>




②Press <b>F1</b> (OFSET) key	<b>F1</b>	<div> <div> <div>OFFSET MEAS</div> <div> F1 : ANGLE OFFSET  F2 : DISTANCE OFFSET  F3 : PLANE OFFSET  F4 : COLUMN OFFSET </div> </div> <div> <div></div> <div></div> <div></div> <div></div> </div> </div>
③Press <b>F3</b> (PLANE OFSET) key	<b>F3</b>	<div> <div> <div>PSM -30 PPM 0.0</div> <div>PLANE OFFSET</div> <div>No 1 #</div> <div>HD : m</div> <div>MEAS</div> </div> <div> <div></div> <div></div> <div></div> </div> </div>
④Collimate Prism P1, and press <b>F1</b> (MEAS) key. N-time measuring will start. After measuring, the display will show the second point measurement.	Collimate P1 <b>F1</b>	<div> <div> <div>PSM -30 PPM 0.0</div> <div>PLANE OFFSET</div> <div>No 1 #</div> <div>HD : m</div> <div>MEAS</div> </div> <div> <div></div> <div></div> <div></div> </div> </div>
⑤Measure the second and third points in the same way.  The instrument calculates and displays coordinate and distance values of the cross point between the collimation axis and of the plane *1*2	Collimate P2 <b>F1</b>  Collimate P3 <b>F1</b>	<div> <div> <div>PSM -30 PPM 0.0</div> <div>PLANE OFFSET</div> <div>No 2 #</div> <div>HD * [N] m</div> <div>MEAS</div> </div> <div> <div></div> <div></div> <div></div> </div> </div> <div> <div> <div>PSM -30 PPM 0.0</div> <div>PLANE OFFSET</div> <div>No 3 #</div> <div>HD * [N] m</div> <div>MEAS</div> </div> <div> <div></div> <div></div> <div></div> </div> </div> <div> <div> <div>V : 95° 30' 55"</div> <div>HR : 65° 45' 30"</div> <div>HD : 147.150 m</div> <div>VD : 12.365 m</div> <div>SD : 123.769 m</div> <div></div> <div></div> <div></div> <div>NEXT</div> </div> </div>

⑥ Collimate the edge (P0) of the plane *3*4	Collimate P0	
<p>⑦ By pressing  key each time , horizontal distance, relative elevation and slope distance are shown in sequence.</p> <p>To show the coordinate of the point (P0), press  key.</p>		
<p>*1 ) In case the calculation of plane was not successful by the measured three points, error displays. Start measuring over again from the first point.</p> <p>*2 ) Data display is the mode beforehand of offset measurement mode.</p> <p>*3 ) Error will be displayed when collimated to the direction which does not cross with determined plane.</p> <p>*4 ) The reflector height of the target point P0 is set to zero automatically.</p>		

5.6.4 Column Offset Measurement

If it is possible to measure circumscription point (P 1) of Column directly the distance to the center of the column (P0), coordinate and direction angle can be calculated by measured circumscription points (P2) and (P3).




















The direction angle of the center of the column is 1/2 of total direction angle of circumscription points (P2) and (P3).



When setting the coordinate value for the occupied station, refer to Section 6.2 ‘Setting Coordinate Values of Occupied Point’.

Operation procedure	Operation	Display
Press the <b>F4</b> (↓) key from distance measuring mode to get the function on menu P2	<b>F4</b>	<div><div><div>PSM -30</div><div>PPM 0.0</div><div>3</div><div><div><div></div><div></div><div></div><div></div><div></div><div></div></div></div></div><div>V : 95° 30' 55"</div><div>HR : 65° 45' 30"</div><div>SD : 106.306 m</div><div><div>MEAS</div><div>MODE</div><div>S/A</div><div>P1↓</div></div><div><div>OFST</div><div>S.O</div><div>m/ft</div><div>P2↓</div></div></div>

Press <b>F1</b> (OFFSET) key	<b>F1</b>	<div> <div>OFFSET MEAS</div> <div> F1 : ANGLE OFFSET  F2 : DISTANCE OFFSET  F3 : PLANE OFFSET  F4 : COLUMN OFFSET </div> </div>
Press <b>F4</b> (COLUMN OFFSET)key	<b>F4</b>	<div> <div> PSM -30 PPM 0.0 </div> <div>COLUMN OFFSET</div> <div>CENTER</div> <div>HD : m</div> <div>MEAS</div> </div>
Collimate the center of the column (P1) and press <b>F1</b> (MEAS) key N-time measuring will start. After the measurement, angle-measuring display of the left side (P2) will be shown.	Collimate P1 <b>F1</b>	<div> <div> PSM -30 PPM 0.0 </div> <div>COLUMN OFFSET</div> <div>CENTER</div> <div>HD* [N] m</div> <div>MEAS</div> </div>
Collimate the left side of column(P2) and press <b>F4</b> (SET) key. After measurement, angle measuring display of the right side (P3) will be shown.	Collimate P2 <b>F4</b>	<div> <div> PSM -30 PPM 0.0 </div> <div>COLUMN OFFSET</div> <div>LEFT</div> <div>HR : 65° 45' 30"</div> <div>SET</div> </div>

<p>⑥Collimate the right side of the column (P3) and press <b>F4</b> (SET) key.</p> <p>After measurement, the distance between the instrument and the center of column (P0) will be calculated.</p>	<p>Collimate</p> <p>P3</p> <p><b>F4</b></p>	<div data-bbox="613 140 960 336"> <div>PSM -30 PPM 0.0   </div> <div>COLUMN OFFSET RIGHT HR : 65° 45' 30"</div> <div>   <b>SET</b></div> </div> <div data-bbox="613 357 960 553"> <div>COLUMN OFFSET  </div> <div>HR : 65° 45' 30"</div> <div>HD : 265.332 m</div> <div>VD : 1.230 m</div> <div>SD : 265.325 m</div> <div>   <b>NEXT</b></div> </div>
<p>To show the coordinate of point P0 , press  key.</p> <p>*1*2</p>	<p></p>	<div data-bbox="613 608 960 804"> <div>COLLIMATE OBJECT   </div> <div>N : 365.332 m</div> <div>E : 15.300 m</div> <div>Z : 1.230 m</div> <div>   <b>NEXT</b></div> </div>

\*1 ) To return to procedure 5, press **F4** (NEXT) key

\*2 ) To escape the measuring , press **ESC** key , the display returns to the previous mode.

## 6. COORDINATE MEASUREMENT

### 6.1 Execution of Coordinate Measurement

Measure the coordinates by entering the instrument height and prism height, coordinates of unknown Point will be measured directly.

\* When setting coordinate values of occupied point, see Section 6.2 “Setting Coordinate Values of Occupied Station Point”.

\* When setting the instrument height and prism height, see Section 6.3 “Setting Height of the Instrument” and 6.4 “Setting Height of Target (prism Height)”.

\* To set backsight, determine the backsight azimuth or check the known azimuth, coordinate and distance.

The coordinates of the unknown point are calculated as shown below and displayed :

Coordinates of occupied point : (  $N_0$  ,  $E_0$  ,  $Z_0$  )

Instrument height :  $INS.HT$

Prism height:  $R.HT$

Vertical distance (Relative elevation) :  $Z$  (  $VD$  )

Coordinates of the center of the prism, originated from the center point of the instrument : (  $n$  ,  $e$  ,  $z$  )


Coordinates of unknown point : (  $N_1$  ,  $E_1$  ,  $Z_1$  )

$$N_1 = N_0 + n$$



$$E_1 = E_0 + e$$

$$Z_1 = Z_0 + INS.HT + Z - R.HT$$

Center point of the instrument ( $N_0$ ,  $E_0$ ,  $Z_0 + INS.HT$ )




When doing coordinate measurement you need to input coordinates of occupied point, instrument height, the prism height and back sight azimuth.

Operation procedure	Operation	Display
Set the direction angle of known point A *1 )	Set direction angle	<div> <div>PSM -30 PPM 0.0</div> <div> <div> <div></div> <div></div> <div></div> </div> <div> <div></div> <div></div> <div></div> </div> </div> <div> V : 95° 30' 55" HR : 65° 45' 30" </div> <div> <div>OSET</div> <div>HOLD</div> <div>HSET</div> <div>P1↓</div> </div> </div>
Collimate target prism B, and press  key	Collimate target prism 	<div> <div>PSM -30 PPM</div> <div> <div></div> <div></div> <div></div> </div> <div> <div></div> <div></div> <div></div> </div> </div> <div> N : 365.332 m E : 15.300 m Z : 1.230 m </div> <div> <div>MEAS</div> <div>MODE</div> <div>S/A</div> <div>P1↓</div> </div>
<p>*1Refer to Section 4.3 “Setting of Horizontal Angle”.</p> <p>In case the coordinate of instrument point is not entered, (0,0,0) will be used as the default for the instrument point. The prism height will be calculated as 0 when the prism height is not set.</p>		

## 6.2 Setting Coordinate Values of Occupied Point
















Set the coordinates of the instrument (occupied point) according to known values and the instrument automatically converts and displays the unknown point (prism point) coordinates following the observation.

The instrument retains the coordinates of the occupied point after turning the power off.






Operation procedure	Operation	Display
Press the <b>F4</b> (P1↓) key from the coordinate measurement mode to get the function on menu P2.	<b>F4</b>	<div> <div> PSM -30 PFM 0.0 </div> <div> N : 365,332 m  E : 15,300 m  Z : 1,230 m </div> <div> MEAS MODE S/A P1↓ </div> <div> R.HT INSHT OCC P2↓ </div> </div>
Press the <b>F3</b> ( OCC ) key	<b>F3</b>	<div> COLLIMATE OBJECT </div> <div> N : 0.000 m  E : 0.000 m  Z : 0.000 m </div> <div> BACK </div>





③Enter N coordinate value	Enter data <div>ENT</div>	<div> <div>PSM -30 PPM 0.0   </div> <div>N 6396_ m</div> <div>E : 0.000 m</div> <div>Z : 0.000 m</div> <div>BACK   </div> </div>
④ Enter E and Z coordinate values in the same manner. After entering the values, the display returns to the coordinate measuring display menu.	Enter data <div>ENT</div>	<div> <div>PSM -30 PPM 0.0   </div> <div>N : 365.332 m</div> <div>E : 15.300 m</div> <div>Z : 1.230 m</div> <div>BACK   </div> </div> <div> <div>PSM -30 PPM 0.0   </div> <div>N : 365.332 m</div> <div>E : 15.300 m</div> <div>Z : 1.230 m</div> <div>R.HT INSHT OCC P2↓</div> </div>
Input range : -999999.999m/ft ≤N、E、Z ≤ +999999.999m/ft		

### 6.3 Setting Height of the Instrument


The instrument height value will be retained after the instrument is powered off.



Operation procedure	Operation	Display
Press the <div>F4</div> (P1↓) key from the coordinate measurement mode to access the P2 menu screen.	<div>F4</div>	<div> <div>PSM -30 PPM 0.0   </div> <div>N : 365.332 m</div> <div>E : 15.300 m</div> <div>Z : 1.230 m</div> <div>MEAS MODE S/A P1↓</div> <div>R.HT INSHT OCC P2↓</div> </div>

<p>② Press the <b>F2</b> (I.HT) key, The current value is displayed.</p>	<p><b>F2</b></p>	
<p>Enter the instrument height and press the <b>ENT</b> key to get to the coordinate measuring display</p>	<p>Enter the I.H. <b>ENT</b></p>	
<p>Input range :  —999.999≤INS.HT≤+999.999m</p>		

### 6.4 Setting Height of Target (Prism Height)

This mode can be used to obtain z coordinate values. The target height value will be retained after the instrument is powered off.

Operation procedure	Operation	Display
<p>Press the <b>F4</b> (P1↓) key from the coordinate measurement mode to access the P2 menu screen.</p>	<p><b>F4</b></p>	

<p>②Press the <b>[F1]</b> (R.HT) key</p> <p>The current value is displayed.</p>	<p><b>[F1]</b></p>	
<p>Enter the prism height, then press the <b>[ENT]</b> key to get to the coordinate measuring display</p>	<p>Enter the prism height</p> <p><b>[ENT]</b></p>	
<p>Input range :</p> <p style="text-align: center;">—999.999m≤prism height≤+999.999m/ft</p>		

## 7. SURVEYING PROGRAM


Surveying Program Mode (programs)

By pressing the menu key **[M]**, the instrument will be in Menu Mode.

### 7.1 Remote Elevation Measurement ( REM )






To obtain elevation of the point at which setting the target prism is not possible, place



the prism at any point on the vertical line from the target then carry out REM procedure as follows.





1 ) With prism height (h) input







Operation procedure	Operation	Display
Press the <b>M</b> Key	<b>M</b>	<div><div>MENU<div><div></div><div></div></div><div>F1 : COLLECT DATA</div><div>F2 : MEAS PROGRAM</div><div>F3 : MEMORY MGR</div><div>F4 : CONFIG</div><div></div></div></div>
Press the <b>F2</b> key , enter MEAS PROGRAM. menu	<b>F2</b>	<div><div>MEAS PROGRAM<div><div></div><div></div></div><div>F1 : REM</div><div>F2 : MLM</div><div>F3 : AREA</div><div>F4 : ZCOORDINATE</div><div></div></div></div>

③ Press the <b>F1</b> ( REM ) key	<b>F1</b>	
④ Press the <b>F1</b> key	<b>F1</b>	
⑤ Enter prism height (1.3 is an example in meters)	<b>F1</b> Enter prism height 1.3 <b>F4</b>	
⑥ Collimate prism	Collimate Prism	
⑦ Press the <b>F1</b> (MEAS) key, measurement starts. Horizontal distance (HD) between the instrument and prism will be shown.	<b>F1</b>	

<p>⑧ Press the <b>F4</b> (SET)</p> <p>The prism position will be decided.</p>	<b>F4</b>	
<p>⑨ Collimate target K. Vertical distance (VD) will be shown.</p>	Collimate K	
<p>To return to procedure 5, press <b>F2</b> (R.HT) key.</p> <p>To return to procedure 6, press <b>F3</b> (HD) key.</p> <p>To return to PROGRAMS Menu, press the <b>ESC</b> key.</p>		

## 2 ) Without prism height input

Operation procedure	Operation	Display
Press the <b>M</b> menu key	<b>M</b>	
Press the <b>F2</b> key , enter the measure programs menu.	<b>F2</b>	

③Press the <b>F1</b> (REM) Key.	<b>F1</b>	
④Press the <b>F2</b> key to select the mode without prism height.	<b>F2</b>	
Collimate prism, press the <b>F1</b> (MEAS) key. Measuring starts. Horizontal distance (HD) between the instrument and target will be shown..	Collimate target	
⑥Press the <b>F4</b> (SET) The target position will be decided.	<b>F4</b>	
Collimate ground point G , press the <b>F4</b> (SET) key. The position of point G will be decided	<b>F4</b>	
Collimate target K Vertical distance (VD) will be shown	Collimate K	

To return to procedure 5, press the **F3** (HD) key.

To return to procedure 6, press the **F2** (V) key.

To return to PROGRAMS Menu, press the **ESC** key.


## 7.2 Missing Line Measurement (MLM)

Measurement for horizontal distance (dHD) , slope distance (dSD),elevation (dVD) and horizontal bearing (HR) between two target prisms.

It is possible to enter the coordinate value directly or calculate from coordinate data file.

MLM Mode has two modes:

1. MLM-1 (A-B, A-C): Measurement A-B, A-C, A-D
2. MLM-2 (A-B, B-C): Measurement A-B, B-C, C-D












It is necessary to set the direction angle of the instrument.







[Example] MLM-1 (A-B, A-C)

Procedure of MLM-2 ( A-B , B-C ) mode is completely the same as that of MLM-1 mode.

Operation procedure	Operation	Display
①Press the <b>M</b> menu key	<b>M</b>	 <p>MENU <span style="float: right;">■■■ <b>III</b></span></p> <p>F1 : COLLECT DATA</p> <p>F2 : PROGRAMS</p> <p>F3 : MEMORY MGR</p> <p>F4 : CONFIG</p> <p style="text-align: right;">↓</p>
②Press the <b>F2</b> key, enter MEAS PROGRAMS	<b>F2</b>	 <p>MEAS PROGRAM <span style="float: right;">■■■ <b>III</b></span></p> <p>F1 : REM</p> <p>F2 : MLM</p> <p>F3 : AREA</p> <p>F4 : ZCOORDINATE</p> <p style="text-align: right;">↓</p>
③Press the <b>F2</b> (MLM) key	<b>F2</b>	 <p>SELECT A FILE <span style="float: right;">■■■ <b>III</b></span></p> <p>FN: 1</p> <p><b>BACK</b> <b>LIST</b> <b>CHAR</b> <b>JUMP</b></p>
④Enter file name	Enter file name	 <p>SELECT A FILE <span style="float: right;">■■■ <b>III</b></span></p> <p>FN: ABC</p> <p><b>BACK</b> <b>LIST</b> <b>CHAR</b> <b>JUMP</b></p>















⑤ Press <b>ENT</b> key.	<b>ENT</b>	
⑥ Press the <b>F1</b> key	<b>F1</b>	
⑦ Collimate prism A, and press the <b>F1</b> (MEAS) key.  Horizontal distance (HD) between the instrument and target A will be shown.	Collimate  A  <b>F1</b>	
⑧ Press the <b>F4</b> (SET) key  The position of the target is confirmed.	<b>F4</b>	
⑨ Collimate prism B and press the <b>F1</b> (MEAS) key. Horizontal distance (HD) between the instrument and target B will be shown..	Collimate  B  <b>F1</b>	

<p>⑩ Press the <b>F4</b> (SET) key</p> <p>The horizontal distance (dHD) and relative elevation (dVD) between target A and B.</p>	<b>F4</b>	
<p>(11) To measure the distance between points A and C, press the <b>F4</b> (NEXT) key*1 )</p>	<b>F4</b>	
<p>(12) Collimate point C (target C) and press the <b>F1</b> (MEAS) key.</p> <p>Horizontal distance (HD) between the instrument and target C will be shown.</p>	Collimate C <b>F1</b>	
<p>(13) Press the <b>F4</b> (SET) key. The horizontal distance (dHD) and relative elevation (dVD) between target A and C will be shown</p>	<b>F4</b>	
<p>(14) To measure the distance between points A and D, repeat procedure 12 to 14 *</p>		
<p>*To return to Previous mode , press the <b>ESC</b> key.</p>		

HOW TO USE COORDINATE DATA

It is possible to input coordinate values directly or calculate from a coordinate data file.

[Example] Input the data (NEZ) directly:

Operation procedure	Operation	Display
① Press the <b>F3</b> (NEZ) key	<b>F3</b>	<div><div>FSM -30 PPM 0.0  </div><div>MLM1 [A-B A-C]</div><div>&lt;STEP-1&gt;</div><div>HD : m</div><div>MEAS R.HT NEZ </div></div> <div><div>MLM  </div><div>PT# : </div><div>BACK LIST CHAR NEZ</div></div>
② Press the <b>F4</b> (coordinate) key	<b>F4</b>	<div><div>MLM  </div><div>N : 0.000 m</div><div>E : 0.000 m</div><div>Z : 0.000 m</div><div>BACK   </div></div>
③ Enter coordinate, press <b>ENT</b> key to get to the second point.	<b>ENT</b>	<div><div>FSM -30 PPM 0.0  </div><div>MLM1 [A-B A-C]</div><div>&lt;STEP-1&gt;</div><div>HD : m</div><div>MEAS R.HT NEZ </div></div>

\*To return to PROGRAMS Menu, press the ESC key.

### 7.3 Area Calculation

This mode calculates the area of an enclosed figure.

There are two area calculation methods as follows:

- 1) Area calculation from Coordinate data file
- 2) Area calculation from measured data

Note :





Area is not calculated correctly if observed lines cross each other.






It is not possible to calculate area from a mix of coordinate file data and measured data.

The number of points used for calculation is not limited.






The area to be calculated shall not exceed 200000 sqm. (approx. 49 acres)



**1) Area calculation from Coordinate data file**

Operation procedure	Operation	Display
①Press <b>M</b> menu key	<b>M</b>	<div><div>MENU (1/2)  </div><div>F1 : COLLECT DATA</div><div>F2 : PROGRAMS</div><div>F3 : MEMORY MGR</div><div>F4 : CONFIG</div><div>↓</div></div>
②Press the <b>F2</b> key, enter the Measurement Program.	<b>F2</b>	<div><div>MEAS PROGRAM  </div><div>F1 : REM</div><div>F2 : MLM</div><div>F3 : AREA</div><div>F4 : ZCOORDINATE</div><div>↓</div></div>

③Press <b>F3</b> (AREA) key	<b>F3</b>	
Press <b>F1</b> (FILE DATA) key	<b>F1</b>	
Enter file name or press F2 for LIST. Press <b>ENT</b> key, Initial display will be shown .	Enter File name <b>ENT</b>	
⑥Press <b>F4</b> (NEXT) key The top of the file data (DATA-01) will be set and the second point number will be shown.	<b>F4</b>	
Repeat pressing <b>F4</b> (NEXT) key to set required number of the points. When 3 points are set, the area surrounded by the points is calculated and the result will be shown.	<b>F4</b>	
<p>* To set the required point number, press <b>F1</b> (PT#) key.</p> <p>* To show the list of the coordinate data in the file, press <b>F2</b> (LIST) key.</p>		

## 2) Area calculation from measured data

Operation procedure	Operation	Display
① Press <b>[M]</b> menu key	<b>[M]</b>	
② Press the <b>[F2]</b> key, enter the Measurement Program.	<b>[F2]</b>	
③ Press <b>[F3]</b> (AREA) key	<b>[F3]</b>	
Press the <b>[F2]</b> (MEASUREMENT) key	<b>[F2]</b>	
Collimate a target or prism and press the <b>[F1]</b> (MEAS) key. Measuring starts *	Collimate Prism <b>[F1]</b>	

Press the <b>F4</b> key to affirm	<b>F4</b>	
⑦ Collimate a next prism and press <b>F1</b> (MEAS) key. When 3 points are set, the area surrounded by the points is calculated and the result will be shown.	Collimate <b>F1</b>	
*1 Measurement is N-time measurement mode.		

## 7.4 Setting Z Coordinate of Occupied Point

Occupied point coordinate data and known point actual measuring data can be utilized, zcoordinate of occupied point is calculated and reset.

Known point data from a coordinate file can used.



1 ) Setting z coordinate of occupied point

[Example setting] Using coordinate data file







Operation procedure	Operation	Display
① Press the <b>M</b> menu key	<b>M</b>	<div><div>MENU ( 1 / 2 )<div><div></div><div></div></div></div><div>F1 : COLLECT DATA</div><div>F2 : PROGRAMS</div><div>F3 : MEMORY MGR</div><div>F4 : CONFIG</div><div>↓</div></div>
② Press the <b>F2</b> key ,enter PROGRAMS	<b>F2</b>	<div><div>MEAS PROGRAM<div><div></div><div></div></div></div><div>F1 : REM</div><div>F2 : MLM</div><div>F3 : AREA</div><div>F4 : ZCOORDINATE</div><div>↓</div></div>
③ Press the <b>F4</b> (Z COORDINATE key	<b>F4</b>	<div><div>SELECT A FILE<div><div></div><div></div></div></div><div>FN: 1</div><div>BACKLISTNUMBJUMP</div></div>
④ Enter the File Name then press <b>ENT</b> to affirm.	Input File Name <b>ENT</b>	<div><div>ZCOORD. MEAS<div><div></div><div></div></div></div><div>F1 : INPUT OCC. PT#</div><div>F2 : REF. MEAS</div></div>
Press the <b>F2</b> (REF. MEAS) key and enter the point number (press <b>F2</b> for LIST)	<b>F2</b>	<div><div>ZCOORD. MEAS<div><div></div><div></div></div></div><div>PT# :</div><div>BACKLISTCHARNEZ</div></div>

<p>After input the PT#, press the <b>ENT</b> key, the coordinate of this point is shown.</p>	<p><b>ENT</b></p>	
<p>⑦ Press the <b>F4</b> (YES) key to confirm instrument height setting display will be shown.</p>	<p><b>F4</b></p>	
<p>Enter the instrument height, press <b>ENT</b> key. Press <b>F1</b> (MEAS) for observation results</p>	<p>Enter INS.HT <b>ENT</b></p>	
<p>For more information about data file, see chapter 10 “Memory Management Mode”.</p>		

## 2 ) Z coordinate calculation from known point measuring data

[Example setting] Using coordinate data file.


Operation procedure	Operation	Display
Press the <b>M</b> menu key	<b>M</b>	
Press the <b>F2</b> key, enter MEAS PROGRAMS.	<b>F2</b>	
Press the <b>F4</b> (Z COORDINATE) key	<b>F4</b>	
Enter the File Name then press <b>ENT</b> to affirm.	INPUT File Name <b>ENT</b>	
⑤ Press the <b>F2</b> key	<b>F2</b>	





⑥Enter the point number in coordinate data file, press <b>ENT</b> to affirm.	Enter PT# <b>ENT</b>	
⑦Press the <b>F4</b> (YES) key to affirm	<b>F4</b>	
⑧Enter the height then press the <b>ENT</b> to affirm.	Enter R.HT <b>ENT</b>	
⑨Collimate a prism on the point and press the <b>F1</b> (MEAS)key. Measuring starts *1	Collimate P <b>F1</b>	 
⑩Press the <b>F4</b> (CAL) key *2 Z: Z coordinate	<b>F4</b>	





(1) Press the <b>F4</b> (SET) key *3 Z coordinate of the occupied point will be set. Backsight point measuring screen will be shown.	<b>F4</b>	
(2) Press the <b>F4</b> (YES) key. Horizontal angle will be set. The display returns to Measurement Programs menu.	<b>F4</b>	
<p>*1 Measurement is Fine Single measurement mode.</p> <p>*2 To measure other points, press the <b>F1</b> (NEXT) key.</p> <p>*3 Pressing the <b>F1</b> or <b>F3</b> key, the display will be changed alternately.</p>		





### 7.5 Point to Line Measurement

This program allows you to define a coordinate system by two points (p1 and p2), then measure them and calculate the relative coordinate of occupied point (station point, OCC) and other target points (P).



Operation procedure	Operation	Display
① Press the <b>M</b> menu key.	<b>M</b>	 <p>MENU</p> <p>F1 : COLLECT DATA</p> <p>F2 : PROGRAMS</p> <p>F3 : MEMORY MGR</p> <p>F4 : CONFIG</p> <p>↓</p>
② Press the <b>F2</b> key for the Measure Program menu.	<b>F2</b>	 <p>MEAS PROGRAM</p> <p>F1 : REM</p> <p>F2 : MLM</p> <p>F3 : AREA</p> <p>F4 : ZCOORDINATE</p> <p>↓</p>
③ Press the <b>▼</b> key.	<b>▼</b>	 <p>MEAS PROGRAM</p> <p>F1 : POINT TO LINE</p> <p>F2 : ROAD MEASURE</p> <p>F3 : LAYOUT</p> <p>F4 : RESECTION</p> <p>↑</p>
④ Press <b>F1</b> (POINT TO LINE) key.	<b>F1</b>	 <p>INPUT INS .HT</p> <p>.HT 0.000 m</p> <p>BACK</p>

<p>⑤ Input instrument height. Press <b>ENT</b>.</p>	<p>Input INS.HT <b>ENT</b></p>	
<p>⑥ Input prism height of point P1. Press <b>ENT</b>.</p>	<p>Enter R.HT <b>ENT</b></p>	
<p>⑦ Sight at P1 and press <b>F1</b> (MEAS) key. When measurement result is shown, press <b>F4</b> <b>YES</b>. It will ask you to input prism height of P2.</p>	<p>Sight at P1, <b>F1</b> , <b>F4</b></p>	
<p>⑧ Input prism height of P2. Press <b>ENT</b>.</p>	<p>Input R.HT <b>ENT</b></p>	

<p>⑨Sight at P2 and press <b>F1</b> (MEAS) key. When measurement result is shown, press <b>F4</b> <b>YES</b>, the distance between P1 and P2 will be shown.</p> <p>Press <b>F2</b> <b>OCC</b> you can see occupied point coordinate.</p>	<p>Sight at P2</p> <p><b>F1</b></p> <p><b>F4</b></p>	 
<p>⑩Sight at point P, Press <b>F1</b> <b>NEZ</b> key to measure target point P.</p>	<p>Sight at point P</p> <p><b>F1</b></p>	
<p>(11)Sight at prism at point P, press <b>F4</b> (MEAS). Measurement result will be shown.</p>	<p><b>F4</b></p>	



## 7.6 Road Construction

By using this program you can define a straight line, a curve, or a transition curve as a reference to make a measurement and set out. This program will do the computation of coordinates and setting out of the design point according to the stake number and deviation which are defined by the roads design.

In order to use this program the observation station coordinates and backsight azimuth angle need to be set.



### 7.6.1 Design: Horizontal Alignment

Horizontal alignment consisted of following elements: start point, straight line, circular curve , transition curve, INTG, WIDE and PEG.

The define option will prompt for the start details ( chainage , NEZ , starting azimuth ) .

START POINT			
PEG :	0.000		
X/Y :	0.000	m	
Y/E :	0.000	m	
AZI :	0.000	m	
BACK			









Enter these details in the screen, press [ENT] key to show the mail input routine screen :





H-LINE	1		
PEG	: 30.000		m
AZIH	: 23.2340		
Ne	: 68.438		m
Ee	: 32.236		m
<div> <div>LINE</div> <div>ARC</div> <div>SPIR</div> <div>P1↓</div> </div>			

top right corner of the screen shows the number of horizontal alignment.

The main line input screen displays current chainage and the bearing angle (the tangent line from the chainage) and the function key (For creating new line). System provides three functions: defining straight line, circular curve, transition curve. Select a function key, enter the detailed information of the chainage, the alignment elements will be created. Press **ENT** key, the new chainage and bearing angle will be calculated automatically and the main alignment screen will be restored. Now other line style can be defined, the new elements can be added only in the end of the original alignment file.

Operation procedure is as follows :


Operation procedure	Operation	Display
In main menu, press <b>F2</b> key to get MEAS PROGRAM menu, press <b>F4</b> key to get second page of MEAS PROGRAM menu.	<b>F2</b> <b>F4</b>	 <p>PROGRAMS  </p> <p>F1 : POINT TO LINE</p> <p>F2 : POAD MEASURE</p> <p>F3 : LAYOUT</p> <p>F4 : RESECTION</p> <p>↑</p>
Press <b>F2</b> ( ROAD MEASURE ) key	<b>F2</b>	 <p>SELECT A FILE  </p> <p>FN: </p> <p><b>BACK</b> <b>LIST</b> <b>CHAR</b> </p>

Enter file name, then press <b>ENT</b> key.	<b>F2</b>	
Press <b>F1</b> ( ROAD DESIGN )key.	<b>F1</b>	
Press <b>F1</b> ( DESIGN H-LINE )key for the H-line menu.	<b>F1</b>	
Input starting chainage, northing coordinate, easting coordinate and starting azimuth. Press <b>ENT</b> key to show the main input routine screen.	Input starting data <b>ENT</b>	

In main input routine screen we can add straight line, circular curve and transition curve to the end of current curve. Select the desired option by pressing F1-F3 keys.

### Straight line

When the start point or other line style is well defined it allows you to easily define a straight line. A straight line length value cannot be negative.




Operation procedure	Operation	Display
Press F1(Line)key from H-LINE menu to get BEELINE.	<b>F1</b>	
After entering the length of the line press ENT key.	<b>ENT</b>	
Return to H-LINE menu.		

## Circular Curve

Press **F2** key (ARC) in the “H-LINE Screen”, the circular curve can be defined. Circular curves consists of Arc length and the Radius. The radius value rule: Looking along the forward direction of the curve, when the curve rotates to right, the radius value is positive. When the curve rotates to left, the radius value is negative. The arc length cannot be

negative.




circular arcs

Operation procedure	Operation	Display
Press F2(ARC) key from H-LINE menu to get ARC.	F2	<div>ARC <span>🔋</span> <span>📶</span></div> <div>R : 0.0000 m</div> <div>L : 0.000 m</div> <div>BACK <span> </span> <span> </span> <span> </span></div>
Input the radius of the ARC (R) and press the ENT key. Input the length of the ARC (L) and press the ENT key.	Input R ENT INPUT L ENT	<div>ARC <span>🔋</span> <span>📶</span></div> <div>R : 600.000 m</div> <div>L : 123.655 m</div> <div>BACK <span> </span> <span> </span> <span> </span></div>
Return to H-LINE menu with calculated values.		<div>H-LINE 3 <span>🔋</span> <span>📶</span></div> <div>PEG : 230.000 m</div> <div>AZIH : 13.2340 m</div> <div>Ne : 99.369 m</div> <div>Ee : 632.236 m</div> <div>LINE ARC SPIR P1↓</div>

Transition curve

Press **F3** key in the “Main Line Input Screen” and a transition curve can be defined. The inputting of transition curve consists of transition curve parameter “A” , starting radius, and resending radius. If the input radius is  $\infty$  you can input 0 as its value.

input, parameter: radius R1, radius R2, parameter of a curve(A)






The rule of transition curve parameter A : Looking along the forward direction of the curve.

When the curve rotates to right, the radius value is positive. When the curve rotates to left, the radius value is negative.

Operation procedure	Operation	Display
Press F3 key from H-Line menu on page 1		
Input A , press ENT key. Input radius , press ENT key.	Enter A  Enter R 	
Instrument returns to previous mode with solution.		




## Stake Spacing ( INTG )

Press F1 (INTG) on the second page of the main alignment screen then enter into the setting interface of stake spacing interval which needs to be greater than 0.

Operation procedure	Operation	Display
Press <b>F4</b> on the main alignment screen (1/2) to enter into the main alignment screen (2/2)	<b>F4</b>	
Press <b>F1</b> to enter into the input interface of stakes space	Enter space <b>ENT</b>	
Return to the main alignment screen.		
Remarks: the stake spacing can be input only once but can be modified during editing of the horizontal alignment.		


## Road Widening Stake Number ( WIDE )

On the second page of the main alignment screen, press F2 (WIDE) to enter into the road widening stake data input interface, and then input the stake number of widening point, left road width and right road width.



Operation procedure	Operation	Display
Press <b>F4</b> on the main alignment screen (1/2) to enter into the P2 alignment screen (2/2).	<b>F4</b>	
Press <b>F2</b> (WIDE) to enter into the input interface of road widening stake number.	<b>F2</b>	
Input the stake number, left road width and right road width, and press ENT to confirm.	Enter data <b>ENT</b>	
Remarks: The data of each road widening point will determine the road width between this stake number and next widening point stake number.		

### Additional stake number ( PEG )

On the second page of the main alignment screen, press F3 (PEG) to enter into the input interface of addition stake data, and then input the stake number of the additional staking point, left road width and right road width.


Operation procedure	Operation	Display
Press <b>F4</b> on the main alignment screen (1/2) to enter into the main alignment screen (2/2).	<b>F4</b>	



Press <b>F3</b> (PEG) to enter into the input interface of additional stake number.	<b>F3</b>	
Input the stake number, left road width and right road width, and press <b>ENT</b> to confirm.	Enter data <b>ENT</b>	
Remarks: Two or more additional stake points can be input.		

## 7.6.2 Editing Horizontal Alignment Data

You can edit the horizontal alignment after input.



From the Road Design Menu select F2: EDIT H-LINE

The function of the soft keys are as follows :

[FST] : Press this key to go to the start of the file , and show the first alignment data ;

[LST] : Press this key to go to the end of the file , and show the last alignment data ;

[EDIT] : To edit the current alignment data ;

[SRCH] : Search the alignment data by inputting chainage;

It is possible to edit data by using the above function keys. After entering the data to be

modified press [ENT] key to record the modified data.

Operation procedure	Operation	Display
Press <b>F2</b> (Edit horizontal alignment) on the road design menu to enter into the horizontal alignment editing interface.	<b>F2</b>	<div><div>ARC<div><div></div><div></div></div><div>R : 600.000 m</div><div>L : 123.6550 m</div><div><div>EDIT</div><div>FST</div><div>LST</div><div>SRCH</div></div></div></div>
Through pressing [ <b>▲</b> ] or [ <b>▼</b> ], select the alignment data which is required to be modified, and press F1 (edit) to edit it, and finally press <b>ENT</b> (ENTER) to confirm. *1 )	[ <b>▲</b> ]or[ <b>▼</b> ] <b>F1</b> Enter data <b>ENT</b>	<div><div>ARC<div><div></div><div></div></div><div>R : 600.000 m</div><div>L : 123.655 m</div><div><div>BACK</div><div></div><div></div><div></div></div></div><div><div>ARC<div><div></div><div></div></div><div>R : 500.0000 m</div><div>L : 127.000 m</div><div><div>BACK</div><div>FST</div><div>LST</div><div>SRTH</div></div></div></div></div>
Return to the alignment interface, the modified alignment data will be displayed, and then continue to modify the other alignment data as needed		<div><div>ARC<div><div></div><div></div></div><div>R : 500.0000 m</div><div>L : 127.000 m</div><div><div>EDIT</div><div>FST</div><div>LST</div><div>SRCH</div></div></div></div>
*1 Or press <b>F4</b> (search), then input the stake number of the alignment data (chainage) which is required to be modified.		

7.6.3 Receiving Horizontal Alignment

You upload a prepared file of horizontal alignment data from a computer for the

alignment work before setting out.

There are two methods to upload data to the instrument.

1. Directly upload the alignment data to the current operating internal memory from a computer through a data cable (RS-232).

Refer to 10.8 for the operation method

2. Store the alignment data on an SD card, insert the SD card into the instrument and then copy data from SD card to the memory.

Refer to 10.9 for the operation procedures.

The horizontal alignment data format is in the following format:

Number	Data Format	Meaning of Parameters
1	start Z,X,Y,a	Initial Point: Stake number of initial point Z, coordinate X, coordinate Y, initial azimuth a
2	Line Lz	Straight line data: the length of straight line Lz
3	spiral A,Rs,Re	Transition curve data: transition curve parameter A, radius of initial point Rs, radius of end point Re.
4	arc R,Ly	Circular curve data: radius of circular curve R, curve length Ly.
5	wide Zi,wLi,wRi	Widening point data: initiation stake number Zi, width of left road wLi, width of right road wRi.
6	integer L0	Stake Space: the length of stake space is L0
7	peg Zj,wLj,wRj	Additional stake point data: additional stake number Zj, left road width wLj, right road width wRj

Explanation:

1. The data in the first row is the initial point data, and only one point can be entered.
2. The data in the second, third, fourth rows is element data, any combination can be input

according to the requirements.

3. The data in the fifth, sixth, and seventh rows is auxiliary calculation data, choosing whether to enter or not according to the requirements as an option, the default step length is 20m. Only one staking space is available.

4. The transition curve parameter A and circular curve radius R as needed (sign as per the direction of route, curve to left is negative, and curve to right is positive), all other parameters are positive.

5. When the radius of circular curve is  $\infty$ , the input radius is 0.

Convert the designed alignment data into \*.HAL file using transmission software, then copy the data to SD card or the memory.

**For example :**

start 0,2541930.604,502841.293,191.5644

line 452.484

arc 1200,165.885

spiral -90,1e20,130

arc -130,214.928

spiral 110,1e20,280

arc 280,77.151

spiral 110,280,1e20

line 100.978

integer 20

wide 0,0,6.5

wide 130.945,1.8,6.5

wide 400,4.5,4.5

wide 1040,0,6.5

peg 130.945,1.8,6.5

peg 220,1.8,0

peg 240,2.338,0

peg 260,2.878,0





peg 1000,4.5,5.28

peg 1020,4.5,6.038

peg 1033.721,4.5,6.48


#### 7.6.4 Deleting Horizontal Alignment Data

The horizontal alignment data in the internal memory can be deleted with the procedure as follows:

Operation procedure	Operation	Display
Press <b>F2</b> (road measurement) in the menu of Measurement Program and choose a file.	<b>F2</b> Select a file <b>ENT</b>	<div>ROAD MEASURE  </div> <div>F1 : ROAD DESIGN F2 : ROAD LAYOUT F3 : DEL H-LINE DATA F4 : DEL V-LINE DATA</div>
Press <b>F3</b> (DEL H-LINE DATA)	<b>F3</b>	<div> </div> <div>DEL H-LINE DATA</div> <div>DET? [NO] [YES]</div>
Press <b>F4</b> (Yes), the current selected horizontal alignment data will be deleted.		


















## 7.6.5 Design: Vertical Curve

A vertical curve consists of series of intersection points. The intersection point consists of a chainage, elevation and curve length. The start and end intersection points must be a zero curve length.






Intersection points can be entered in any order. After entering a point data press **ENT** to save it and advance to enter the next point. Press **ESC** to exit without saving.

Operation procedure	Operation	Display
Press <b>F2</b> key from the menu to get MEAS PROGRAM. Press <b>]</b> for page 2/2	<b>F2</b>	
Press <b>F2</b> ( ROAD MEASURE ) key	<b>F2</b>	
Input file name, then press <b>ENT</b> key	<b>ENT</b>	

Press <b>F1</b> ( ROAD DESIGN )key	<b>F1</b>	<div>ROAD DESIGN  </div> <div>F1 : DESIGN H-LINE</div> <div>F2 : EDIT H-LINE</div> <div>F3 : DESIGN V-LINE</div> <div>F4 : EDIT V-LINE</div>
Press <b>F3</b> ( DESIGN V-LINE )key	<b>F3</b>	<div>INPUT V-LINE  </div> <div>PEG : 0.000 m</div> <div>H : 0.000 m</div> <div>L : 0.000 m</div> <div>BACK   </div>
Input the PEG, H and L of the first point,then press <b>ENT</b> key *1	Enter data <b>ENT</b>	<div>INPUT V-LINE  </div> <div>PEG : 100.000 m</div> <div>H : 50.000 m</div> <div>L : 0.000 m</div> <div>BACK   </div>
After inputting each point the menu will advance to the next point. ESC to exit.		<div>INPUT V-LINE  </div> <div>PEG : 0.000 m</div> <div>H : 0.000 m</div> <div>L : 0.000 m</div> <div>BACK   </div>
*1 The start and end intersection points must be a zero curve length.		

## 7.6.6 Editing Vertical Alignment Data

The following procedures are used to edit the data.

Operation procedure	Operation	Display
Press <b>F4</b> (edit vertical alignment data) in the menu of road design, the last entered point will be shown.	<b>F4</b>	
Press <b>[▲]</b> or <b>[▼]</b> to select the alignment data to be modified. Press <b>F1</b> (edit) to edit, and press <b>ENT</b> (ENTER). *1	<b>[▲]or[▼]</b>  <b>F1</b>  Enter data  <b>ENT</b>	
The modified alignment data will be displayed. Continue to select data to modify by using the <b>[▲]</b> or <b>[▼]</b> keys. ESC to end.		
*1Or press <b>F4</b> (search), then input the stake number of the alignment data (chainage) which is required to be modified.		



## 7.6.7 Receiving Vertical Alignment Data

The vertical curve data can be prepared in the office and uploaded to the instrument to increase efficiency.

There are two methods to upload data to the instrument.

1. Directly upload the alignment data to the current operating internal memory from a computer through a data cable (RS-232).

Refer to 10.8 for the operation method

2. Store the alignment data on an SD card, insert the SD card into the instrument and then copy the data to memory.

Refer to 10.9 for the operation procedures.

The vertical alignment data format is as follows:

Stake number, elevation, length

Note: The length of the initial point and end point must be 0.

For example :

1015.600 , 30.000 , 0.000

1325.000 , 60.000 , 200.000

1632.000 , 27.000 , 315.000

1900.000 , 33.000 , 0.000



Convert the designed alignment data into \*.VCL file using transmission software.

Then copy the data to SD card or the memory.

Note: keep the text file and work file names consistent.

## 7.6.8 Deleting Vertical Alignment Data



The vertical alignment data in the internal memory can be deleted as follows:

Operation procedure	Operation	Display
On measurement procedure menu, press <b>F2</b> (road measurement) and choose a file.	<b>F2</b> Select a file <b>ENT</b>	
Press <b>F4</b> (DEL V-LINE DATA)	<b>F4</b>	
Press <b>F4</b> (YES), the selected vertical alignment data will be deleted.		

## 7.6.9 Generating a Road Coordinate File


After finishing the operation of vertical and horizontal alignment you can output a coordinate file \*.PTS to memory.

The operation procedure is as follows:

Operation procedure	Operation	Display
In the ROAD DESIGN menu press [▼] for menu P2.	[▼]	<div> ROAD DESIGN  </div> <div> F1 : CAL AND SAVE CO-ORDINATE TO FILE </div>
Press [F1] (CAL AND SAVE COORDINATE TO FILE), the coordinate file *.PTS will be created.	[F1]	<div>  </div> <div> &lt; CONVERT.... &gt; </div>

#### 7.6.10 Road Setting Out Procedures

For the road setting out program the line of the road must be defined. Horizontal and vertical alignment can be done according to the procedures in the previous sections. If vertical data is not required it can be ignored.







Before setting out the occupied point and backsight should be set. Locations can be determined by the methods described in sections ( 9.2.3 ) and ( 9.2.4 ) or by inputting stake numbers after defining the horizontal alignment data.

Before setting out, press F4 (select file) on the road setting-out interface to select required coordinate file so as to call the observation station point and backsight point.





### Set observation station point

Before setting out, press F4 (select file) on the road setting-out interface to select required coordinate file so as to call the observation station point and backsight point.

Operation procedure	Operation	Display
Press <b>F2</b> (ROAD MEASURE) in the menu of Measurement Program (2/2). Choose a data file.	<b>F2</b> Select a file <b>ENT</b>	 <p>ROAD MEASURE</p> <p>F1 : ROAD DESIGN</p> <p>F2 : ROAD LAYOUT</p> <p>F3 : DEL H-LINE DATA</p> <p>F4 : DEL V-LINE DATA</p>
Press <b>F2</b> (ROAD LAYOUT) to enter into the road setting out interface.	<b>F2</b>	 <p>ROAD LAYOUT</p> <p>F1 : SET OCC.PT#</p> <p>F2 : SET BACKSIGHT</p> <p>F3 : LAYOUT</p> <p>F4 : SELECT A FILE</p>
Press F1 key (SET OCC. PT#)	<b>F1</b>	 <p>SET OCC. PT#</p> <p>PEG : 0.000</p> <p>OF : 0.000 m</p> <p>I,HT : 0.000 m</p> <p>BACK PH#</p>
Input the stake number, offset, and instrument height to set the observation station point. (*1,*2) . Press ENT to confirm,	Enter data <b>ENT</b>	 <p>COLLIMATE VALUE</p> <p>N : 365.332 m</p> <p>E : 15.300 m</p> <p>Z : 1.230 m</p> <p>SET</p>

the instrument will calculate the coordinate of this point automatically.		
Press F4 (setting) to finish the setting of the observation station point and then return to the interface of road setting out menu.	F4	
<p>*1 ) The input stake number must be on the defined horizontal alignment; otherwise the instrument will display “Invalid Stake Number”.</p> <p>*2 ) Pressing F3 (PT#), you can set the station point from an existing point or by manually entering coordinate values (9.2.3).</p>		

### Set backsight point

Operation procedure	Operation	Display
Press F2 (ROAD LAYOUT) in menu 2/2 of ROAD MEASURE.	F2 Select a file ENT	<div>           ROAD MEASURE   </div> <div>           F1 : ROAD DESIGN            F2 : ROAD LAYOUT            F3 : DEL H-LINE DATA            F4 : DEL V-LINE DATA         </div>
Press F2 (ROAD LAYOUT) key	F2	<div>           ROAD LAYOUT   </div> <div>           F1 : SET OCC;PT#            F2 : SET BACKSIGHT            F3 : LAYOUT            F4 : SELECT A FILE         </div>

Press the F2 ( SET BACKSIGHT ) key	<div>F2</div>	<div> <div>SET BACKSIGHT</div> <div> <div>PEG : 0.000</div> <div>OF : 0.000 m</div> </div> <div> <div>BACK</div> <div>PT#</div> </div> </div>
Input the stake number and deviation (offset) to set the backsight point. (*1,*2,*3 ) . Press ENT to confirm and the instrument will calculate the coordinate of this point automatically.	<div>Enter data</div> <div>ENT</div>	<div> <div>CACULATE VALUE</div> <div> <div>N : 27.230 m</div> <div>E : 19.600 m</div> <div>Z : 3.010 m</div> </div> <div>OK? [NO]</div> </div>
Press <div>F4</div> (setting) to finish the setting of the backsight point and the instrument will calculate the backsight azimuth angle automatically.	<div>F4</div>	<div> <div>COLLMATE BS</div> <div> <div>HB : 48° 37' 13"</div> <div>&gt;COLLMATE? [NO] [YES]</div> </div> </div>
Sighting the backsight point, press <div>F4</div> (YES) to finish the backsight point setting, and then the instrument will configure horizontal circle automatically according to azimuth angle.	<div>F4</div>	<div> <div>ROAD LAYOUT</div> <div> <div>F1 : SET OCC:PT#</div> <div>F2 : SET BACKSIGHT</div> <div>F3 : LAYOUT</div> <div>F4 : SELECT A FILE</div> </div> </div>
<p>*1 ) The input stake number must be on the defined horizontal alignment; otherwise, it will display “Invalid Stake Number”.</p> <p>*2 ) Pressing F3 (PT#), you can set the station point from an existing point or by</p>		

manually entering coordinate values (9.2.3).

\*3 ) The deviation is defined as the distance from offset point to center line.







## Road setting out






Note :

Offset left: the horizontal distance from the left stake point to the center line.

Offset right: the horizontal distance from the right stake point to the center line.

Operation procedure is as follows :

Operation procedure	Operation	Display
Press <b>F2</b> (ROAD MEASURE) in menu 2/2 of the Measurement Program and choose a file.	<b>F2</b> Select a file <b>ENT</b>	<div>ROAD MEASURE  </div> <div>F1 : ROAD DESIGN</div> <div>F2 : ROAD LAYOUT</div> <div>F3 : DEL H-LINE DATA</div> <div>F4 : DEL V-LINE DATA</div>
Press <b>F2</b> (ROAD LAYOUT) to enter into the road setting out interface	<b>F4</b>	<div>ROAD LAYOUT  </div> <div>F1 : SET OCC.PT#</div> <div>F2 : SET BACKSIGHT</div> <div>F3 : LAYOUT</div> <div>F4 : SELECT A FILE</div>
Press <b>F3</b> key (LAYOUT) *1	<b>F3</b>	<div>LAYOUT MODE  </div> <div>F1 : USE FILE DATA</div> <div>F2 : INPUT PEG</div>

Press <b>F2</b> key (INPUT PEG)	<b>F2</b>	
Input the chainage of the initial stake and the incremental distance of additional stakes, press <b>ENT</b> (ENTER) to confirm. *2	Enter data <b>ENT</b>	
Input the offsets *3 and press <b>ENT</b> (ENTER) to confirm.	Enter data <b>ENT</b>	
Press <b>F4</b> (P↓) to confirm data of the setting out point. (*4,*5,*6).	<b>F4</b>	
After inputting the data of finished stake number press <b>F3</b> (LAYOUT) on the first page of software function menu, then the instrument will calculate the	<b>F3</b>	





is positive.

\*4 ) On the second page, press **F2** (Left) **F3** (Right) to switch over among left stake, center line stake and right stake.

\*5 ) On the second page, press **F2** (Increase), **F3** (Decrease) to switch over between different stake numbers.






\*6 ) By pressing [**▲**]or[**▼**], you can input the deviation, height difference, and elevation of the same stake number manually.

\*7 ) Press **F1** (Record) to keep the coordinate of setting-out point.


### 7.6.11 Slope Setting-out

Slope setting-out can be performed as part of the Alignment setout option. After defining the vertical curve and horizontal alignment in the “Define Roads Menu” it is possible to perform slope setting-out. Press the **F2** (SLOPE) key, Slope Setout will be displayed.

Main screen of SLOPE LAYOUT :






SLOPE LAYOUT		 
LDIG :	<b>0.000</b>	m
LFIL :	0.000	m
RDIG :	0.000	m
RFIL :	0.000	m
<b>BACK</b>		 

The input cut and fill value ratio is depicted below:



The left and right slopes may be entered for both cut and fill. Enter the required slopes using positive numbers for both cut and fill. The software selects the appropriate slope from the table depending on whether the situation is on the left or right and in cut or fill.

Cutting or filling is determined by the estimated level at the offset of the hinge point. If the level is above the level of the hinge then the cut slope is used, otherwise the fill slope is used.

Operation procedure	Operation	Display
Press <b>F2</b> (SLOP)key from LAYOUT menu	<b>F2</b>	
Input LDIG, LFIL, RDIG, or RFIL and press the ENT key.*1,*2	Enter data <b>ENT</b>	 
Turn the instrument and measure. When the data displayed in [→] and [↑] is 0, the setting out point is correct.	<b>F1</b>	
To return to the previous mode press the <b>ESC</b> key	<b>ESC</b>	

Note \*1 ) An intersection can not be computed if the ground surface passes through the hinge point.

\*2 ) The cut is not displayed because the cut at the computed point is zero.

## 7.7 Stake Out


Please refer to Chapter 9 (LAYOUT) for specific operation procedures.

## 7.8 Resection

Resection will determine an unknown instrument position using a maximum of 7 known coordinates and measurement data.

Specific operation procedures are in section 9.4.2 ( Resection )

## 8. DATA COLLECTION



The total station stores measured data in internal memory or SD card.

The internal memory is shared by the measured data and the coordinate data files.

### **Measured data:**

The collected data is organized into files and you can save measured original data and coordinate data together.

- 1 ) When turning the instrument off always have the instrument display on the main menu or angle measurement screen. This ensures completion of the memory access process and avoids possible damage to the stored data.
- 2 ) It is recommended to use fully charged batteries to facilitate data collection whenever possible.

## **8.1 Operation Procedure**

1. Select a Data Collection File to save data to.

\* You should first go to menu 2/2 of the COLLECT DATA menu, select F2 (CONFIG) and select “YES” or “NO” in “AUTO SAVE COORD.”

2. Select a Coordinate Data file .

3. Set occupied Point including Instrument Height, Point Number and Coordinate.

4. Set Backsight Point, Direction and Azimuth.












5. Set PT#, PCODE and R.HT ,start collecting and saving data.




# 8.2 Preparation

## 8.2.1 Selecting a File for Data Collection







The file used by data collection mode must be selected first.



And a selection from data collection menu is possible in the mode.

Operation procedure	Operation	Display
①Press the <b>M</b> key	<b>M</b>	<div><div>MENU (1/2)  </div><div>F1 : COLLECT DATA</div><div>F2 : PROGRAMS</div><div>F3 : MEMORY MGR</div><div>F4 : CONFIG</div><div>↓</div></div>
② Press <b>F1</b> (COLLECT DATA) key	<b>F1</b>	<div><div>SELECT A FILE  </div><div>FN: DATA 01</div><div>BACK LIST NUME </div></div>
③Press <b>F2</b> (LIST) key to display the list of files *1	<b>F2</b>	<div><div>FILE LIST  </div><div>→ * DATA 01 .RAW 15 k</div><div>DATA 02 .RAW 20 k</div><div>DATA 03 .RAW 10 k</div><div>SRCH  FPAG NPAG</div></div>
④ Scroll the file list by pressing <b>[▲]</b> or <b>[▼]</b> key, and select a file. (*2,*3)	<b>[▲]</b> or <b>[▼]</b>	<div><div>FILE LIST  </div><div>DATA 01 .RAW 15 k</div><div>→ * DATA 02 .RAW 20 k</div><div>DATA 03 .RAW 10 k</div><div>SRCH  FPAG NPAG</div></div>

Press the (ENT) key. The file will be set and the COLLECT DATA 1/2 menu will be shown.		
<p>*1 ) If you want to make a new file or input a file name directly enter a file name and press ENT.</p> <p>*2 ) When a file has been already selected, a “*” mark is indicated on left of the current file name</p> <p>*3 ) To search for data use the [▲] or [▼] keys to select a file and press the  (SRCH) key.</p>		

### 8.2.2 Selecting a Coordinate File for Data Collection

Operation procedure	Operation	Display
① Press the  (SELECT A FILE) key from the COLLECT DATA menu 1/2.		
② Press the  (COORD DATA) key		

③Press the <b>F2</b> ( LIST ) key	<b>F2</b>	
④Pressing [ <b>▲</b> ]or [ <b>▼</b> ] key to select a file press <b>ENT</b> to return to COLLECT DATA menu 1/2.	<b>ENT</b>	

### 8.2.3 Occupied Point and Backsight Point

The occupied point coordinates and the direction angle in the data collect mode are linked with the occupied point. It is possible to set or change the occupied point and direction angle from the data collect mode.

Occupied points can be set by two methods:

- 1) Setting from a known point stored in the internal memory
- 2) Direct key input

The following three setting methods for backsight point can be selected:



- 1 ) Setting from a known point stored in the internal memory
- 2 ) Direct key input of coordinate data
- 3 ) Direct key input of setting angle

\*\* The setting of the direction angle can be confirmed by measurement.









Example of establishing the occupied point from known data:

Operation procedure	Operation	Display
①Press the <b>F1</b> (INPUT OCC.PT # ) key from the COLLECT DATA menu 1/2. The previous data is shown.	<b>F1</b>	
②Press the <b>F3</b> (OCC) key	<b>F3</b>	
③Enter PT #, press <b>ENT</b> key	<b>ENT</b>	
④Press <b>F4</b> (YES) key to set	<b>F4</b>	
⑤Enter PCODE and INS.HT	Enter PCODE  Enter INS.HT	

⑥press <b>F4</b> (SAVE)key	<b>F4</b>	
⑦Press <b>F4</b> (YES) key, the display returns to the COLLECT DATA menu 1/2	<b>F4</b>	
<p>The data recorded is PT#, PCODE and INS.HT</p> <p>If a point is not found in internal memory “PT # DOES NOT EXIST” is displayed.</p>		











Example for setting the direction angle : (\*The setting of the direction angle must be confirmed by measement.)









The following is to memorize the data of the backsight after setting the backsight point from point number








Operation procedure	Operation	Display
① Press the <b>F2</b> (INPUT BACKSIGHT) key from the data collect menu 1/2. The previous data is shown.	<b>F2</b>	
② Press the <b>F3</b> (BS) key	<b>F3</b>	
③ Enter backsight point name *1, press <b>ENT</b> key	<b>ENT</b>	
④ Press the <b>F4</b> (YES) key, collimate the instrument and press F4 (YES), INPUT BS will be displayed.	<b>F4</b>	
⑤ Enter PCODE, R.HT as above. *2	Enter PT # <b>F4</b>	
Press the <b>F4</b> (MEAS) key	<b>F4</b>	

<p>Collimate back sight point.</p> <p>Select one of the measuring modes and press the soft key.</p> <p>Example :</p> <p><b>F2</b> (SD) key - measuring starts. The horizontal circle is set to calculate direction angle. The measuring result is memorized and the display returns to the COLLECT DATA menu 1/2.</p>	<p>Collimate</p> <p><b>F2</b></p>	<div data-bbox="636 129 981 320"> <div> PSM -30 PPM 0.0 </div> <div> V : 95° 30' 55" </div> <div> HR : 65° 45' 30" </div> <div> SD * [N] m </div> <div> MEAS </div> </div> <div data-bbox="636 341 981 533"> <div>AUTO SAVE NEZ</div> <div>PT# DATA 10</div> <div>&gt;REWRITE? [NO] [YES]</div> </div> <div data-bbox="636 549 981 740"> <div>COLLECT DATA</div> <div>F1 : INPUT OCC:PT#</div> <div>F2 : INPUT BACKSIGHT</div> <div>F3 : MEASURE</div> <div>F4 : SELECT A FILE</div> <div>↓</div> </div>
<p>*1 ) Refer to Chapter 1.10 “How to Enter Alphanumeric characters”.</p> <p>*2 )PCODE can be input by inputting a register number linked with the PCODE library.</p> <p>To show the list in the PCODE library press the <b>F2</b> (SRCH) key.</p> <p>If the point is not found in internal memory "PT # DOES NOT EXIST" is displayed.</p>		

8.2.4 Measuring and Storing the Data



Operation procedure	Operation	Display
①Press the <b>F3</b> (MEAS) key from the COLLECT DATA menu 1/2 to measure an unknown point.	<b>F3</b>	<div>COLLECT DATA (1/2)  </div> <div>F1: INPUT OCC.PT# F2: INPUT BACKSIGHT F3: MEASURE F4: SELECT A FILE</div> <div>▼</div> <div>INPUT OCC. PT#  </div> <div>PT# → : PCODE : R.HT : 0.000 m</div> <div><b>INPT</b> <b>SRCH</b> <b>MEAS</b> <b>ALL</b></div>
②Press the <b>F1</b> (INPUT) key and enter the PT # *1 Press the <b>ENT</b> key	<b>F1</b> Enter PT # <b>ENT</b>	<div>INPUT PH#  </div> <div>PT# → <b>DATA 1</b> PCODE : R.HT : 0.000 m</div> <div><b>BACK</b> <b>RETN</b> <b>NUMB</b> </div>
③Enter PCODE, R.HT as above *2	<b>F1</b> Enter PCODE <b>F4</b> <b>F1</b> Enter PCODE <b>F4</b>	<div>INPUT PT#  </div> <div>PT# : DATA 16 PCODE : R.HT →: 1.210 m</div> <div><b>BACK</b> <b>RETN</b> <b>NUMB</b> </div>

④Press the <b>F3</b> (MEAS) key	<b>F3</b>	<div> <div> INPUT PT#   </div> <div> PT# → : DATA 16  PCODE :  R.HT : 1.210 m </div> <div> <div>ANG</div> <div>SD</div> <div>NEZ</div> <div>OFST</div> </div> </div>
⑤Collimate the target point	Collimate	
⑥Press the desired key <b>F1</b> to <b>F3</b> to measure.  Example: <b>F2</b> (SD) key and measuring starts. *3 Press F4 (SAVE) to store.	<b>F2</b>	<div> <div> <div> PSM -30 PPM 0.0   </div> <div> V : 95° 30' 55"  HR : 65° 45' 30"  SD * 122.568 m </div> <div> <div>MEAS</div> <div></div> <div>STOP</div> <div>SAVE</div> </div> </div> <div> <div> INPUT PT#   </div> <div> PT# → : DATA 17  PCODE :  R.HT : 1.210 m </div> <div> <div>INPT</div> <div>SRCH</div> <div>MEAS</div> <div>REP</div> </div> </div> </div>
⑦Enter the next point data and collimate the instrument.		<div> <div> INPUT PT#   </div> <div> PT# → : DATA 17  PCODE : PICD  R.HT : 1.302 m </div> <div> <div>INPT</div> <div>SRCH</div> <div>MEAS</div> <div>REP</div> </div> </div>

<p>⑧ Press <b>F4</b> (REP) key</p> <p>Measuring starts in the same measuring mode of the previous point.</p> <p>Data is recorded</p> <p>Continue the measuring in the same way. Press <b>ESC</b> to finish COLLECT DATA mode.</p>	<p>Collimate</p> <p><b>F4</b></p>	<div data-bbox="636 129 983 320"> <p>FSM ~30 PPM 0.0  </p> <p>V : 95° 30' 55"</p> <p>HR : 65° 45' 30"</p> <p>SD * [N] m</p> <p>MEAS   </p> </div> <div data-bbox="636 341 983 533"> <p>INPUT PT#  </p> <p>PT# → : DATA 18</p> <p>PCODE : PICD</p> <p>R.HT : 1.302 m</p> <p>INPT SRCH MEAS REP</p> </div>
<p>*1 ) Refer to Chapter 1.10 “How to Enter Alphanumeric characters”.</p> <p>*2 ) PCODE can be input by inputting a register number linked with PCODE library To show the list in the PCODE library, press the <b>F2</b> (SRCH) key.</p> <p>*3 ) The measurement data will be automatically saved to internal memory when measure mode ONE FINE is selected.</p>		

## Searching the recorded data

While executing the COLLECT DATA mode you can search the recorded data.

Operation procedure	Operation	Display
<p>① While executing the COLLECT DATA mode, press <b>F2</b> (SRCH) key.*1</p> <p>The file name in use will appear on the top of the right side of the display.</p>	<p><b>F2</b></p>	<div data-bbox="642 1082 972 1257"> <p>INPUT OCC. PT#  </p> <p>PT# →</p> <p>PCODE :</p> <p>R.HT : 0.000 m</p> <p>INPT SRCH MEAS ALL</p> </div>

② Select one of three search methods by pressing <b>F1</b> to <b>F3</b> key *2	<b>F1</b> — <b>F3</b>	<div> SEARCH DATA <div> <div></div> <div></div> </div> <div> FN:FN 01  F1:FIRST DATA  F2:LAST DATA  F3:INPUT PT# </div> <div>▼</div> </div>
<p>*1 ) It is possible to see the PCODE list when the arrow is located beside PCODE or ID.</p> <p>*2 ) The operation is same as the “SEARCH” in the MEMORY MANAGEMENT MODE For more information, refer to Section 10.3 “Searching Data”.</p>		

### Entering PCODE directly




While executing the Data Collect mode, you can enter PCODE/ID from PCODE Library.

Operation procedure	Operation	Display
① Move the arrow to PCODE in the COLLECT DATA mode, press the <b>F1</b> (INPUT) key	<b>F1</b> Enter PCODE <b>ENT</b>	<div> INPUT PT# <div> <div></div> <div></div> </div> <div> PT  PCODE → PICD  R.HT : 1.302 m </div> <div> INPT LIST MEAS ALL </div> </div> <div> INPUT PT# <div> <div></div> <div></div> </div> <div> PT# : DATA 17  PCODE → <div></div>  R.HT : 1.210 m </div> <div> BACK RETN CHAR <div></div> </div> </div>



**Entering PCODE from the list of PCODE's**

You also can enter PCODE from the list of PCODE's.

Operation procedure	Operation	Display
① Move the arrow to the PCODE in the COLLECT DATA mode, press the <b>F2</b> (SRCH) key.	<b>F2</b>	<div>INPUT PT# </div> <div>PT# : DATA 20</div> <div>PCODE →</div> <div>R.HT : 1.302 m</div> <div><b>INPT</b> <b>LIST</b> <b>MEAS</b> <b>ALL</b></div>
By pressing the following keys, the register number will increase or decrease. [▲] or [▼]: Increasing or Decreasing one by one.	[▲]or[▼]	<div>LIST PCODE </div> <div>00:</div> <div>01: 01</div> <div>→ 02: 02</div> <div>03: 03</div> <div><b>EDIT</b> <b>FPAG</b> <b>DEL</b> <b>NPAG</b></div>
Press the <b>F4</b> (ENT) key	<b>F4</b>	<div>INPUT PT# </div> <div>PT# : DATA 20</div> <div>PCODE →</div> <div>R.HT : 1.302 m</div> <div><b>INPT</b> <b>LIST</b> <b>MEAS</b> <b>ALL</b></div>
*1 ) To edit the PCODE library, Press the <b>F1</b> (EDIT) key. To delete the selected PCODE registered press the <b>F3</b> (DEL) key, PCODE can be edited in COLLECT DATA menu 2/2 or MEMORY MANAGEMENT menu 2/3.		


**8.3 Data Collect Offset Measurement Mode**

This mode is useful when it is difficult to set up the prism directly for example at the center of a tree.

Data Collect Offset Measurement has four measuring methods:

1. Angle Offset Measurement
2. Distance Offset Measurement
3. Plane Offset Measurement
4. Column Offset Measurement





### 8.3.1 Angle Offset



Place the prism at the same horizontal distance from the instrument as that of the point to be determined (A0). To measure the coordinates of the center position (A0) use the offset measurement feature after setting the instrument height/prism height.


When measuring coordinates of ground point AI: Set the instrument height/Prism height, When measuring coordinates of point A0: Set the instrument height only (Set the prism height to 0).






Operation procedure	Operation	Display
① Press <b>F3</b> (MEAS) key from the COLLECT DATA mode.	<b>F3</b>	<div> INPUT PT# <span>📶</span> <span>🔋</span>  PT# → DATA 22  PCODE :  R.HT : 1.365 m  <b>INPT</b> <b>SRCH</b> <b>MEAS</b> <b>ALL</b> </div> <div> INPUT PT# <span>📶</span> <span>🔋</span>  PT# → DATA 22  PCODE :  R.HT : 1.365 m  <b>ANG</b> <b>TILT</b> <b>NEZ</b> <b>OFST</b> </div>
② Press <b>F4</b> (OFST) offset key.	<b>F4</b>	<div> OFFSET MEAS <span>📶</span> <span>🔋</span>  F1 : ANGLE OFFSET  F2 : DISTANCE OFFSET  F3 : PLANE OFFSET  F4 : COLUMN OFFSET </div>
③ Press <b>F1</b> (ANGLE OFFSET) key.	<b>F1</b>	<div> <b>PSM</b> ~30 <b>PPM</b> 0.0 <span>📶</span> <span>🔋</span>  COLLIMATE PRISM  HR : 65° 45' 30"  HD : m  <b>MEAS</b> <span style="background-color: black; color: black;"> </span> <span style="background-color: black; color: black;"> </span> <span style="background-color: black; color: black;"> </span> </div>
④ Collimate the prism	Collimate P	
⑤ Press <b>F1</b> (MEAS) key. Continuous measuring starts, display HR, HD, VD and SD of aim point.	<b>F1</b>	<div> COLLIMATE OBJECT <span>📶</span> <span>🔋</span>  HR : 65° 45' 30"  HD : 265.332 m  VD : 1.230 m  SD : 265.325 m  <span style="background-color: black; color: black;"> </span> <span style="background-color: black; color: black;"> </span> <span style="background-color: black; color: black;"> </span> <b>NOTE</b> </div>





























⑥Collimate Point A0 using the horizontal motion clamp and horizontal tangent screw.	Collimate A0	<div>COLLIMATE OBJECT</div> <div> <div>HR : 65° 45' 30"</div> <div>HD : 265.332 m</div> <div>VD : 1.230 m</div> <div>SD : 265.325 m</div> </div> <div>NOTE</div>
⑦To show the coordinates of A0 press the  key. Coordinates are shown.		<div>COLLIMATE OBJECT</div> <div> <div>N : 365.332 m</div> <div>E : 15.300 m</div> <div>Z : 1.230 m</div> </div> <div>NOTE</div>
⑧Press  key. The data is recorded and the next measuring point is displayed.		<div>INPUT PT#</div> <div> <div>PT# →: DATA 23</div> <div>PCODE :</div> <div>R,HT : 1.210 m</div> </div> <div>INPT SRCH MEAS REP</div>

### 3.2 Distance Offset Measurement

Obtaining coordinates of a point using a distance offset can be achieved as follows:




Operation procedure	Operation	Display
① Press <b>F3</b> (MEAS) key from the COLLECT DATA mode.	<b>F3</b>	 
② Press <b>F4</b> (OFST) key.	<b>F4</b>	
③ Press <b>F2</b> (DISTANCE OFFSET) key	<b>F2</b>	
④ Enter Right and Left direction offset value (offset left is negative) Press <b>ENT</b> key.	Enter HD <b>ENT</b>	

<p>⑤Enter Forward direction offset value. (offset towards the front is negative). Press <b>ENT</b> key.</p>	<p>Enter Forward direction offset value <b>ENT</b></p>	<div data-bbox="642 134 972 319"> <p>DISTANCE OFFSET   </p> <p>INPUTL FORWARD HD</p> <p>oHD: 0_ m</p> <p><b>BACK</b>   </p> </div>
<p>⑥ Collimate the Prism P and press <b>F1</b>, display HR, HD, VD and SD of aim point and add offset correction.</p>	<p><b>F1</b> Enter HD <b>F4</b></p>	<div data-bbox="642 408 972 593"> <p><b>PSM</b> -30 <b>PPM</b> 0.0   </p> <p>DISTANCE OFFSET</p> <p>HR : 65° 45' 30"</p> <p>HD : m</p> <p><b>MEAS</b>   </p> </div> <div data-bbox="642 612 972 798"> <p>DISTANCE OFFSET   </p> <p>HR : 65° 45' 30"</p> <p>HD : 265.332 m</p> <p>VD : 1.230 m</p> <p>SD : 265.325 m</p> <p>   <b>NOTE</b></p> </div>
<p>⑦Press the  to display A0 coordinates values, N, E and Z.</p>	<p></p>	<div data-bbox="642 826 972 1011"> <p>COLLIMATE OBJECT   </p> <p>N : 365,332 m</p> <p>E : 15,300 m</p> <p>Z : 1.230 m</p> <p>   <b>NOTE</b></p> </div>
<p>⑧Press <b>F4</b> (NOTE) key. The data is recorded and the next Measuring point is displayed.</p>	<p><b>F4</b></p>	<div data-bbox="642 1043 972 1225"> <p>INPUT PT#  </p> <p>PT# →: DATA 26</p> <p>PCODE :</p> <p>R,HT : 1,262 m</p> <p><b>INPT</b> <b>SRCH</b> <b>MEAS</b> <b>ALL</b></p> </div>

















### 8.3.3 Plane Offset Measurement

By measuring three known points on a plane other points on that plane can be calculated and determined.















Three random prism points (P1, P2, P3) on a plane need to be measured first. To determine an unknown point collimate the measuring target point (P0), the instrument calculates and displays coordinate and distance value of the cross point between the collimation axis and the plane.



When setting the coordinate value for the occupied station, refer to Section 6.2 “Setting Coordinate Values of Occupied Point”

Operation procedure	Operation	Display
①Press <b>F3</b> (MEAS) key from COLLECT DATA mode.	<b>F3</b>	<div> <p>INPUT PT#  </p> <p>PT# → : DATA 15</p> <p>PCODE :</p> <p>R,HT : 1.265 m</p> <p><b>INPT</b> <b>SRCH</b> <b>MEAS</b> <b>ALL</b></p> </div> <div> <p>INPUT PT#  </p> <p>PT# → : DATA 15</p> <p>PCODE :</p> <p>R,HT : 1.265 m</p> <p><b>ANG</b> <b>TILT</b> <b>NEZ</b> <b>OFST</b></p> </div>
②Press <b>F4</b> (OFST) key.	<b>F4</b>	<div> <p>OFFSET MEAS  </p> <p>F1 : ANGLE OFFSET</p> <p>F2 : DISTANCE OFFSET</p> <p>F3 : PLANE OFFSET</p> <p>F4 : COLUMN OFFSET</p> </div>
③Press <b>F3</b> (PLANE OFFSET) key	<b>F3</b>	<div> <p><b>PSM</b> -30 <b>PPM</b> 0.0  </p> <p>PLANE OFFSET</p> <p>NO 1 #</p> <p>HD : m</p> <p><b>MEAS</b>   </p> </div>
④ Collimate P1, press <b>F1</b> (MEAS) key.  Measuring will start.  After measuring, the display will show the second point measurement.	Collimate P1  <b>F1</b>	<div> <p><b>PSM</b> -30 <b>PPM</b> 0.0  </p> <p>PLANE OFFSET</p> <p>NO 2 #</p> <p>HD : m</p> <p><b>MEAS</b>   </p> </div>




<p>⑤ Measure the second and third points.</p> <p>The display change to PT# in the plane offset measurement screen.</p>	<p>Collimate</p> <p>P2</p> <p><b>F1</b></p> <p>Collimate</p> <p>P3</p> <p><b>F1</b></p>	<div data-bbox="641 140 969 323"> <div>PSM -30 PPM 0.0   </div> <div>PLANE OFFSET</div> <div>NO 2 #</div> <div>HD * <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> m</div> <div>MEAS <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span></div> </div> <div data-bbox="641 339 969 523"> <div>PSM -30 PPM 0.0   </div> <div>PLANE OFFSET</div> <div>NO 3 #</div> <div>HD * <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> m</div> <div>MEAS <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span></div> </div>
<p>⑥ Collimate the edge (P0) of the plane *1,*2</p> <p>Instrument displays V, HR, HD, VD and SD</p>	<p>Collimate</p> <p>P0</p>	<div data-bbox="641 558 969 742"> <div>V : 95° 30' 55"  </div> <div>HR : 65° 45' 30"</div> <div>HD : 265.332 m</div> <div>VD : 1.230 m</div> <div>SD : 265.325 m</div> <div><span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <b>NOTE</b></div> </div>
<p>⑦ Press the  key to display P0 coordinates in N, E and Z.</p>	<p></p>	<div data-bbox="641 766 969 949"> <div> </div> <div>N : 365.332 m</div> <div>E : 15.300 m</div> <div>Z : 1.230 m</div> <div><span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <span style="border-bottom: 1px solid black; display: inline-block; width: 100px;"></span> <b>NOTE</b></div> </div>
<p>⑧ Press <b>F4</b> and the data is recorded. The next offset point number will be displayed.</p>	<p><b>F4</b></p>	<div data-bbox="641 973 969 1157"> <div>INPUT PT#  </div> <div>PT# → DATA 16</div> <div>PCODE :</div> <div>R,HT : 1.265 m</div> <div>INPT <b>SRCH</b> <b>MEAS</b> <b>ALL</b></div> </div>
<p>*1) If the calculation of the plane was not successful an error will display. Begin measuring again from the first point.</p> <p>*2) An error will be displayed when an observation is taken that does not cross the observed plane.</p>		







### 8.3.4 Column Offset Measurement







If it is possible to measure the circumscription point (P1) of a column, the distance to the center of the column (P0), coordinate and direction angle can be calculated by observing circumscription points (P2) and (P3).

The direction angle of the center of the column is the average of the observed angles of circumscription points (P2) and (P3).



When setting the coordinate value for the occupied station refer to Section 6.2 “Setting Coordinate Values of Occupied Point”

Operation procedure	Operation	Display
①Press <b>F3</b> (MEAS) key from data collect mode.	<b>F3</b>	 
②Press <b>F4</b> (OFSET) key.	<b>F4</b>	
③ Press <b>F4</b> (COLUMN OFFSET) key	<b>F4</b>	
④Collimate the center of the column (P1) and press <b>F1</b> (MEAS) key.  Measuring starts.  After the measurement the instrument will display “LEFT” (P2).	<b>F1</b>	 



<p>⑤Collimate the left side of the column (P2) and press <b>F4</b> (SET) key. After the measurement the instrument will display “RIGHT” (P3).</p>	<p>Collimate P2 <b>F4</b></p>	
<p>⑥Collimate the right side of the column (P3) and press the <b>F4</b> key, the display shows P0, HR, HD, VD and SD.</p>	<p>Collimate P3 <b>F4</b></p>	
<p>⑦To show the coordinates of P0, press the  key.</p>		
<p>⑧Press <b>F4</b> and the data is recorded.</p>	<p><b>F4</b></p>	

8.4 Editing PCODE Library [PCODE INPUT]

PCODE data can be entered into the PCODE library using the following procedures. A PCODE is represented with a number between 1 to 50.



The PCODE data can be also be edited in MEMORY MANAGEMENT menu 2/3.

Operation procedure	Operation	Display
① Press the <b>F1</b> (PCODE INPUT) key from COLLECT DATA menu 2/2	<b>F1</b>	<div><div>MEAS PROGRAM</div><div>F1 : INPUT PCODE</div><div>F2 : CONFIG</div><div>▲</div></div>
② Scroll through the data point list using the <b>[▲]</b> or <b>[▼]</b> keys.	<b>[▲]</b> or <b>[▼]</b>	<div><div>INPUT OCC. PT#</div><div>00:</div><div>→ 01:</div><div>02:</div><div>03:</div><div>EDITFPAGDELNPAG</div></div> <div><div>INPUT OCC. PT#</div><div>→ 00:</div><div>01:</div><div>02:</div><div>03:</div><div>EDITFPAGDELNPAG</div></div>
③ Press the <b>F1</b> ( EDIT ) Key	<b>F1</b>	<div><div>INPUT OCC. PT#</div><div>00:</div><div>→ 01: </div><div>02:</div><div>03:</div><div>BACKFPAGCHARNPAG</div></div>

④Enter the PCODE and press the (ENT) key, the input window scrolls to the next point *1		
*1 ) Refer to Chapter 1.10 “How to Enter Alphanumeric characters”.		

8.5 Setting the Data Collection Parameters

The following parameters can be set for the data collection mode.

Menu	Selecting item	Contents
Press the  (CONFIG) key from COLLECT DATA menu 2/2		
F1: MEASURE MODE	<u>FINE</u> / TRACK	Selecting distance measurement mode: Fine / Track
F2: MEASURE SEQ	ONE TIMES / <u>REPEAT</u>	Selecting distance measurement mode: one-times / Repeat
F3: SAVE CONFIG	<u>YES</u> / NO	Auto save coordinate data
F4: DATA COLLECT SET	<u>FIRST INPUT PT</u> / FIRST MEASURE	Point input or measure sequence option

Note: Underlined parameters are default settings.

Set relevant parameters before data collection.


## 9. LAYOUT

The two functions of LAYOUT mode are staking out known points and surveying unknown points either using a sideshot or resection method. Surveying points can be retrieved from internal memory or coordinates manually entered into the instrument.. The coordinate data is loaded from a computer to the internal memory via RS-232C, USB, or SD card.

The coordinate data is stored in a COORD. DATA file.

For the internal memory refer to Chapter 10 "MEMORY MANAGEMENT MODE"

- 1 ) When turning off the power always have the instrument display on the main menu screen or main angle measurement mode screen. Failure to have the instrument in these screens could corrupt the stored data if the instrument is powered off.
- 2 ) It is recommended for safety to fully charge the batteries before operation. Always have a fully charged battery on hand for convenience.
- 3 ) When recording new data always consider the amount of internal memory available. The SD card port will provide nearly unlimited available storage.



## 9.1 Setting the Parameters of Data Collection

To use the layout procedure mode use the following steps:

1. Select the data file to record the data collected.
2. Set the occupied point.
3. Set the backsight point or azimuth angle.
4. Input layout point coordinates and follow menu prompts.

## 9.2 Preparation





### 9.2.1 Setting the GRID FACTOR

The Grid Factor can be set in the Parameter Set menu of the CONFIG options.




### 9.2.2 Selecting Coordinate Data File

You can execute a Layout from a selected coordinate data file or you can record new measured data into a selected coordinate data file.

When in LAYOUT MODE the instrument will prompt for a file name.

Operation procedure	Operation	Display
①Press [M] key.		<div><div>MENU ( 1 / 2 )  </div><div>F1 : GATHER DATA</div><div>F2 : MEAS PROGRAM</div><div>F3 : MEMORY MGR</div><div>F4 : CONFIG</div><div></div></div>



<p>② Press <b>F4</b> (CONFIG) key</p>	<p><b>F4</b></p>	 <p>CONFIG (1/2) [Signal] [Battery]</p> <p>F1 : UNIT SET  F2 : PARAMETER SET  F3 : POWER ON DISPLAY  F4 : SHORTCUT KEY SET</p> <p>↓</p>
<p>③ Press <b>F2</b> (PARAMETER SET)</p>	<p><b>F2</b></p>	 <p>MEAS. PARA (1/2) [Signal] [Battery]</p> <p>F1 : TILT SENSOR  F2 : W-CORRECTION  F3 : GRID FACTOR  F4 : LEAST ANGLE DISP</p> <p>↓</p>
<p>③ Press <b>F1</b> (ON) and continue rest set</p>	<p><b>F1</b></p>	 <p>GRID FACTOR [OFF] [Signal] [Battery]</p> <p><b>ON</b> [Blank] [Blank] [Blank]</p> <p>GRID FACTOR =1.000000 [Signal] [Battery]</p> <p><b>OFF</b> [Blank] [Blank] <b>MODY</b></p> <p>GRID FACTOR =1.000000 [Signal] [Battery]</p> <p><b>OFF</b> [Blank] [Blank] <b>MODY</b></p>

\*1 ) If you want to input file name directly, press the **F1** (INPUT)key and enter a file name.

\*2 ) A file will be highlighted by a **▶** indicated on left of the file name. Press ENT to select.



\*3 ) For the file discrimination mark (\*, &,), refer to Section 10.4 “FILE MAINTENANCE”



### 9.2.3 Setting Occupied Point

Occupied points can be set by two setting methods:




- 1) Setting from the coordinate data stored in the internal memory
- 2) Direct key input of coordinate data

Setting the occupied point from the internal coordinate data file.

Operation procedure	Operation	Display
① Press the <b>F1</b> (OCC. PT INPUT) key from the Layout menu 1/2.	<b>F1</b>	
②The point can be manually entered or retrieved by F2 LIST. Press <b>ENT</b> key to confirm.	<b>ENT</b>	

③Press the <b>F4</b> (YES) key to get to the instrument height.	<b>F4</b>	
④Enter INS.HT press ENT. The display returns to layout menu 1/2.	Enter INS.HT <b>ENT</b>	
*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”		

Example setting: Setting the instrument point coordinates directly

Operation procedure	Operation	Display
Press the <b>F1</b> (OCC. PT INPUT) key from the Layout menu 1/2. The previous data is shown.	<b>F1</b>	
Press the <b>F4</b> key	<b>F4</b>	
Enter the coordinate value and press the <b>ENT</b> key. The menu will advance to the INPUT INS HT display.	Enter coordinate <b>ENT</b>	


Enter Instrument Height, press ENT. The display returns to layout menu 1/2.	Enter INS.HT ENT	<div> LAYOUT (1/2) <div> F1 : INPUT OCC. PT#  F2 : INPUT BACKSIGHT  F3 : LAYOUT </div> </div>
*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”		

## 9.2.4 Setting Backsight Point















The following three methods for the Backsight point can be used:

- 1 ) Setting from the coordinate data file stored in the internal memory.
- 2 ) Direct key input of coordinate data.
- 3 ) Direct key input of azimuth.





Every press of the **F4** key will switch the inputting backsight orientation angle and inputting coordinate data of backsight point directly.



Example setting: Setting the backsight point from the internal coordinate data file

Operation procedure	Operation	Display
Press the <b>F2</b> (BACKSIGHT INPUT) key from the Layout menu.	<b>F2</b>	 <p>INPUT BS#  </p> <p>PT# : 02 </p> <p><b>BACK</b> <b>LIST</b> <b>CHAR</b> <b>NEZ</b></p>
Enter PT# or F2 LIST and select a point *1, press the <b>ENT</b> key.	Enter PT# <b>ENT</b>	 <p>INPUT BS#  </p> <p>N : 365.332 m</p> <p>E : 15.300 m</p> <p>Z : 1.230 m</p> <p>&gt;OK? [NO] [YES]</p>
Press the <b>F4</b> (YES) key, instrument will calculate automatically and show the backsight set display.	<b>F4</b>	 <p><b>PSM</b> -30 <b>PPM</b> 0.0   </p> <p>COLLIMATE BS</p> <p>HR : 65° 45' 30"</p> <p>&gt;COLLIMATE? [NO] [YES]</p>
Sight the backsight point and press the <b>F4</b> (YES) key. The display returns to the layout menu 1/2	Sight BS <b>F4</b>	 <p>LAYOUT (1/2)  </p> <p>F1 : INPUT OCC. PT#</p> <p>F2 : INPUT BACKSIGHT</p> <p>F3 : LAYOUT</p> <p>▼</p>

Example: Setting instrument point coordinates directly.

Operation procedure	Operation	Display
Press the <b>F2</b> (BACKSIGHT INPUT) key from the Layout menu 1/2.  The previous data is shown.	<b>F2</b>	
Press the <b>F4</b> (NEZ) key	<b>F4</b>	
Enter the coordinate value and press the <b>ENT</b> key*1	Enter coordinate <b>ENT</b>	
Sight the backsight point	Sight BS	
Press the <b>F4</b> (YES) key  The display returns to the layout menu 1/2.	<b>F4</b>	
*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”		





## 9.3 Executing a Layout





The following methods can be selected for executing a Layout:

- 1) Recall points from internal memory by point number




## 2) Direct key input of coordinate values

Example setting: Recalling a point from internal memory

Operation procedure	Operation	Display
Press the <b>F3</b> (LAYOUT) key from the layout menu 1/2.	<b>F3</b>	 
Enter the PT# and press the <b>ENT</b> key *2 to get to reflector height screen.	Enter PT# <b>ENT</b>	
Enter the reflector height and press ENT.  After inputting values the instrument will calculate the layout point position.  HR : Calculated horizontal angle of the layout point  HD : Calculated horizontal distance from the instrument to the layout point.	Enter R.HT <b>F4</b>	

<p>Press the <b>F4</b> (NEXT) key .</p> <p>HR : Measured (actual) horizontal angle</p> <p>dHR: difference in calculated angle in relation to actual observed angle.</p> <p>Collimate the instrument to dHR=0°00'00"</p>	<p>Collimate</p>	
<p>Press the <b>F2</b> (DIST) key</p> <p>HD : Measuring (actual) horizontal distance</p> <p>dH : Horizontal distance remaining to the layout point.</p> <p>dZ: Vertical distance remaining to the layout point.</p>	<p><b>F2</b></p>	
<p>Press the <b>F1</b> ( MEAS ) key.</p> <p>The fine mode measuring starts.</p>	<p><b>F1</b></p>	
<p>⑦When the display value dHR, Dhd and DZ are equal to 0 the layout point is established *3</p>		
















<p>Press the <b>F3</b> (NEZ) key.</p> <p>The measured coordinate data is shown to confirm the value of the layout point.</p>	<b>F3</b>	
<p>Press the <b>F4</b> (NEXT) key to set next layout point.</p>	<b>F4</b>	
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”</p> <p>*2 ) A point number can not be entered when data to comply with the coordinate value does not exist in the file.</p> <p>*3 ) Pressing the  or <b>ANG</b> keys can switch between the layout angle and distance.</p>		






## 9.4 Setting A New Point




New points can be established by the instrument either using a sideshot or resection method.

### 9.4.1 Side Shot Method

Set up the instrument at a known point and measure the coordinate of the new points by the side shot method.

Operation procedure	Operation	Display
Press the [▼] key from the layout menu 1/2 to get the layout menu 2/2.	<b>F4</b>	<div> LAYOUT (1/2)    F1 : INPUT OCC.PT#  F2 : INPUT BACKSIGHT  F3 : LAYOUT  ▼ </div> <div> LAYOUT (2/2)    F1 : SELECT A FILE  F2 : NEW POINT  ▲ </div>
Press the <b>F2</b> (NEW POINT) key	<b>F2</b>	<div> NEW POINT    F1 : SIDE SHOT  F2 : RESECTION </div>
Press the <b>F1</b> (SIDE SHOT) key	<b>F1</b>	<div> SELECT A FILE      FN:     <b>BACK</b> <b>LIST</b> <b>CHAR</b>  </div>
Press the <b>F2</b> (LIST) key to display the list of coordinate data files *1	<b>F2</b>	<div> FILE LIST    → &amp; 1 .PTS 1 k    <b>SRCH</b>  <b>FPAG</b> <b>NPAG</b> </div>

<p>Scroll file list by pressing the [▲]or[▼]keys and select a file to use *2,*3</p>	<p>[▲]or[▼]</p>	
<p>Press the <b>F4</b> (ENT) key.</p> <p>The file will be set.</p>	<p><b>F4</b></p>	
<p>Enter the new point name and code.*4</p> <p>Press the <b>ENT</b> key and the instrument will prompt for the target height.</p>	<p>Enter PT#</p> <p><b>ENT</b></p>	
<p>Enter the reflector height and press the <b>ENT</b> key.</p>	<p>Enter R.HT</p> <p><b>ENT</b></p>	
<p>⑨Collimate the new point and press the <b>F1</b> (MEAS) key.</p> <p>Distance measuring starts.</p>	<p>Collimate</p> <p><b>F1</b></p>	


<p>⑩ Press the <b>F4</b> (YES) key *5</p> <p>The name and coordinate value are stored into the COORD DATA.</p> <p>The input menu for next point is displayed and the PT# is automatically incremented.</p>	<b>F4</b>	
<p>*1 ) If you want to input a file name directly press the <b>F1</b> (INPUT) key and enter a file name.</p> <p>*2 ) A file will be highlighted by a  indicated on left of the file name. Press ENT to select. For the file discrimination mark refer to Chapter 10.4 “FILE MAINTENANCE”.</p> <p>*3 ) Data in a file indicated with  can be searched by pressing the <b>F2</b> (SRCH) key.</p> <p>*4 ) Refer to Section 1.10 “to Enter Alphanumeric characters”.</p> <p>*5 ) An error will be displayed when the</p>		

## 9.4.2 Resection Method

The location of a new point can be determined by observing up to a maximum of seven known points.

\*Resection by distance measurement: 2 or more points must be measured, the angle between two points should not exceed 180 °.



The occupied point coordinate value will be calculated using the least squares method.  
 (except in the case of 3 known points measured by angle measurement only).



Operation procedure	Operation	Display
Press the [▼] key from the 1/2 layout menu to get to the 2/2 layout menu screen.	<div>F4</div>	<div>LAYOUT ( 2 / 2 )</div> <div>F1 : SELECT A FILE</div> <div>F2 : NEW POINT</div> <div>▲</div>
Press <div>F2</div> (NEW POINT) key	<div>F2</div>	<div>NEW POINT</div> <div>F1 : SIDE SHOT</div> <div>F2 : RESECTION</div>
Press <div>F2</div> (RESECTION) key	<div>F2</div>	<div>SELECT A FILE</div> <div>FN: </div> <div>BACK LIST CHAR </div>

Enter the File Name (FN) of the new point and press the <b>ENT</b> key	Enter FN <b>ENT</b>	<div> RESECTION <div> <div></div> <div></div> </div> PT# : DATA 02 PCODE : <div> BACK SRCH CHAR JUMP </div> </div>
Enter the new point name *1,*2 Press the <b>ENT</b> key Enter PCODE press the <b>ENT</b> key again.	Enter PT# <b>ENT</b>	<div> RESECTION <div> <div></div> <div></div> </div> F1 : DIST RESECTION </div>
Press <b>F1</b> (DIST RESECTION) key	<b>F1</b>	<div> INPUT INS.HT <div> <div></div> <div></div> </div> I.HT 1.350 m <div> BACK <div></div> <div></div> <div></div> </div> </div>
Enter the instrument height. Press <b>ENT</b> key.	Enter INS.HT <b>ENT</b>	<div> NO 1# <div> <div></div> <div></div> </div> PT# : <div> BACK LIST CHAR NEZ </div> </div>
Enter the first known point number "A".*3	Enter PT# <b>ENT</b>	<div> FN : FN <div> <div></div> <div></div> </div> N : 365.332 m E : 15.300 m Z : 1.230 m &gt;OK? [NO] [YES] </div>


<p>Enter the reflector height, press the <b>ENT</b> key.</p>	<p><b>F4</b> Enter R.HT <b>ENT</b></p>	<div> <div> INPUT R.HT <div> <div></div> <div></div> </div> </div> <div> R.HT : <div>1.220</div> m </div> <div> <div>BACK</div> <div></div> <div></div> <div></div> </div> </div> <div> <div>PSM -30 PPM 0.0</div> <div> <div></div> <div></div> <div></div> </div> </div> <div> V : 95° 30' 55" </div> <div> HR : 65° 45' 30" </div> <div> HD * [N] m </div> <div> VD : m </div> <div> <div>MEAS</div> <div></div> <div></div> <div></div> </div>
--	--	--

<p>(14) Press the <b>F4</b> (CALC) key.</p> <p>Coordinate data of the new point will be shown.</p>	<p><b>F4</b></p>	
<p>(15) Press <b>F4</b> (YES) key *5</p> <p>The new point data will be stored into the coordinate data file and the value of occupied coordinate data will change to that of the calculated new point.</p>	<p><b>F4</b></p>	
<p>*1 ) See Section 1.10 “How to Enter Alphanumeric characters”</p> <p>*2 ) When there is no need to store the new point data press <b>F3</b> (SKP) key.</p> <p>*3 ) To enter the known point coordinate data by directly press <b>F3</b> (NEZ) key.</p> <p>*4 ) RESIDUAL ERROR</p> <p>dHD (Horizontal distance between two known points )= Measured Value - Calculated Value</p> <p>dZ (Z coordinate of the new point calculated from known point A) - (Z coordinate of the new point calculated from Point B )</p> <p>*5 ) If the <b>F3</b> (NO) key is pressed the new point data is not stored to the coordinate data file, only the value of the occupied coordinate data changes to that of the calculated new point.</p>		

### View Coordinate Data

You can audit the PT# list and enter data from the list you can also see the coordinate data of a point.



Operation procedure	Operation	Display
<p>While executing the Layout Mode, press the <b>F2</b> (LIST) key.</p> <p>the arrow (  ) indicates selected data</p>	<p><b>F3</b></p> <p><b>F2</b></p>	<div> <div> LAYOUT <div></div> <div></div> </div> <div> PT# : 19 </div> <div> <div>BACK</div> <div>LIST</div> <div>CHAR</div> <div>NEZ</div> </div> </div> <div> <div>FN : FN</div> <div>→ DATA 01</div> <div>DATA 02</div> <div>DATA 03</div> <div> <div>VIEW</div> <div>SRCH</div> <div>FPAG</div> <div>NPAG</div> </div> </div>
<p>②To scroll through the data use the [▲]or[▼] keys.</p>	<p>[▲]or[▼]</p>	<div> <div> FN : FN <div></div> <div></div> </div> <div> DATA 01 </div> <div> → DATA 02 </div> <div> DATA 03 </div> <div> <div>VIEW</div> <div>SRCH</div> <div>FPAG</div> <div>NPAG</div> </div> </div>
<p>③To show the coordinates of the selected data press the <b>F1</b> (LIST) key.</p> <p>To scroll through the PT# data use the [▲]or[▼] keys.</p>	<p><b>F1</b></p>	<div> <div> PT# DATA 03 <div></div> <div></div> </div> <div> PCODE </div> <div> N : 365,332 m </div> <div> E : 15,300 m </div> <div> Z : 1,230 m </div> </div>
<p>④Press <b>ESC</b> key.</p> <p>The display returns to the list.</p>	<p><b>ESC</b></p>	<div> <div> FN : FN <div></div> <div></div> </div> <div> DATA 01 </div> <div> DATA 02 </div> <div> → DATA 03 </div> <div> <div>VIEW</div> <div>SRCH</div> <div>FPAG</div> <div>NPAG</div> </div> </div>

<p>⑤ Press <b>ENT</b> the key.</p> <p>The selected point number is set as the PT# to layout</p>	<p><b>ENT</b></p> <p><b>F4</b></p>	<div style="border: 1px solid black; padding: 5px;"> <p>FN : FN <span style="float: right;">■■■■ ■■■■</span></p> <p>N : 365.332 m</p> <p>E : 15.300 m</p> <p>Z : 1.230 m</p> <p>&gt;OK? [NO] [YES]</p> </div>
---	------------------------------------	---

## 10. MEMORY MANAGEMENT MODE

The following internal memory settings are available in this mode:

- 1) MEMORY MEDIUM: Choose the current data storage medium (flash / SD card)
- 2) FILE STATE: Checking the number of stored data / Remaining internal memory capacity.
- 3) DATA SEARCH: Search the recorded data
- 4) FILE MAINTAIN: Deleting files / Editing file name
- 5) INPUT COORDINATE: Inputting coordinate data into coordinate data file
- 6) DEL COORDINATE: Deleting coordinates from a coordinate data file
- 7) PCODE INPUT: Inputting PCODE DATA into the PCODE library
- 8) DATA TRANSFER: Sending measured data or coordinate data or PCODE Library data /  
Uploading coordinate data or PCODE library data/setting
- 9) FILE OPERATION: Exchange the files of the FLASH memory and SD CARD with each other.
- 10) INITIALIZE: Initializing internal memory

Memory manager menu operation:




By pressing the **M** menu key the instrument will be in MENU 1/2 mode.

Press the **F3** (MEMORY MGR) key, the menu of MEMORY MGR 1/3 will be shown.





10.1 Choose Storage Medium

This mode is used to select the storage medium.

Operation procedure	Operation	Display
Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.	<b>F3</b>	<div>MEMORY MGR </div> <div>F1 : MEMORY MEDIUM</div> <div>F2 : MEMORY STATE</div> <div>F3 : DATA SEARCH</div> <div>F4 : FILE MAINTAIN</div> <div>▼</div>
Press <b>F1</b> (MEMORY MEDIUM) key	<b>F1</b>	<div>MEMORY MGR </div> <div>F1 : FLASH</div> <div>F2 : SD CARD</div>
Press the <b>F1</b> or <b>F2</b> key to choose the desired storage medium. The menu returns to MEMORY MGR ( 1/3 )	<b>F4</b>	<div>MEMORY MGR </div> <div>F1 : MEMORY MEDIUM</div> <div>F2 : MEMORY STATE</div> <div>F3 : DATA SEARCH</div> <div>F4 : FILE MAINTAIN</div> <div>▼</div>
Note : If the SD card is not present “NO SD CARD!” will be shown on the display.		

## 10.2 Display Internal Memory Status

This mode is used to check the internal memory status.

Operation procedure	Operation	Display
Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.	<b>F3</b>	<div><div>MEMORY MGR </div><div>F1 : MEMORY MEDIUM</div><div>F2 : MEMORY STATE</div><div>F3 : DATA SEARCH</div><div>F4 : FILE MAINTAIN</div><div>▼</div></div>
Press the <b>F2</b> (MEMORY STATE) key  The total capacity, capacity used by the stored data, and free memory is displayed.	<b>F2</b>	<div><div>MEMORY STATE </div><div>CAPACITY : 2016 K</div><div>USED : 65 K</div><div>UNUSED : 1955 K</div></div>
Note: To return to MEMORY MGR menu press the ESC key.		

## 10.3 Searching Data

This mode is used to search the recorded file data.

The following 3 search methods in each type of file can be selected:

1. First data search
2. Last data search
3. Point number search (MEAS. DATA, COORD. DATA)

Number search (PCODE LIB)



MEASURE DATA: Measured data in the data collect mode

COORDINATE DATA: Coordinate data for layout, control points and new point data measured in the layout mode

PCODE DATA: The data which is registered with a number from 1 to 99 in the Point Code library.





10.3.1 Measured Data Searching

Operation procedure	Operation	Display
① Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.	<b>F3</b>	<div><div>MEMORY MGR</div><div>F1: MEMORY MEDIUM</div><div>F2: MEMORY STAT</div><div>F3: DATA SEARCH</div><div>F4: FILE MAINTAIN</div><div>▼</div></div>
② Press the <b>F3</b> (DATA SEARCH) key	<b>F3</b>	<div><div>SEARCH DATA</div><div>F1: MEASURE DATA</div><div>F2: COORDINATE DATA</div><div>F3: PCODE DATA</div><div>F4: PLOT POINT</div><div>▼</div></div>
③ Press the <b>F1</b> (MEASURE DATA) key	<b>F1</b>	<div><div>SELECT A FILE</div><div>FN: FN01</div><div>BACK LIST NUMB</div></div>
④ Enter the file name and press the <b>ENT</b> key *1,*2	Enter FN <b>ENT</b>	<div><div>SEARCH DATA</div><div>FN: FN 02</div><div>F1: FIRST DATA</div><div>F2: LAST DATA</div><div>F3: INPUT PT#</div><div>▼</div></div>

<p>⑤ Press the <b>F3</b> key to enter PT#, then press the <b>ENT</b> key.</p>	<p><b>F3</b> Enter PT# <b>ENT</b></p>	
<p>Press the <b>F4</b> ( P↓ ) key to scroll the data for the selected point.</p>	<p><b>F4</b></p>	
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.</p> <p>*2 ) To show the file list, press the <b>F2</b> (LIST) key.</p> <p>Press the [▲] or [▼] key to scroll to next or previous point.</p>		

Edit measured data in search mode










In this mode PT#, ID, Pcode, Instrument Height and Prism Height can be changed but the measured data can not be modified.


Operation procedure	Operation	Display
① Press <b>F1</b> (EDIT) key in data display 1/3.	<b>F1</b>	
② Press <b>[▲]</b> or <b>[▼]</b> key to select the data item to be modified.	<b>[▲]</b> <b>[▼]</b>	
③ Enter data. Press <b>ENT</b> key	Enter data <b>ENT</b>	
④ Press the <b>F4</b> (SAVE) key and the corrected data is stored.	<b>F4</b>	
*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.		



10.3.2 Coordinate Data Searching



Example searching: Point number searching










Operation procedure	Operation	Display
① Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2	<b>F3</b>	<div>MEMORY MGR  </div> <div>F1: MEMORY MEDIUM F2: MEMORY STATE F3: DATA SEARCH F4: FILE MAINTAIN</div> <div>▼</div>
② Press the <b>F3</b> (DATA SEARCH) key	<b>F3</b>	<div>SEARCH DATA  </div> <div>F1: MEASURE DATA F2: COORDINATE DATA F3: PCODE DATA F4: PLOT POINT</div> <div>▼</div>
③ Press the <b>F2</b> (COORD DATA) key	<b>F2</b>	<div>SELECT A FILE  </div> <div>FN: <b>FN 02</b></div> <div><b>BACK</b> <b>LIST</b> <b>NUMB</b> </div>
④ Enter the File Name and press the <b>ENT</b> key *1,*2)	Enter FN <b>ENT</b>	<div>SEARCH DATA  </div> <div>FN: FN 01 F1: FIRST DATA F2: LAST DATA F3: INPUT PT#</div> <div>▼</div>

<p>⑤ Press the <b>F3</b> key to enter the PT#, then press the <b>ENT</b> key.</p>	<p><b>F3</b> Enter PT# <b>ENT</b></p>	
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.</p> <p>Press the [<b>▲</b>] or [<b>▼</b>] key to scroll to next or previous point.</p>		

### 10.3.3 PCODE LIBRARY Searching






Example searching: Register number searching

Operation procedure	Operation	Display
<p>① Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.</p>	<b>F3</b>	
<p>② Press the <b>F3</b> (DATA SEARCH) key</p>	<b>F3</b>	

③Press the <b>F3</b> (PCODE DATA) key	<b>F3</b>	<div>PCODE DATA SEARCH  </div> <div>F1 : FIRSR DATA</div> <div>F2 : LAST DATA</div> <div>F3 : NO.SEARCH</div>
④Press the <b>F3</b> (NO. SEARCH) key	<b>F3</b>	<div>PCODE DATA SEARCH  </div> <div>NO: <b>01</b></div> <div><b>BACK</b>   </div>
⑤Enter the register number and press the (ENT) key *1 The number and linked data will be shown.	Enter Register no. <b>ENT</b>	<div>PCODE DATA SEARCH  </div> <div>→ 00 :</div> <div>01 : 01</div> <div>02 : 02</div> <div>03 : 03</div> <div><b>EDIT</b> <b>FPAG</b> <b>DEL</b> <b>NPAG</b></div>
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.</p> <p>Press the [<b>▲</b>] or [<b>▼</b>] key to scroll to next or PCODE data.</p> <p>To edit the chosen PCODE press the <b>F1</b> (EDIT) key.</p> <p>To delete the PCODE data press the <b>F3</b> (DEL) key.</p>		

10.3.4 Plotting Points

The function is used to display the coordinate points in the coordinate file of the instrument.

Operation procedure	Operation	Display
① Press <b>F3</b> (MEMORY MGR) key from the menu (1/3)	<b>F3</b>	
② Press <b>F4</b> key to select a plotting coordinate file	<b>F4</b>	
③ Select the starting points of plotting. Just like the operation of data research after define the plotting starting points, press <b>F4</b> key	<b>F4</b>	
④ Now the coordinate points are displayed on the screen. The black block is the starting points. Press <b>F1</b> or <b>F2</b> to find the last point or the next point, press <b>F3</b> or <b>F4</b> key to reduce or magnify the picture, press  , <b>S.O</b> , <b>K1</b> , <b>K2</b> key to move the picture.		


# 10.4 File Maintenance

In this mode the following options are available:

- Renaming file names
- Searching data in a file
- Deleting files

Pressing **F4** (FILE MAINTAIN) key from MEMORY MANAGER menu 1/3 and the file listing will be shown.

## FILE MAINTAN menu



File discrimination marks ( \*, & ) are placed before the file name indicating the file status.

“\*” : current measure file

“&” : current coordinate file

Data discrimination character ( M/ C )

“. RAW” Measured data file

“PTS” Coordinate data file

“. HAL” Horizontal line layout data file

“. VCL” Vertical line layout data file

The figures in the far right column indicate the size of the data file.

Press the [▲]or[▼]key to scroll to next file.

#### 10.4.1 Renaming a File

An existing file in internal memory can be renamed.

Operation procedure	Operation	Display
Press the <b>F4</b> (FILE MAINTAIN) key from the Memory manager menu 1/3.	<b>F4</b>	<div><div>FILE MAINTAIN</div><div><div>→* FN 01 .RAW 3 k</div><div>&amp; FN 02 .PTS 9 k</div><div>FN 03 .HAL 4 k</div><div>FN 04 .VCL 1 k</div></div><div><div>RENM</div><div>DEL</div><div>FPAG</div><div>NPAG</div></div></div>
Select a file by pressing the [▲]or[▼] keys	[▲]or[▼]	<div><div>FILE MAINTAIN</div><div><div>* FN 01 .RAW 3 k</div><div>&amp; FN 02 .PTS 9 k</div><div>→ FN 03 .HAL 4 k</div><div>FN 04 .VCL 1 k</div></div><div><div>RENM</div><div>DEL</div><div>FPAG</div><div>NPAG</div></div></div>
Press the <b>F2</b> (RENM) key	<b>F2</b>	<div><div>FILE MAINTAIN</div><div><div>* FN 01 .RAW 3 k</div><div>&amp; FN 02 .PTS 9 k</div><div>→ <b>FN 03</b> .HAL 4 k</div><div>FN 04 .VCL 1 k</div></div><div><div>BACK</div><div>RETN</div><div>NUMB</div><div></div></div></div>

Enter the new file name and press the <b>ENT</b> key *1	Enter FN <b>ENT</b>	<div> FILE MAINTAIN <div> <div> </div> <div> </div> </div> <div> * FN 01 .RAW 3 k  &amp; FN 02 .PTS 9 k  → FN 03 .HAL 4 k  FN 04 .VCL 1 k </div> <div> RENM DEL FPAG NPAG </div> </div>
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.</p> <p>A file cannot be renamed to that of an existing file, an error message will be displayed.</p> <p>To return to the FILE MAINTAN Menu, press the ESC key.</p>		

10.4.2 Deleting a File

This mode erases a file from internal memory - only one file can be erased at a time.

Operation procedure	Operation	Display
① Press the <b>F4</b> (FILE MAINTAIN) key from the Memory Manager menu 1/3.	<b>F4</b>	<div> FILE MAINTAIN <div> <div> </div> <div> </div> </div> <div> → * FN 01 .RAW 3 k  &amp; FN 02 .PTS 9 k  FN 03 .HAL 4 k  FN 04 .VCL 1 k </div> <div> RENM DEL FPAG NPAG </div> </div>
② Select a file to delete by pressing the <b>[▲]</b> or <b>[▼]</b> key.	<b>[▲]</b> or <b>[▼]</b>	<div> FILE MAINTAIN <div> <div> </div> <div> </div> </div> <div> * FN 01 .RAW 3 k  → &amp; FN 02 .PTS 9 k  FN 03 .HAL 4 k  FN 04 .VCL 1 k </div> <div> RENM DEL FPAG NPAG </div> </div>
③ Press the <b>F2</b> (DEL) key	<b>F2</b>	<div> FILE MAINTAIN <div> <div> </div> <div> </div> </div> <div> * FN 01 .RAW 3 k  → &amp; FN 02 .PTS 9 k  FN 03 .HAL 4 k  FN 04 .VCL 1 k </div> <div> DEL? [NO] [YES] </div> </div>




④ Confirm the deleting by pressing the <b>F4</b> (YES) key.	<b>F4</b>	<div> FILE MAINTAIN <div> <div></div> <div></div> </div> <div> * FN 01 .RAW 3 k  → FN 03 .HAL 4 k  FN 04 .VCL 1 k </div> <div> RENM DEL FPAG NPAG </div> </div>
To return to the FILE MAINTAIN Menu, press the ESC key.		

10.5 Coordinate Data Direct Key Input

Coordinate data for the layout point or control point can be input directly from the keyboard. The data can be stored into a file in the internal memory.


Operation procedure	Operation	Display
①Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.	<b>F3</b>	<div> MEMORY MGR <div> <div></div> <div></div> </div> <div> F1: MEMORY MEDIUM  F2: MEMORY STATE  F3: DATA SEARCH  F4: FILE MAINTAIN </div> <div>▼</div> </div>
② Press the <b>▼</b> key for menu MEMORY MGR 2/3	<b>▼</b>	<div> MEMORY MGR <div> <div></div> <div></div> </div> <div> F1: INPUT COORDINATE  F2: DEL COORDINATE  F3: INPUT PCODE </div> <div>▼</div> </div>
③ Press the <b>F1</b> (INPUT COORDINATE) key	<b>F1</b>	<div> SELECT A FILE <div> <div></div> <div></div> </div> <div> FN: FN 01 </div> <div> BACK LIST NUMB </div> </div>


















④Enter the File Name you want to input. Press the <b>ENT</b> key *1	Enter PN <b>ENT</b>	
⑤Enter the point number (PT#) you wish to input. Press the <b>ENT</b> key and enter the PCODE and press <b>ENT</b> *1	Enter PT# <b>ENT</b>	
⑥Enter the coordinate data. After storing the new point the next point number (PT#) is automatically incremented and displayed.	Enter COORD <b>ENT</b>	
*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.		

## 10.6 Deleting a Coordinate Data From a File











Coordinate data in a file can be erased


Operation procedure	Operation	Display
① Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.	<b>F3</b>	

<p>② Press the  key to scroll the menu.</p>		
<p>③ Press the  (DEL COORDINATE) key</p>		
<p>④ Enter or select the File Name and press the  key *1</p>	<p>Enter PN </p>	
<p>⑤ Enter the point number (PT#) and press the  key *1</p>	<p>Enter PT# </p>	
<p>⑥ Confirm the data and press the  (YES) key to delete. The display will return to the previous display.</p>		
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.</p>		

10.7 Editing PCODE Library

PCODE data can be entered into the PCODE Library in this mode. A PCODE is linked with a number 1 to 99. PCODE can also be also edited in the DATA COLLECT menu 2/2.

Operation procedure	Operation	Display
① Press the <b>F3</b> (MEMORY MGR) key from the menu screen 1/2.	<b>F3</b>	<div>MEMORY MGR  </div> <div>F1 : MEMORY MEDIUM F2 : MEMORY STATE F3 : DATA SEARCH F4 : FILE MAINTAIN</div> <div>▼</div>
② Press the <b>▼</b> key	<b>▼</b>	<div>MEMORY MGR  </div> <div>F1 : INPUT COORDINATE F2 : DEL COORDINATE F3 : INPUT PCODE</div> <div>▼</div>
③ Press the <b>F3</b> (INPUT PCODE) key.	<b>F3</b>	<div>EDIT PCODE  </div> <div>→ 00 : 01 : 01 02 : 02 03 : 03</div> <div><b>EDIT</b> <b>FPAG</b> <b>DEL</b> <b>NPAG</b></div>
④ Scroll to the number desired using the <b>[▲]</b> or <b>[▼]</b> keys and F2 or F3 to scroll pages.	<b>[▲]</b> or <b>[▼]</b>	<div>EDIT PCODE  </div> <div>→ 00 : 01 : 01 02 : 02 03 : 03</div> <div><b>EDIT</b> <b>FPAG</b> <b>DEL</b> <b>NPAG</b></div>
⑤ Press the <b>F1</b> (EDIT) key.	<b>F1</b>	<div>EDIT PCODE  </div> <div>00 : → 01 : 01 02 : 02 03 : 03</div> <div><b>EDIT</b> <b>FPAG</b> <b>DEL</b> <b>NPAG</b></div>

<p>⑥Enter the PCODE and press the <b>ENT</b> key, entry scrolls to the next point automatically *1</p>	<p><b>ENT</b></p>	
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.</p>		


## 10.8 Data Communication

You can send a data file stored in the internal memory to a computer through the DATA TRANSFER menu. Also you can upload a coordinate data file and PCODE Library data to the instrument from a computer. There are two modes of data communication, RS-232 and USB.

1. Transmit data by connecting the instrument to PC with RS-232 cable.
2. Convert file by connecting the instrument to PC with USB cable.

### 10.8.1 Data Communication with RS-232

RS-232 Data Communication Menu:



F1 : SEND DATA - send data from the instrument to the computer
















F2 : LOAD DATA - load data from the computer to the instrument




F3 : COMM. PARAMETERS - set the communication parameters

Note: When transferring data check that the cables are connected securely and that the parameter settings on the computer and Total Station are consistent.

### 10.8.1.1 Sending Data

Refer to the Transfer.exe program on the CD included with your instrument. Start this program and follow the prompts for data transfer.

Operation procedure	Operation	Display
① Press the  (MEMORY MGR) key from the menu 1/2.		 <p>MEMORY MGR (1/3)   F1: MEMORY MEDIUM F2: MEMORY STATE F3: DATA SEARCH F4: FILE MAINTAIN ▼</p>
② Press the  key twice for screen 3/3		 <p>MEMORY MGR (3/3)   F1: DATA TRANSFER F2: FILE OPERATION F3: INITIALIZE ▼</p>
③ Press the  ( DATA TRANSFER ) key		 <p>DATA TRANSFER   F1: SEND DATA F2: LOAD DATA F3: COMM.PARAMETERS</p>

<p>④ Press the <b>F1</b> ( SEND DATA ) key</p>	<p><b>F1</b></p>	
<p>⑤ Select the type of data to send by pressing the <b>F1</b> – <b>F2</b> key. Example: <b>F1</b> (MEASURE DATA)</p>	<p><b>F1</b></p>	
<p>⑥ Enter the File Name you want to send and press the <b>ENT</b> key *1,*2</p>	<p>Enter FN <b>ENT</b></p>	
<p>⑦ Press the <b>F4</b> (YES ) key *3 The data transfer begins. The display will return to the SEND DATA menu after the transfer is finished.</p>	<p><b>F4</b></p>	
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.</p> <p>*2 ) To scroll the data press the [▲] or [▼] key. To show the file list press the <b>F2</b> (LIST) key.</p> <p>*3 ) To cancel transfer press the <b>F4</b> (STOP) key.</p>		



### 10.8.1.2 Loading Data

Coordinate data files and PCODE Library data can be loaded from a PC. Refer to the Transfer.exe program on the CD included with your instrument. Start this program and

follow the prompts for data transfer.



Example: Loading a coordinate data file.

Operation procedure	Operation	Display
① Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.	<b>F3</b>	<div><div>MEMORY MGR</div><div><div></div><div></div><div></div><div></div></div><div>F1 : MEMORY MEDIUM</div><div>F2 : MEMORY STATE</div><div>F3 : DATA SEARCH</div><div>F4 : FILE MAINTAIN</div><div>▼</div></div>
② Press the ▼ key twice for screen 3/3	▼	<div><div>MEMORY MGR</div><div><div></div><div></div><div></div><div></div></div><div>F1 : DATA TRANSFER</div><div>F2 : FILE OPERATION</div><div>F3 : INITIALIZE</div><div>▲</div></div>
③ Press the <b>F1</b> (DATA TRANSFER) key	<b>F1</b>	<div><div>DATA TRANSFER</div><div><div></div><div></div><div></div><div></div></div><div>F1 : SEND DATA</div><div>F2 : LOAD DATA</div><div>F3 : COMM.PARAMETERS</div></div>
④ Press the <b>F2</b> (LOAD DATA) key	<b>F2</b>	<div><div>RECEIVE DATA</div><div><div></div><div></div><div></div><div></div></div><div>F1 : COORDINATA DATA</div><div>F2 : PCODE DATA</div><div>F3 : H-LINE DATA</div><div>F4 : V-LINE DATA</div></div>
⑤ Select the type of data to load. Example: <b>F1</b> (COORDINATE DATA)	<b>F1</b>	<div><div>SELECT A FILE</div><div><div></div><div></div><div></div><div></div></div><div>FN: FN 01</div><div>BACK NUMB</div></div>















⑥Enter a new file name for the data. Press the <b>ENT</b> key *1	<b>ENT</b>	
⑦Press the <b>F4</b> (YES) key to confirm and start the transfer. *2		
<p>*1 ) Refer to Section 1.10 “How to Enter Alphanumeric characters”.</p> <p>*2 ) To cancel the transfer press the <b>F4</b> (STOP) key.</p>		

### 10.8.1.3 Setting the Parameters of Data Communication

Example setting the baud rate to 4800

Operation procedure	Operation	Display
① Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.	<b>F3</b>	
②Press the <b>▼</b> key twice	<b>▼</b>	



<p>③ Press the <b>F1</b> ( DATA TRANSFER ) key</p>	<p><b>F1</b></p>	<div data-bbox="641 137 969 320"> <p>DATA TRANSFER  </p> <p>F1 : SEND DATA</p> <p>F2 : LOAD DATA</p> <p>F3 : COMM.PARAMETERS</p> </div>
<p>④ Press the <b>F3</b> (COMM PARAMETERS ) key</p>	<p><b>F3</b></p>	<div data-bbox="641 346 969 529"> <p>COMM. PARAMETERS  </p> <p>F1 : BAUD RATE</p> <p>F2 : CHAR CHECKOUT</p> <p>F3 : PROTOCOL</p> </div>
<p>⑤ Press the <b>F1</b>, <b>F2</b> and <b>F3</b> keys one by one to select BAUD RATE, CHAR CHECKOUT and PROTOCOL.</p> <p>The parameters need to be consistent between the instrument and the Transfer.exe program.</p>	<p><b>F1</b></p> <p><b>F2</b></p> <p><b>F3</b></p>	<div data-bbox="641 555 969 738"> <p>BAUD RATE  </p> <p>BAUD RATE : [ 9600 ] b/s</p> <p> </p> </div> <div data-bbox="641 746 969 930"> <p>CHAR CHECKOUT  </p> <p>F1 : 7 BIT EVEN</p> <p>F2 : 7 BIT ODD</p> <p>F3 : [ 8 BIT NOTE ]</p> </div> <div data-bbox="641 938 969 1121"> <p>COMM. PARAMETERS  </p> <p>F1 : ACK</p> <p>F2 : [ NO ACK ]</p> </div>
<p>⑥ After selecting each parameter press the <b>ENT</b> key *1</p>	<p><b>ENT</b></p>	<div data-bbox="641 1144 969 1327"> <p>COMM. PARAMETERS  </p> <p>F1 : BAUD RATE</p> <p>F2 : CHAR CHECKOUT</p> <p>F3 : PROTOCOL</p> </div>
<p>*1 ) BAUD RATE can be set to: 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 b/s. Select by pressing the <b>F3</b> (DECE) or <b>F4</b> (ADD) key.</p>		

\*2 ) To cancel the setting press the ESC key.

These settings will be saved as the default values after powering off.

## 10.8.2 Data Conversion By USB

Start up the instrument, connect the instrument to PC with USB cable, the menu is displayed on the screen as below.

USB Working.....

Please disconnection

Press <ESC> to exit!

This represents the connection is normal, then you can operate the data file stored in the instrument by data transmission software, It is also possible to copy the file on PC into the instrument.

### 10.8.2.1 Data Export

Data type in the memory of total station

1. \*. RAW—Measurement file
2. \*. PTS—Coordinate file
3. \*. HAL—Horizontal line location file
4. \*. VCL—Verical line location file
5. \*. PCOPE. LIB—Pcode file

In order to export the relevant data from certain file, you can just open the corresponding file by data transmitting software.

For example: Open TS. RAW file

Start transmission software, select “open EMS file” in the menu “USB operation”, then select “open\*. RAW(measurement data file)” and choose “TS. RAW” file of the memory to realize opening the TS. RAW file, the measurement data will be displayed in the transmission software and can be stored in PC.

### 10.8.2.2 Data Inport

For example: Inporting POCDE data

Start the data transmission software, import the coding which is needing to be imported in the text box or open the PCODE file of text style which has been edited already.

The encoding format is as below

1. CODE ✓
2. HOUSE ✓
3. TREE ✓










Up to 500 codes can be input, after inputing the codes, select “convert EMS memory file” in the menu “USB operation”, choose “\*.txt或PCODE. LIB” to realize the conversion, store the data in the memory of the instrument.

Note: Only one encoding file is allowed to exist, and the file name can't be modified, the file can only be covered, In addition, the file can only be stored in the memory, not in the SD card.

10.9 File Operation














This function is used to realize the mutual copy between the memory and SD card.

10.9.1 Copy File From SD Card To Memory Of The Instrument

Operation procedure	Operation	Display
① Press <b>F2</b> key from MEMORY MGR.(3/3) menu to get FILE OPERATION	<b>F2</b>	<div>FILE OPERATION  </div> <div>F1:SD CARD → MEMORY F2:MEMORY → SD CARD</div>
② Press <b>F1</b> key to enter import interface, the file names existing in SD card are displayed.	<b>F1</b>	<div>SELECT A FILE  </div> <div>→ FN 01 .RAW 2 k FN 02 .PTS 3 k FN 04 .</div> <div>  <b>FPAG</b> <b>NFAG</b></div>
③Select a file name , press <b>ENT</b> key.	<b>ENT</b>	<div>SELECT A FILE  </div> <div>FN:FN01</div> <div><b>BACK</b> <b>LIST</b> <b>CHAR</b> </div>
④Input a file name for the inported, then press <b>ENT</b> key to finish the operation.	<b>ENT</b>	

10.9.2 Copy The File From Memory To SD Card.

This operation procedure is similar to the section 10.9.1 just introduced above, the only difference is to press **F2** key instead of **F1** key in the second step of the section 10.9.1

Operation procedure	Operation	Display
① Press the <b>F2</b> key from MEMORY MGR.(3/3) menu to get FILE OPERATION	<b>F2</b>	<div>FILE OPERATION  </div> <div>F1:SD CARD → WORK EMS F2:WORK EMS → SD CARD</div>
②Press the <b>F2</b> key: WORK EMS→SD CARD.	<b>F2</b>	<div>FILE TYPE  </div> <div>F1:MEASURE FILE F2:COORDINATE FILE</div>
③Press the <b>F1</b> or <b>F2</b> key to choose an export file type.	<b>F1</b> <b>F2</b>	<div>SELECT A FILE  </div> <div>FN: <b>FN 06</b></div> <div><b>BACK</b> <b>LIST</b> <b>CHAR</b> </div>
④Choose a file to export and press the <b>ENT</b> key.	<b>ENT</b>	<div>FILE TYPE  </div> <div>F1:*.DAT F2:*.TXT</div>
⑤Press the <b>F1</b> or <b>F2</b> key to choose an export file data type.	<b>F1</b> <b>F2</b>	<div>SELECT A FILE  </div> <div>FN: <b>FN 06</b>.TXT</div> <div><b>BACK</b>  <b>CHAR</b> </div>

⑥Enter a new file name and press the <b>ENT</b> key to convert and store.	<b>ENT</b>	
---	------------	--

## 10.10 Initialization

This mode is used to initialize the internal memory. Following data can be initialized:




FILE DATA: All measuring data and coordinate data. (data in the files)

PCODE DATA: PCODE list.

ALL FILE: All files will be deleted. (except PCODE).

For example: Initialize all files.

Operation procedure	Operation	Display
①Press the <b>F3</b> (MEMORY MGR) key from the menu 1/2.	<b>F3</b>	
②Press the <b>▼</b> key twice	<b>▼</b>	

③ Press the <b>F3</b> (INITIALIZE) key	<b>F3</b>	
④ Select the data to initialize by pressing the <b>F1</b> to <b>F3</b> keys. Example : <b>F2</b> (ALL FILE)	<b>F3</b>	
⑤ To confirm the erase function press the <b>F4</b> (YES) key. Initializing will begin.	<b>F4</b>	





Note: The following data will not be initialized during this process:

- Instrument Coordinates
- Instrument Height
- Target Height.

# 11. BASIC SETTINGS



The instruments basic function settings should be monitored and set for each job.

Operation procedure is as follows :

Operation procedure	Operation	Display
Press the <b>M</b> key to get the main MENU 1/2.	<b>M</b>	<div><div>MENU ( 1/2 )</div><div>F1 : COLLECT DATA</div><div>F2 : PROGRAMS</div><div>F3 : MEMORY MGR</div><div>F4 : CONFIG</div><div>↓</div></div>
Press the <b>F4</b> (CONFIG) from the main MENU(1/2) to get CONFIG menu.	<b>F4</b>	<div><div>CONFIG ( 1/2 )</div><div>F1 : UNIT SET</div><div>F2 : PARAMETER SET</div><div>F3 : POWER ON DISPLAY</div><div>F4 : SHORTCUT KEY SET</div><div>↓</div></div>

## 11.1 Unit Settings

Setting the instrument units as needed.





Operation procedure	Operation	Display
In CONFIG (1/2), press the <b>F1</b> key to get to the UNIT SET menu.	<b>F1</b>	<div><div>UNIT SET</div><div>F1 : ANGLE</div><div>F2 : TEMPERATURE</div><div>F3 : AIR PRESSURE</div><div>F4 : DISTANCE</div></div>
Press the <b>F1</b> to <b>F4</b> keys to set the angle, temperature, air pressure and distance		





variables.			
Select unit and parameter			
Unit Select	ANGLE	DEG (360 °) GON (400GON) MIL (6400MIL)	Select the desired angle measurement unit DEG/GON/MIL
	TEMPERATURE	Temperature : °C/°F	Select temp. unit : °C/°F
	AIR PRESSURE	Air pressure : hPa /mmHg/inHg	Select air pressure unit : hPa/mmHg/inHg
	DISTANCE	m/ft	Select distance measurement unit : m/ft

## 11.2 parameter Settings

Setting other parameters.



Operation procedure	Operation	Display
<p>In CONFIG (1/2) press the <b>F2</b> key for the MEAS. PARA. menu screen.</p> <p>Press the <b>▼</b> to scroll to the second MEAS. PARA. 2/2 menu.</p>	<b>F2</b>	<div> MEAS. PARA ( 1 / 2 )    F1 : TILT SENSOR  F2 : W-CORRECTION  F3 : GRID FACTOR  F4 : LEAST ANGLE DISP  ↓ </div> <div> MEAS. PARA ( 2 / 2 )    F1 : V ANGLE DISP  F2 : MEASURE DISTANCE  ↑ </div>

11.2.1 Setting of the Tilt Sensor

Operation procedure	Operation	Display
Press the <b>F1</b> key from the MEAS. PARA. menu to get to the TILT SENSOR display.	<b>F1</b>	
Press <b>F3</b> key turn on ,press <b>F4</b> key turn off.	<b>F3</b> <b>F4</b>	

If the instrument is with dual axis compensator.

The operation is as below.

① Press the <b>F1</b> key from the MEAS. PARA. Setting menu to get to the TILT SENSOR display.	<b>F1</b>	
② Press <b>F3</b> or <b>F4</b> key to turn on or off X axis or Y axis compensator.	<b>F3</b> <b>F4</b>	

11.2.2 Setting of the W-Correction

The instrument will automatically correct the influence of atmosphere refraction and earth curvature when measuring Horizontal Distance and Elevation Difference:

Corrected Horizontal Distance:

$$D=S*[\cos\alpha+\sin\alpha* S*\cos\alpha (K-2)/2Re]$$

Corrected Elevation Difference:

$$H=S*[\sin\alpha+\cos\alpha* S*\cos\alpha (1-K)/2Re]$$

If the correction of atmospheric refraction and earth curvature is not used the formula of calculating the Horizontal Distance and Elevation Difference is as follows:

$$D=S* \cos\alpha$$

$$H=S* \sin\alpha$$

Note: In the factory the atmospheric refraction coefficient of the instrument is set at K=0.14.

For the value of K there are three options, K=0.14, K=0.2, and Off.



K=0.14..... Atmospheric refraction coefficient

Re=6371km..... Earths Radius

$\alpha$ .....The vertical angle calculated from horizon

S .....Slope Distance

Setting is as follows :

Operation procedure	Operation	Display
Press the <b>F2</b> key from the MEAS. PARA. Menu to get to the W-CORRECTION screen.	<b>F2</b>	
Press <b>F1</b> to <b>F3</b> key to select the atmospheric refraction coefficient of the W-CORRECTION.	<b>F1</b> - <b>F3</b>	

### 11.2.3 Setting the GRID FACTOR

#### Calculation Formula

##### 1 ) Elevation factor

$$\text{Elevation factor} = R / (R + \text{ELEV})$$

R : the average radius of the earth

ELEV : the elevation above mean sea level

##### 2 ) Scale factor

Scale factor at the surveying station

##### 3 ) Grid factor

$$\text{Grid factor} = \text{Elevation factor} \times \text{Scale factor}$$

#### Distance calculation

##### 1 ) Grid distance

$HDg = HD \times \text{Grid factor}$




HDg : Grid distance



HD : Ground distance

2 ) Ground distance

$HD = HDg / \text{Grid factor}$

Setting is as follows :

Operation procedure	Operation	Display
Press <b>F3</b> key from MEAS. PARA. menu to get to the GRID FACTOR screen.	<b>F3</b>	
Press the <b>F1</b> (ON) key to turn on the GRID FACTOR.	<b>F1</b>	
Press the <b>F4</b> (MODY) key to modify.	<b>F4</b>	

Press <b>F4</b> (YES) key to set the elevation (ELEV) and SCALE.	<b>F4</b>	<div> GRID FACTOR   </div> <div> ELEV = 0.000 m </div> <div> SCALE = 1.000000 </div> <div> BACK </div>
After modifying press the <b>ENT</b> key and the calculated grid factor is shown.	<b>ENT</b>	<div> GRID FACTOR=1.000001 </div>



#### 11.2.4 Setting of the Minimum Angle Reading

The Total Station can be programmed to display the angle measured to the nearest 1" or 5".

The instrument can also be set to the desired angle measurement unit.

Mode	unit		
	degree	gon ( 400 gon )	mil
CST300R	5"/1"	1mgon /0.2mgon	0.1mil/0.01mil

Minimum angle display reading.

Operation procedure	Operation	Display
Press the <b>F4</b> key from the MEAS. PARA. menu to get to the LEAST ANGLE DISP screen.	<b>F4</b>	<div> LEAST ANGLE DISP   </div> <div> F1 : [1°] </div> <div> F2 : 5" </div>

Press <b>F2</b> to choose 5" or F1 to choose the 1" display mode, then press the <b>ENT</b> key to confirm. This setting does not effect the accuracy of the instrument.	<b>F2</b>	<p>LEAST ANGLE DISP       </p> <p>F1 : 1"</p> <p>F2 : [5"]</p>
--	-----------	--






### 11.2.5 Setting the Vertical Angle Display

The vertical angle display can be measured from Zenith or the horizontal plane. The Z0 (zenith) method is the most often used for surveying purposes, the “0” value will be directly overhead.

Operation procedure	Operation	Display
Press <b>F1</b> key from MEAS PARA. menu 2/2 for the V ANGLE Z0/H0 screen	<b>F1</b>	<p>V ANGLE Z0/H0       </p> <p>F1 : [Z0]</p> <p>F2 : H0</p>
Press the <b>F2</b> (H0) key then press the <b>ENT</b> key to return to MEAS PARA menu.	<b>F2</b>	<p>V ANGLE Z0/H0       </p> <p>F1 : [Z0]</p>

11.2.6 Setting of Plotting Points Number

Setting of the maximum points number displayed on the screen.



Operation procedure	Operation	Display
Press <b>F2</b> in the menu measured parameter (2/2) setting interface to enter setting of plotting points number interface.	<b>F2</b>	<div>SET PLOT POINTS  </div> <div>RANGE: 5~50</div> <div>NUMBER: <b>20</b></div> <div><b>BACK</b>   </div>
Input the points number needing to be displayed and then press <b>ENT</b> key.		

11.2.7 Setting the Distance Range Mode


The Total Station has the option of defining the normal distance measured during operation to increase measuring efficiency:

0-2KM (0-1.2 miles): Selecting this option gives the quickest measurement times.

0-5KM (0-3 miles): Use this mode when measuring longer distances.

Operation procedure	Operation	Display
Press the <b>F2</b> key from MEAS PARA. menu 2/2 to get to the MEASURE DISTANCE screen.	<b>F2</b>	<div>MEASURE DISTANCE  </div> <div>F1 : [ 0-2KM ]</div> <div>F2 : 0-5KM</div>




Press the <b>F2</b> (0-5KM) or <b>F1</b> (0-2KM) key and then the <b>ENT</b> key to select and return to the MEAS PARA. menu.	<b>F2</b> or <b>F1</b>	
---	------------------------	---

11.2.8 Automatic Compensation For Temperature And Air Pressure

The total station has function of Auto compensation for temperature and air pressure. You can turn on this function to compensate the temp. and air pressure auto matically, and you can also turn off the automatic compensation to set the temp. and air pressure by hand.

For example: Setting Auto Compensation To Be [ON]

Operation procedure	Operation	Display
Press the <b>F3</b> in menu “measured parameters setting” (2/2) to get to Auto compensation interface.	<b>F3</b>	
Press <b>F1</b> to select “YES”. Press <b>ENT</b> key to return.	<b>F1</b>	

### 11.3 Setting the Measure Mode Display

The default display in the measure modes can be set by pressing [F3] POWER ON DISPLAY on menu 1/2 in the CONFIG screen:

Shown	F1: MEASURE MODE	Angle or distance	Choose the angle or distance measuring mode.
	F2: HD&VD /SD	HD&VD /SD	Choose the distance mode - Horizontal &Vertical Distance or Slope Distance
	F3: COORD. FORMAT	ENZ/NEZ	Select the coordinate display order ENZ or NEZ



### 11.4 Setting the Shortcut Keys

The CST300R has two shortcut keys that can be configured by the user.

Shortcut key	Operation	Function
K1	Press the <b>K1</b> key for 1second	1、 REM
	Press <b>F4</b> key from CONFIG menu	2、 MLM
K2	Press the <b>K2</b> key for 1second.	3、 AREA
		4、 Z COORD.
	Press the <b>F4</b> key from the CONFIG menu	5、 POINT TO LINE
		6、 ROAD
		7、 RESECTION
		8、 NONE





11.5 Other Settings

The instrument can be set to auto matically power off, change the battery type, reset configurations and select the operating language.

Operation procedure	Operation	Display
Press <b>F1</b> (OTHERS SET) from the CONFIG menu 2/2.	<b>F2</b>	<div>OTHER SET  </div> <div>F1 : AUTO POWER OFF F2 : BATTERY TYPE F3 : RENEW F4 : Select Language</div>

11.5.1 Auto Power Off

If there is no key operation or ongoing measurement in 60 minutes the instrument will power off automatically.



Operation procedure	Operation	Display
Press the <b>F1</b> key from the OTHERS SET menu to get to AUTO POWER OFF.	<b>F1</b>	<div>AUTO POWER OFF  </div> <div>F1 : [ON] F2 : OFF</div>
Press the <b>F2</b> (OFF) key to not select this feature or <b>F1</b> to engage, press the <b>ENT</b> key and the instrument will return to the OTHER SET menu.	<b>F2</b>	<div>AUTO POWER OFF  </div> <div>F1 : ON F2 : [OFF]</div>

11.5.2 Choosing Battery Type

The instrument comes with a standard NiMH battery and this option should not be changed.

The NB-36 battery option is reserved for future use.

NB-36: battery                      NB-28: Ni-H battery

Operation procedure	Operation	Display
Press the <b>F2</b> key from the OTHER SET menu to get to the BATTERY TYPE display.	<b>F2</b>	<div><div>BATTERY TYPE </div><div>F1 : [HB-36]</div><div>F2 : HB-28</div></div>
Press <b>F2</b> (NB-28) and <b>ENT</b> to confirm and return to the OTHER SET Menu.	<b>F2</b>	<div><div>BATTERY TYPE </div><div>F1 : HB-36</div><div>F2 : [HB-28]</div></div>
Note: If BATTERY TYPE is changed to an incorrect setting the instrument will power off.		

11.5.3 Renew to Factory Configuration


The following procedures reset the instrument settings and parameters to the original factory settings.

Operation procedure	Operation	Display
Press the <b>F3</b> RENEW key from the OTHERS SET menu.	<b>F3</b>	<div><div><div><div></div><div></div><div></div><div></div></div><div>RENEW CONFIG TO LEAVE FACTORY</div><div>RENEW? [NO] [YES]</div></div></div>
Press the <b>F2</b> (YES) key to reset the instrument. After finished the instrument will return to the OTHERS SET screen.	<b>F2</b>	<div><div><div><div></div><div></div><div></div><div></div></div><div>OTHER SET</div><div>F1 : AUTO POWER OFF</div><div>F2 : BATTERY TYPE</div><div>F3 : RENEW</div><div>F4 : Select Language</div></div></div>

11.5.4 Selecting a Language



The instrument can be set to an alternative language using the flowing procedures.



Operation procedure	Operation	Display
Press the <b>F4</b> SelectLanguage key from the OTHERS SET menu.	<b>F3</b>	<div><div><div><div></div><div></div><div></div><div></div></div><div>Select language</div><div>F1 : [English]</div><div>F2 : Spanish</div></div></div>

Press the <b>F1</b> or <b>F2</b> key to select the desired language, press <b>ENT</b> and the instrument will return to the OTHERS SET screen.	<b>F2</b>	
--	-----------	---

11.6 Date and Time




The date and time can be set using the following procedures:

Operation procedure	Operation	Display
Press the <b>F1</b> (EMENDATION) key from the main menu page 2/2	<b>F1</b>	
Press the <b>F3</b> (TIME AND DATE) key to set time and date.	<b>F3</b>	

<p>Press the <b>F1</b> or <b>F2</b> key to set date and time. After entry press the <b>ESC</b> key to return to ADJUSTMENT MODE.</p>	<p><b>F1</b> <b>F2</b></p>	 
--	----------------------------	--

### 11.7 Adjusting the Contrast of the LCD


The contrast of the LCD can be adjusted using the following procedures:

Operation procedure	Operation	Display
Press the <b>F1</b> (EMENDATION) key from the main menu page 2/2.	<b>F1</b>	
Press the <b>F4</b> (LCD CONTRAST) key to get to the CONTRAST screen.	<b>F4</b>	
Press <b>F2</b> and <b>F3</b> keys to set the contrast, after finished press the <b>ESC</b> key to return to ADJUSTMENT MODE.	<b>F2</b> <b>F3</b>	

## 12. CHECK AND ADJUSTMENT

The instrument has been checked and adjusted thoroughly at the factory to insure the instrument meets our quality requirements. But long distance transportation and the change of the environment could cause the instrument to go out of adjustment. It is recommended before using the instrument it should be checked and adjusted according to the procedures outlined below.

### 12.1 Plate Vial



#### **Inspection**

Refer to Section 1.4 Instrument Set Up and “Leveling by using the plate vial”

#### **Adjustment**

1. Place instrument on the tripod.
2. Face the instrument with two of the three leveling screws in front of you.
3. Rotate the right level screw to center the plate vial bubble.
4. Move instrument CCW and rotate the next right level screw to center the plate vial bubble again.



5. Move instrument CCW and rotate the next right level screw to center the plate vial bubble again.
6. Now, move CCW to the next position and check to see if the bubble is centered.
7. If the plate vial bubble is not centered, remove 1/2 of the error with right level screw and 1/2 of the error with the plate vial adjusting screw.
8. Repeat steps 4, 5, and 6.
9. If there is still an offset error with the plate vial bubble repeat procedure until bubble is centered.

## 12.2 Circular Vial

### **Inspection**

No adjustment is necessary if the bubble of the circular vial is in the center after inspection and adjustment of the plate vial.

### **Adjustment**


If the bubble of the circular vial is not in the center bring the bubble to the center by using the adjusting pin or hexagon wrench to adjust the bubble adjusting screw. First loosen the screw opposite to the offset side and then tighten the other adjusting screw on the offset side, bringing the bubble to the center. After the bubble stays in the center each of the three adjustment screws should be tightened in a uniform manner.

## 12.3 Inclination of Reticle

### Inspection

1. Sight object A through the telescope and lock the horizontal and vertical clamp screws.
2. Move object A to the edge of the field of view with the vertical tangent screw (point A')
3. No adjustment is necessary if object A moves along the vertical line of the reticle and point A' is still in the vertical line.


As illustrated A' offsets from the center and the cross hair tilts, then the reticle needs adjustment.



### Adjustment

1. If the object A does not move along the vertical line, first remove the eyepiece cover to expose the four reticle adjusting screws.
2. Loosen the four reticle adjusting screws uniformly with an adjusting pin. Rotate the reticle around the sight line and align the vertical line of the reticle with point A'
3. Tighten the reticle adjusting screws uniformly, repeat the inspection and adjustment to see if the adjustment is correct.

4. Replace the eyepiece cover.



## 12.4 Perpendicularity of Line of Sight to Horizontal Axis (2c)

### Inspection


1. Set an object A at a far distance the same height as the instrument, then level and center the instrument and turn on the power.

2. Sight object A in the left position and read the horizontal angle value ( horizontal angle  $L=10^{\circ}13'10''$  ).

3. Loosen the vertical and horizontal clamp screws and rotate the telescope. Sight object

A in right position and read the horizontal angle value.(horizontal angle  $R = 190^{\circ}13'40''$  ).

4.  $2C = L - (R \pm 180^{\circ}) = -30'' \geq \pm 20''$  , adjustment is necessary.



### **Adjustment**

1. Use the tangent screw to adjust the horizontal angle reading,
2. Take off the cover of the reticle between the eyepiece and focusing screw. Adjust the two adjusting screws by loosening one and tightening the other. Move the reticle to sight object A exactly.
3. Repeat inspection and adjustment until  $|2C| < 20''$ .
4. Replace the cover of the reticle.

## **12.5 Vertical Index Difference Compensation**

### **Inspection**

1. Mount and level the instrument and make the telescope parallel with the line connecting the center of the instrument to any one of the screws. Lock the horizontal clamp screw.
2. After turning on the power, zero the vertical index. Lock the vertical clamp screw and the instrument should display the vertical angle value.
3. Rotate the vertical clamp screw slowly in either direction about 10mm in circumference, and the error message "b" will appear. The vertical axis has increased to more than 3" at this time and exceeds the designated compensation range.

Rotate the above screw to its original position, and the instrument display screen will show the vertical angle again, meaning that the vertical index difference compensation function is working.

## Adjustment

If the compensation function is not working, send the instrument back to the factory for repair.

## 12.6 Adjustment of Vertical Index Difference ( I angle) and Vertical Angle 0

### Datum


Inspect the item after finishing the inspection and adjustment of item 13.3 and 13.4.

### Inspection

1. Power on after leveling the instrument. Sight object A in left position and read the Vertical angle value L.
2. Rotate the telescope. Sight object B in right position and read the Vertical angle value R.
3. If the vertical angle is 0° in zenith,  $i = (L + R - 360^\circ) / 2$   
If the vertical angle is 0° in horizon  $i = \frac{L + R - 180^\circ}{2}$  or  $\frac{L + R - 540^\circ}{2}$ .
4. If  $|i| \geq 10''$  set the Vertical Angle 0 Datum again.

### Adjustment

1. After leveling the instrument, go to the main menu screen 2/2 and press the **F1** key:



2. In left position rotate the telescope. Precisely sight any target A at the same height as the instrument, the vertical angle is displayed. Press the **F4** key:

V ANGLE 0 ADJUST		[Signal Icon] [Battery Icon]	
<STEP-1> FRONT			
V : 95° 30' 55"			
[Blank]	[Blank]	[Blank]	ENT

3. Rotate the telescope and precisely sight the same target. Press the **F4** key. The setting is finished and the instrument returns to the previous Angle Measurement Mode:

V ANGLE 0 POINT		[Signal Icon] [Battery Icon]	
<STOP-2> REVERSE			
V : 264° 29' 00"			
[Blank]	[Blank]	[Blank]	ENT

4. Repeat the inspection steps to measure the Index difference ( I angle). If the Index Difference does not meet requirements redo the steps above. Carefull sighting must be done to insure the proper result..

5. If Index Difference does not meet the requirements after the repeated operation the instrument should be returned to factory for inspection and repair.


Method: in step three, press the **F1** (SET) key after collimating the target A.

The vertical angles shown in the Vertical Angle 0 Datum are only for reference.

## 12.7 Optical Plummet

### Inspection

1. Set the instrument on the tripod and place a piece of white paper with two perpendicular lines under the instrument.
2. Adjust the focus of the optical plummet and move the paper so that the intersection point of the lines on the paper comes to the center of the field of view.
3. Adjust the leveling screws so that the center mark of the optical plummet coincides with the intersection point of the cross on the paper.
4. Rotate the instrument around the vertical axis and at every  $90^\circ$  observe whether the center mark position coincides with the intersection point of the cross.
5. If the center mark always coincides with intersection point no adjustment is necessary. Otherwise, the following adjustment is needed.



### Adjustment

1. Take off the protective cover between the optical plummet eyepiece and focusing knob.
2. Fix the paper. Rotate the instrument and mark the indicated point of the center of the optical plummet on the paper at every  $90^\circ$ . As illustrated: Point A, B, C, D.
3. Draw lines that attach AC and BD and mark the intersection point of the two lines as

O.

4. Adjust the four adjusting screws of the optical plummet with an adjusting pin until the center mark coincides with Point O.

5. Repeat the inspection and adjusting steps to be sure the adjustment is correct.

6. Replace the protective cover.

## 12.8 Laser Plummet

A laser plummet tribrach may be purchased separately for the instruments.

## 12.9 Instrument Constant (K)

The instrument constant has been checked and adjusted in the factor,  $K=0$ . It changes seldom and it is suggested to check one or two times every year. The inspection should be made on a base line but also can be made according to the following method.

### **Inspection**

1. Mount and level the instrument on Point A in a flat area. Use the vertical hair to mark Point B and Point C on the same line with the distance of 50m between each point. Set the reflector accurately on each point when measuring.

2. After setting temperature and air pressure in the instrument measure the Horizontal Distance of AB and AC accurately.


3. Set the instrument on Point B and center it accurately, measure the Horizontal Distance of BC accurately.

4. Then you can calculate the Instrument Constant:

$$K=AC-(AB+BC)$$




K should be very close to 0, If  $|K| > 5$  mm the instrument should be inspected at a standard baseline site and adjusted according the inspection value.



### Adjustment

If a strict inspection proves that the Instrument Constant K has changed the operator can change the constant by entering the adjustment amount. Press F2 in ADJUSTMENT MODE and key in the new constant.

### 12.10 Parallel between Line of Sight and Emitting Photoelectric Axis



### **Inspection**

1. Set the reflector 50m from the instrument.
2. Sight the center of the reflector prism with reticle.
3. Power on and enter Distance Measurement Mode. Press **MEAS** to measure.

Rotate the Horizontal Tangent Screw and Vertical Tangent Screw, to do electric collimation and make the light route of EDM unblocked. In the bight zone find the center of emitting photoelectric axis.

4. Check whether the center of reticle coincides with the center of emitting photoelectric axis. If so, the instrument is up to grade.

### **Adjustment**

If there is great difference between the center of reticle and the center of emitting photoelectric axis the instrument needs repair.

## **12.11 Tribrach Leveling Screw**

If the leveling screw becomes loose adjust the two adjusting screws in the leveling screw to tighten appropriately.

13. SPECIFICATIONS

Model		CTS-632R6
Telescope	Image	Erect
	Magnification	30×
	Effective aperture	45mm(EDM:47mm)
	Resolving power	3"
	Field of view	1°30'
	Minimum focus	1 m
	Stadia ratio	100
	Sight distance precision	≤0.4%D
	Tube length	152mm
Angle Measurement	Measuring method	absolute encode
	Dia of circle (vertical, horizontal)	79mm
	Minimum reading	1"/5"Selectable
	Detection method	Horizontal: Dual Vertical: Dual
	Measuring unit	360 °/400gon/6400mil Selectable
	Vertical angle 0 °	Zenith0 °Horizontal0 °Selectable
	Accuracy	2"/5"
	Single prisn(under fair weather condition)	3.5km
	Triple prism(under fair weatjer condition)	5km

Distance Measurement	Reflectorless(white)	600m
	Displaly	Max:999999.999m Min:1mm
	Unit	m/ft
	Accuracy	$\pm(2\text{mm}+2\text{ppm } D)$
	Measuring time	Fine single shot:2s Tracking:0.25s
	Measurement system	Basic frequency:80MHZ
	Meteorologic Correction	Manual input,Auto correction
	Atmospheric refraction and earth curvature correction	Manual input,Auto correction,K=0.14/0.2
	Reflection prism correction	Manual input,Auto correction
Vial	Plate vial	30"/ 2mm
	Circular vial	8'/2mm
Vertical Compensator	System	dual axis
	Compensation range	$\pm 6'$
	Resolving power	1"
Optical Plummet	Image	Erect
	Magnification	3×
	Focusing range	0.3m ~ ∞
	Field of view	5 °
Display	Type	LCD, Six lines, digital
Data Communication	RS-232C, USB,SD Card	

On-board Battery	Power resource	Rechargeable Ni-H battery NB-28
	Voltage	DC 6V
	Continuous operation time	8 hrs
Operation Environment	Operating temperature	-20 °~ +45 °C
Size & weight	Dimension	160×150×340mm
	Weight	5.4kg

#### Part of distance measurement

Laser type 0.670um

Measuring system basic frequency: 60MHZ

EDM type coaxiality

Smallest unit displayed 1mm

Laser spot approx 7×14mm/20m ( only no cooperate mode )

approx 10×20mm/50m

#### Precision

##### Cooperate mode

measuring mode	precision	measuring time
prism fine	2mm + 2ppm	< 1.2s
prism track	5mm + 2ppm	< 0.5s
IR baffle-board	5mm + 2ppm	< 1s

##### No cooperate mode

measuring mode	precision	measuring time
----------------	-----------	----------------

fine	3 + 2ppm	< 1.2s
track	10 + 2ppm	< 0.25s

Maximum deviation occurs under unfavourable conditions such as bright sunlight or when measuring to poorly reflecting or very rough surfaces. Measuring errors can occur when measuring toward colorless liquids (e.g.water), dust free glass, Styrofoam or similar semi-permeable surfaces.

Measuring range without reflector(400m)

Atmospheric conditions	No reflector ( white target )	No reflector (grey,0.18)
Object in strong sunlight, severe heat shimmer	400m	280m
Object in shade, or sky overcast	320m	200m

Measuring range without reflector(800m)

Atmospheric conditions	No reflector ( white target )	No reflector (grey,0.18)
Object in strong sunlight, severe heat shimmer	800m	560m
Object in shade, or sky overcast	640m	400m

※ Kodak Grey Card used with exposure meter for reflected light

## 14. ERROR DISPLAYS

Error code	Description	Countermeasures
CALC ERROR	Calculation is impossible because of error in data input.	Enter correct data.
FILE EXISTS	The same file name exists.	Use another file name.
FULL FILES	The maximum of 48 files are already created.	If necessary transmit or delete files.
OVERTOP	The measurement is carried out over 45 ° (100%) from the horizontal.	Measure a new point.
MEMORY POOR	Internal memory is nearly full.	Download data from the internal memory to a computer. Switch to SD card memory or change SD cards.
NO FILE	There is no file in internal memory.	Create a file.
FILE NOT SELECTED	When using a file no file is selected.	Confirm and select a file.
PT#EXIST	The point name already exists in the memory.	Confirm the new point name and input again.
PT#DOES NOT EXIST	An incorrect name is entered or PT# does not exist in the internal memory.	Confirm the new point name and input again.
TILT OVER	Instrument tilt is beyond the compensation range of 3'.	Level the instrument properly.
ERROR 01-06	Angle measurement system	If the error code appears

	abnormal	continuously the instrument needs repair.
ERROR 31 ERROR 33	Distance measurement system abnormal	If the error code appears continuously the instrument needs repair.



## 15. SAFETY INSTRUCTIONS

### 15.1 Integrated EDM ( Visible Laser )

#### Warning :

Total station with EDM of laser class 3R resp.a-identifiable by :

Warning decal is above the vertical braking screw in Face 1: “Class III Laser Product”.

The product is a class 3R laser product in accordance with:

IEC 60825-1:2001 “Radiation safety of laser products”.

Class 3R laser products :

Direct intrabeam viewing is always hazardous. Avoid direct eye exposure. The accessible emission limit is within five times the accessible emission limits of Class 2 in the wavelength range from 400nm to 700nm.

#### Warning :

Direct intrabeam viewing is always hazardous.

#### Precautions :

Do not stare into the beam or direct it towards other people unnecessarily. These measures are also valid for the reflected beam.

#### Warning :

Looking directly into the reflected laser beam could be dangerous to the eyes when the laser beam is aimed at areas that reflect like a mirror or emit reflections unexpectedly (e.g. prisms, mirrors, metallic surfaces, windows).

**Precautions :**

Do not aim at areas that are essentially reflective, such as a mirror, or which could emit unwanted reflections. Do not look through or beside the optical sight at prisms or reflecting objects when the laser is switched on (in laser pointer or distance measurement mode). Aiming at prisms is only permitted when looking through the telescope.

**Warning :**

The use of Laser Class 3R laser equipment can be dangerous.

**Precautions :**

To counteract hazards, it is essential for every user to respect the safety precautions and control measures specified in standard IEC60825-1:2001 within the hazardous distance range.

Below is an interpretation of the main points in the relevant section of the standard quoted.

Class 3R laser products used on construction sites and outdoors (surveying, alignment, leveling):

- a) Only qualified and trained persons should be assigned to install, adjust and operate the laser equipment.
- b) Areas in which these lasers are used should be posted with an appropriate laser warning sign.
- c) Precautions should be taken to ensure that persons do not look directly, with or without an optical instrument, into the beam.
- d) The laser beam should be terminated at the end of its useful beam path and should in all cases be terminated if the hazardous beam path extends beyond the limit (hazard

distance \*) of the area in which the presence and activities of personnel are monitored for reasons of protection from laser radiation.

e) The laser beam path should be located well above or below eye level wherever practicable.

f) When not in use the laser product should be stored in a cool and dry location.

g) Precautions should be taken to ensure that the laser beam is not unintentionally directed at mirror-like (mirrored) surfaces (e.g. mirrors, metal surfaces, windows) and more importantly, at flat or concave mirror-like surfaces.

\*) The hazard distance is the distance from the laser at which beam irradiance or radiant exposure equals the maximum permissible value to which personnel may be exposed without being exposed to a health risk.

Products with an integrated EDM of laser class 3R resp. IIIa has a hazard distance of 1000m (3300ft). After this distance, the laser beam rates as Class 1 (= direct intrabeam viewing is not hazardous).

## 15.2 Laser Plummet

The internal laser plummet sends out a ray of red visible laser beam from the bottom of the instrument.

This product is classified as Class 2/III laser product.

Class 2 laser product is in accordance with the following standard:

IEC 60825-1:1993 "SAFETY of LASER PRODUCTS"

EN 60825-1:1994+A11:1996 "SAFETY of LASER PRODUCTS"

Class II laser product is in accordance with the following standard:

FDA 21 CFR ch.1 § 1040:1998 (U.S. Department of Health and Human Services, Code

of Federal Regulations)

Class 2/II Laser Product:

Do not stare at the laser beam or point it at others. Users should prevent the laser beam and the strong reflecting light from impinging into eyes so as to avoid incurring harm.