

# *Operation Manual*



## N3 Series Mechanical Total Station

**SOUTH**  
Target your success



# CONTENTS

<b>PRECAUTIONS</b> .....	<b>1</b>
<b>1. INTRODUCTION</b> .....	<b>2</b>
1.1 Appearance.....	2
1.2 Keyboard.....	3
1.3 Screen.....	4
1.4 Status Icon.....	4
1.5 Abbreviation.....	4
1.6 Function Key.....	5
1.6 Star Key.....	5
<b>2. OPERATION</b> .....	<b>8</b>
2.1 Preparation.....	8
2.2 Instrument Setup.....	8
2.3 Battery.....	10
2.4 Tribrach.....	11
2.5 Eyepiece Focusing.....	12
2.6 Input Mode.....	12
<b>3. ANGLE MEASUREMENT</b> .....	<b>13</b>
3.1 [F1] 0 Set.....	13
3.2 [F2] Hold.....	13
3.3 [F3] HA Set.....	14
3.4 [F1] V&.....	14
3.5 [F2] R/L.....	15
3.6 [F3] VA.....	15
<b>4. DISTANCE MEASUREMENT</b> .....	<b>16</b>
4.1 [F1] Meas.....	16
4.2 [F2] Mode.....	16

4.3 [F3] S.O.....	17
<b>5. COORDINATE MEASUREMENT.....</b>	<b>18</b>
5.1 [F1] Meas.....	18
5.2 [F2] Mode.....	19
5.3 [F3] Station.....	19
5.4 [F1] R.HT.....	20
5.5 [F2] I.HT.....	20
5.6 [F3] BS.....	20
<b>6. MENU.....</b>	<b>21</b>
<b>7. COLLECT.....</b>	<b>22</b>
7.1 Data Collect.....	22
7.2 Distance Offset.....	22
7.3 Plane Offset.....	23
7.4 Column Offset.....	24
7.5 MLM.....	25
7.6 REM.....	26
<b>8. STAKE OUT.....</b>	<b>27</b>
8.1 Guide Light.....	27
8.2 Coordinate.....	27
8.3 Angle & Distance.....	28
8.3 Reference Line.....	29
<b>9, COGO.....</b>	<b>30</b>
9.1 Calc.XYZ.....	30
9.2 Inverse.....	30
9.3 Area & Girth.....	31
9.4 Point to Line Inverse.....	32
9.5 Point Projection.....	33
<b>10. ROAD.....</b>	<b>34</b>

10.1 Horizontal Alignment.....	34
10.2 Vertical Alignment.....	37
10.3 Road S.O.....	38
10.4 Calculation.....	39
<b>11. STATION.....</b>	<b>40</b>
11.1 Known Point.....	40
11.2 Resection.....	42
11.3 Point to Line.....	43
11.4 Height Transfer.....	44
11.5 BS Check.....	44
<b>12. DATA.....</b>	<b>45</b>
12.1 Job.....	45
12.2 Meas. Data.....	45
12.3 Coord. Data.....	46
12.4 Code Data.....	46
12.5 Data Export.....	47
12.6 Data Import.....	48
12.7 Memory.....	48
12.8 Format.....	48
<b>13. SETTINGS.....</b>	<b>49</b>
13.1 Measurement.....	49
13.2 Unit.....	50
13.3 Bluetooth.....	50
13.4 Backlight.....	51
13.5 Time & Date.....	52
13.6 Others.....	52
13.7 Data Collect.....	53
13.8 Choose Job.....	53

13.9 Touch Screen.....	53
<b>14. AUTO HEIGHT.....</b>	<b>54</b>
<b>15. INSPECTION &amp; ADJUSTMENT.....</b>	<b>55</b>
15.1 Plate Vial.....	55
15.2 Circular Vial.....	56
15.3 Compensator.....	56
15.4 Inclination of Reticle.....	57
15.5 Perpendicularity between Sight of View & Horizontal Axis (2C).....	59
15.6 Vertical Index (I Angle) & V0 Adjustment.....	60
15.7 Optical Plummet.....	61
15.8 Laser Plummet.....	62
15.9 Instrument Constant (K).....	63
15.10 Coincidence between Sight of View % Emitting Axis.....	64
15.11 Leveling Screws on Tribrach.....	64
<b>16. SPECIFICATIONS.....</b>	<b>65</b>
<b>17. SAFETY GUIDE.....</b>	<b>68</b>

## **PRECAUTIONS**



Congratulations on the purchase of SOUTH N3 Total Station!

Please read carefully through the User Manual before you switch on the product.

1. Do not collimate the objective lens directly to the sunlight without a filter.
2. Do not stare at the laser beam, or point the laser to the others' eye!
3. Do not store the equipment in extremely high or low temperature.
4. When the equipment is not in use, store it in the case to avoid dust and humidity.
5. If there is a great difference between the temperature in work field or store place, you should leave the equipment in the case until it adapts to the temperature of environment.
6. If the equipment has not been used for a long time, you should remove the battery for separate storage. The battery should be charged once a month.
7. When shipping the equipment, please place it in the carry case. The cushioned material should be used to cover around the case for support.
8. Clean the optical parts by absorbent cotton or lens-paper only!
9. Clean the surface softly with a woolen cloth. If it gets wet, you should dry it immediately before switch-on.
10. Please check the power supply, functions, indications and parameters of the equipment goes well before operation.
11. Do not disassemble the total station by yourself. Please contact your authorized agency or SOUTH Service Team when you find the equipment abnormal.

# 1. INTRODUCTION


## 1.1 Appearance



No.	Description
1	Handle
2	Guide Light
3	Objective Lens
4	Center Mark
5	Battery Unit
6	Horizontal tangent Screw
7	EDM Trigger Key
8	Tribrach

No.	Description
9	Collimator
10	Eyepiece
11	Vertical Tangent Screw
12	Vial Bubble
13	Plummet
14	Display Unit with Keypad
15	Circular Bubble


## 1.2 Keyboard



- a) Quick Key
- b) Power Key
- c) Alphanumeric Keypad
- d) Measurement Key
- e) Backspace/ESC/ENT
- f) Navigation Key
- g) Function Keys

Key	Description
α	Quick-access to transfer the input mode between alphabets and numbers
MENU	Quick-access to main menu
★	Quick-access to star key for basic settings
⏻	On/Off key. Turn the instrument on or off.
∠	Quick-access to angle measurement
▭	Quick-access to distance measurement
∟	Quick-access to coordinate measurement
⊗	Delete characters before cursor
ESC	Return to previous page
ENT	Enter. Confirm the operation or record the data
▲▼▶◀	Navigation keys. Controls the cursor in four directions
F1—F4	Function keys. Responds to the message displayed

## 1.3 Screen



The screen can be divide into four parts:

- A) Title
- B) Status Icon
- C) Active Field
- D) Function Key

## 1.4 Status Icon

Icon	Description
123 ABC	Input status. Click to set the input mode.
	Bluetooth status. Click to switch on or off.
	Target status. Click to switch among non-prism, prism or reflective sheet.
	Compensator status. Click to activate the E-Bubble.
	USB status.
	Battery status.

## 1.5 Abbreviation

Abbr.	Description
HA	Horizontal angle
VA	Vertical angle
HL/HR	Horizontal left/ right
HD	Horizontal distance
VD	Vertical distance
SD	Slope distance
N/E/Z	North/ East/ Elevation

## 1.6 Function Key

Menu	Function Key	Description
Angle	0 Set	Set horizontal angle to 0
	Hold	Hold the horizontal angle
	HA Set	Input the horizontal angle
	V%	Vertical angle in percent (%) mode
	R/L	Switch between horizontal right or left
	VA	Switch between V0 or H0
Distance	Meas.	Measure
	Mode	Set the measure mode
	S.O.	Stake out points by distance
Coordinate	Meas.	Measure
	Mode	Set the measure mode
	Station	Set station
	R.HT	Set reflector height
	I.HT	Set instrument height
	BS	Set the backsight

## 1.7 Star Key

Press [★] in any page to access to the quick set. Click or use navigation key to select the item.

- |               |                  |
|---------------|------------------|
| 1) Target     | 5) Laser Pointer |
| 2) E Bubble   | 6) Settings      |
| 3) PPM        | 7) Plummet       |
| 4) Meas. Mode | 8) Bluetooth     |

Quick Set	
1.Target	2.E Bubble
3.PPM	4.Meas.Mode
5.Laser Pointer	6.Settings
7.Plummet	8.Bluetooth
Back	Time Info

### 1.7.1 Target

Check the settings of target.

Click or use the navigation key [◀][▶] to switch the target.

The default value of prism constant is -30. It can be defined by manual.

Target			
Target	Prism	◀▶	
Const.	-30		
Back			OK

▶ Target


### 1.7.2 E-Bubble

Check the settings of E-bubble.

**[F2]XY ON:** Turn on (Under dual axis)

**[F3]X ON:** Turn on (Under single axis)

**[F4]OFF:** Turn off the E-bubble

E Bubble			
	X	00'43"	
	Y	00'24"	
		▼	L-Plummet
Back	XY ON	X ON	OFF

▶ E-Bubble

### 1.7.3 PPM

Check the settings of T&P sensor.

The value of temperature, pressure and PPM and be detected or calculated by sensor automatically, or inputted by manual.

T&P Sensor			
Temp.	27.8	°C	
Press.	1006.7	hPa	
PPM	8.9		
Auto	On	◀▶	
Back			OK

▶ PPM

#### Input range:

Temp: -30 ~+60 C° or -22~+140 F°


Press.: 560~1066hPa, 420~800mmHg or 16.5~31.5inHg

PPM: -99.9 to +99.9, Interval: 0.1PPM

### 1.7.4 Meas. Mode

Check the settings of measure mode.

Click or use the navigation key to select the measurement among Fine (Single/ 2times/ 3times/ 4times/ 5times), Repeat or Tracking mode.



► Measure Mode

### 1.7.5 Laser Pointer

Click to turn on or off the laser pointer for easier target aiming.


### 1.7.6 Settings

Quick access to setting page. Please refers to Chapter 13.

### 1.7.7 Plummet

Check the settings of laser plummet.

Click or use navigation keys to turn on or off the plummet. The illumination can be selected among class 1 to 5.




► Laser Plummet

If your total station features the Auto Height function, click **[F3]Meas.HT** to measure the instrument height.

### 1.7.8 Bluetooth

Check the settings of Bluetooth.

The device name and password can be revised for matching and pairing.



► Bluetooth

## **2. OPERATION**

### **2.1 Preparation**

#### **Unpacking**

Lay down the case lightly with the cover upward. Unlock the case, and take out the instrument.

#### **Storage of Instrument**

Cover the cap, put the instrument into the case with the vertical clamp screw tightened and circular vial upwards (lens towards tribrach).

### **2.2 Instrument Setup**

#### **1) Setting up the tripod**

- A. Loosen the screws on the tripod legs, pull out to the required length and tighten the screws.
- B. Make the center of tripod and the occupied point approximately on the same plumb line.
- C. Step on the tripod to make sure if it is well stationed on the ground.

#### **2) Instrument setup (Laser plummet)**

- A. Place and fix the instrument carefully on the tripod
- B. Press **[★]** and select **[7]Plummet** to turn on the laser plummet. Hold the two legs which are not fixed on the ground and decide the position to fix according to the laser dot. When the laser dot is roughly on the station point, fix those 2 legs.


#### **Instrument setup (Optical plummet)**

Adjust the eyepiece of the optical plummet telescope to your eyesight.

Slide the instrument by loosening the tripod screw; place the point on the center mark of the optical plummet. Sliding the instrument carefully as to not rotate the axis will allow you to get the least dislocation of the bubble.

### 3) Roughly leveling by the circular vial


A. Rotate the foot-screw A and B to move the bubble in the circular vial, in which case the bubble is located on a line perpendicular to a line running through the centers of the two leveling screw being adjusted .




B. Rotate the foot-screw C to move the bubble to the center of the circular vial.

### 4) Leveling by the plate vial

A. Rotate the instrument horizontally by loosening the horizontal clamp unit and place the plate vial parallel to the line connecting rotating the foot-screw A and B, and then bring the bubble to the center of the plate vial by rotating the foot-screw A and B.



B. Rotate the instrument in 90° (100gon) around its vertical axis and turn the remaining leveling screw or leveling C to center the bubble once more.



C. Repeat the steps and check whether the bubble is correctly

centered in all directions.

If the laser or optical plummet doesn't stay at the center position after levelling, please slightly loosen the screw under the tripod head and move the instrument (don't rotate the instrument) until the equipment is on the station point. Tighten the screw and level the instrument again. Repeat these steps until the instrument is precisely centered and leveled.

## **2.3 Battery**

### **Inserting**

Put the battery into the instrument, push it. Check and insert it correctly to side into the housing.

### **Replacing**

Press the battery lock on both sides, remove the battery. When the remaining voltage is less than one grid, please stop your operation and charge it as soon as possible.

Before remove the battery from the instrument, make sure that the power is turned off. Otherwise, the instrument may be damaged.

### **Charging**

The battery must be charged prior to using before the first time operation.

The battery LI-30 should be charged only by the official charger NC-III, which packed together with the instrument. Please connect the power supply in 220V, among  $0^{\circ}\sim\pm 45^{\circ}\text{C}$ .

When the indicator on the charger is red, the charging process has begun. When indicator turns green, the charging has finished. For safety, please pull out the battery and charger in time.

In order to get the maximum service life, please charge the battery at least once in a month.


Note:

- a) *The operating time depends on the outside conditions, such as ambient temperature, charging time, the cycles of charging, etc. It is recommended for safety to charge the battery beforehand or to prepare spare full-charged batteries.*
- b) *The remaining voltage of battery shows the power regarding to the current measure mode. The consumption of distance measurement is higher than angle measurement in normal. When switching the measurement mode from angle to distance in a low battery voltage, the equipment might be interrupted.*

## 2.4 Tribrach

### Dismounting

If necessary, the instrument can be dismounted from tribrach. Turn the locking knob in 180° counter-clockwise to disengage anchor jaws, and take off the instrument.



### Mounting

Insert three anchor jaws into holes of tribrach and line up the directing

stub. Turn the locking knob about 180° clockwise to mounting the instrument.

## 2.5 Eyepiece Focusing

Sight the Telescope to bright place and rotate the eyepiece tube to make the reticle clear. Roughly collimate the target by the top of the triangle mark on EDM cover.

Rotate the focusing screw on eyepiece to make the image clear.

## 2.6 Input Mode

When **ABC** is displayed on the status bar, you can input alphabets;

When **123** is displayed, you can input numbers.

Swift the input mode between numbers and alphabets by **[a]**.

Press navigation key **[▲]** **[▼]** to move the cursor up or down.

Station Pt	123	→	⊕	☰	□
Pt N	STN1	<input type="text"/>			
Code	<input type="text"/>				
Inst.Ht	0.000	<input type="text"/>			m
Input	New	Call	Next		

## 3. ANGLE MEASUREMENT

Press  under basic measurement page to activate the function of angle measurement.

Angle.			
VA	62°46'39"		
HR	0°00'00"		
0 Set	Hold	HA Set	1/2
V%	R/L	VA	2/2

### 3.1 [F1] 0 Set

Set the horizontal angle of the first target as 0°00'00". Then aim at the other target to measure the HA between two points.

**[F1] 0 Set:** Set the current HA as 0.

0 Set			
Set HA to 0°?			
Cancel			OK

### 3.2 [F2] Hold

Define and hold the horizontal angle of target as previous value

**[F2] Hold:** Lock the previous horizontal angle

**[F4] OK:** Define the horizontal angle of target as previous holding value.

Hold			
HA Locked!			
80°00'00"			
Back			OK
Angle.			
VA	75°09'58"		
HR	80°00'00"		
0 Set	Hold	HA Set	1/2

### 3.3 [F3] HA Set

Input the horizontal angle by manual.  
The value will apply to the target.

**[F3] HA Set:** Input the requested value

HA Set		123				
HA 90 <input type="text"/>						
Back						OK
Angle.						
VA		75°09'50"				
HR		90°00'00"				
0 Set	Hold	HA Set				1/2

### 3.4 [F1] V%

**[F1] V%:** Switch the display method of vertical angle between degree and percent.

**[F4]1/2, [F4]2/2:** Switch the page of function keys

Note:

When the vertical angle is over 45°(100%) from the horizontal direction, N3 will show "-----" on the screen, which means overrange.

Angle.						
VA		75°09'57"				
HR		148°57'11"				
V%	R/L	VA				2/2
Angle.						
VA		26.49%				
HR		148°57'10"				
V%	R/L	VA				2/2

### 3.5 [F2] R/L

Measure the target in both two side (Face 1/2) will effectively cancels out the operation error to obtain maximum accuracy for measurement.


**[F2] R/L:** Switch the horizontal angle between HR (horizontal right) and HL (horizontal left).

Angle.		    	
VA	26.49%		
HR	148°57'10"		
V%	R/L	VA	2/2

Angle.		    	
VA	26.49%		
HL	211°02'50"		
V%	R/L	VA	2/2

### 3.6 [F3] VA

The vertical angle can be defined by horizontal zero or vertical zero.



Angle.		    	
VA	14°50'04"		
HR	148°57'10"		
V%	R/L	VA	2/2

Angle.		    	
VA	75°09'56"		
HR	148°57'11"		
V%	R/L	VA	2/2

**[F3] VA:** Switch between V0 and H0

## 4. DISTANCE MEASUREMENT

Press  under basic measurement page to activate the function of distance measurement.

Distance					
VA	46°45'50"				
HA	148°28'35"				
SD					m
HD					m
VD					m
Meas.	Mode	S.O			

### 4.1 [F1] Meas.

Measure the target to get the data of SD, HD and VD.

The unit is "m" (meter) in default.

**[F1] Meas.:** The result of measurement will be updated after the beeping.

Distance					
VA	60°37'53"				
HA	215°47'27"				
SD	3.029 m				
HD	2.640 m				
VD	1.485 m				
Meas.	Mode	S.O			

### 4.2 [F2] Mode

Change the mode of measurement among fine (N times), repeat or tracking mode.

**[F2] Mode. :** Switch the mode of measurement.

Measure Mode					
Mode	Repeat				
Back					OK

## 4.3 [F3] S.O

This function calculates the distance elements (SD/HD/VD) to stakeout points.

**[F3] S.O:** Click to enter the page of distance stake out

Dist. S.O			
123			
SD 5.0 m			
SD	HD	VD	OK

**[F1] SD :** Slope distance

**[F2] HD :** Horizontal distance

**[F3] VD :** Vertical distance

**[F4] OK:** Confirm the stake-out value

Dist. S.O.			
VA	37°01'32"		
HA	143°12'14"		
SD	1.787 m		
dSD	-3.213 m		
Meas.	Mode	S.O	

**[F1] Meas. :** Find the stake-out point until the dSD becomes 0.

# 5. COORDINATE MEASUREMENT

Press  $\swarrow$  under basic measurement page to activate the function of coordinate measurement.

Coordinate			
VA	37°07'52"		
HA	138°51'53"		
N			m
E			m
Eleva.(Z)			m
Meas.	Mode	Station	1/2
R.HT	I.HT	BS	2/2


The coordinates of the unknown point are calculated as shown below:

Station: (N0, E0, Z0)

Prism center: (n, e, z)

Unknown point: (N1, E1, Z1)

$$\begin{aligned} N1 &= N0 + n \\ E1 &= E0 + e \\ Z1 &= Z0 + \text{INS.HT} + Z - \text{R.HT} \end{aligned}$$



## 5.1 [F1] Meas.

**[F1] Meas.:** Measure the point to get the N, E and Z coordinate based on the occupied point.

*Note: Please setup the station with instrument height and target height, define the backsight orientation before measurement.*

Coordinate			
VA	37°01'42"		
HA	138°43'17"		
N	99.139 m		
E	100.646 m		
Eleva.(Z)	8.335 m		
Meas.	Mode	Station	1/2

When lacking the data of occupied point, N3 will use the value you inputted last time as the current station point.

## 5.2 [F2] Mode

Change the mode of measurement among fine (N times), repeat or tracking mode.

**[F2] Mode.** : Switch the mode of measurement.


Measure Mode			
Mode		Repeat	
Back			OK

## 5.3 [F3] Station

Set the occupied point as Station before measurement. N3 can automatically convert and display the coordinate of unknown point (prism) under the existed coordinate system.

N3 will remain the data of station point after power off.

**[F3] Station** : Input the coordinate of station by manual.



Input Stn		123
N	<input type="text" value="500.000"/>	m
E	<input type="text" value="500.000"/>	m
Eleva.(Z)	<input type="text" value="10.000"/>	m
Back		OK

## 5.4 [F1] R.HT

Under prism mode, it's necessary to set the reflector height.

**[F1] R.HT:** Input the height of reflector by manual

R.HT	123	→	📏	📄	🔋
R.HT <input type="text" value="0.000"/> m					
Back				OK	

## 5.5 [F2] I.HT

**[F2] I.HT:** Set the height of instrument by manual.

If your N3 total station features LPDM module for Auto Height:

**[F3] Meas.HT:** Activate the function of auto height, from 0.5m to 3m. The result will apply to the current station automatically.

Inst.Ht	123	→	📏	📄	🔋
Inst.Ht <input type="text" value="1.911"/> m					
Back		Meas.HT		OK	

## 5.6 [F3] BS

**[F3] BS:** Simply set the backsight by coordinate (N/E)

BS Coord.	123	→	📏	📄	🔋
N <input type="text" value="0.000"/> m					
E <input type="text" value="0.000"/> m					
Back				OK	

## 6. MENU

Press **[MENU]** under basic measurement screen to enter the menu of N3.  
Click or use navigation key to select the item.

- |              |               |
|--------------|---------------|
| 1) Collect   | 5) Station    |
| 2) Stake Out | 6) Data       |
| 3) COGO      | 7) Settings   |
| 4) Program   | 8) Adjustment |

Main Menu			
1.Collect	2.Stake Out		
3.COGO	4.Program		
5.Station	6.Data		
7.Settings	8.Adjustment		
Back		Time	Info

**[F3] Time:** Check the current time and date

System Time			
Date	2020-01-15		
Time	14:17:37		
Back			

**[F4] Info:** Check the information of total station, including model name, serial number, device ID and system version

System Info			
Model N3			
SN 220910			
DeviceID 7703ad32			
Back		Version	

## 7. COLLECT

### 7.1 Data Collect

Collect and record the point by angle, distance or coordinate measurement.

**[F1] Meas.:** Click or press EDM trigger key for measurement

**[F2] Switch:** Switch the measurement among angle, distance and coordinate

**[F3] R.HT:** Reflector height

**[F4] Save:** Save the current data as a new point

Collect	
1.Data Collect	2.Dist. Offset
3.Plane Offset	4.Column Offset.
5.MLM	6.REM
Back	

Distance	
VA	56°01'32"
HR	251°40'16"
SD	2.507 m
HD	2.079 m
VD	1.401 m
Meas.	Switch
R.HT	Save


### 7.2 Distance Offset

This function calculates the coordinate of point based on lateral and longitudinal offset or height difference of the target.

**R+/L-:** Lateral offset. Input positive number means right (refers to station); otherwise, left

**Fr+/Nr-:** Longitudinal offset. Positive number means far; otherwise, near

**Up+/Dw-:** Altitude deviation. Positive number means up; otherwise, down



Dist. Offset		123
R+/L-	<input type="text" value="5.000"/>	m
Fr+/Nr-	<input type="text" value="-5.000"/>	m
Up+/Dw-	<input type="text" value="1.000"/>	m
Back		Next

**[F1] Meas.:** Measure the target


**[F2] Coord.:** Check the coordinate of offset point

Dist. Offset		→	📄	📁	🔋
R.HT	0.000				m
HA	251°40'18"				
SD	1.600				m
HD	0.763				m
VD	1.406				m
Meas.	Coord.	Back	Next		

## 7.3 Plane Offset

This function calculates the point which cannot be measured directly from the other three points in same plane.

Those three points (P1/P2/P3) can be measured, inputted or selected from the data list to define a plane. Then aim at the target (P0) to calculate the coordinate and SD/HD/VD from station.



**[F1] Meas.:** Measure the point

**[F2] Call:** Call/Select point from list

**[F3] Input:** Input the coordinate directly


*Note: No intersection means those three points cannot define a plane.*

Plane Offset		123	→	📄	📁	🔋
Pt1	PT1					
Pt2	PT2					
Pt3	PT3					
Meas.	Call	Input	Next			

Plane Offset		→	📄	📁	🔋
R.HT	0.000				m
VA	19°55'58"				
HA	220°33'02"				
Back	Dist.	Coord.	Save		

## 7.4 Column Offset

This function calculates the coordinate of a hidden point (P0) that is not directly visible inside from the center (P1) and edge (P2/P3) of column.



**[F1] Meas./ReMeas.:** Measure the center or edge of column

Column Center		123	→			
R.HT	<input type="text" value="0.000"/>					m
HD		1.836				m
<b>Measure the Center of Column</b>						
ReMeas.	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Next

**[F4] Next:** Aim at the left and right edge based on the guidance


Column Center		123	→			
R.HT	<input type="text" value="0.000"/>					m
HD		1.836				m
Left		207°57'02"				
<b>Measure the Left Azimuth</b>						
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Next

**[F4] Calc.:** Calculate the coordinate of hidden center

Coord.			→			
N		99.665				m
E		97.602				m
Eleva.(Z)		13.331				m
Back	<input type="text"/>	Save				

## 7.5 MLM

MLM, is mainly used to compute the HD/ VD/ SD/ azimuth difference between two target points, and this function can be selected under two methods:



- 1) MLM Radial(A-B, A-C) , lock the start point
- 2) MLM Cont. (A-B, B-C) , unlock the start point.

MLM			
1.MLM Radial[A-B A-C]			
2.MLM Cont.[A-B B-C]			
Back			

**[F1] Meas.:** Measure the target as start point or end point.

**[F2] Call:** Select the data from memory as start point or end point.

**[F3] Input:** Input the data as start point or end point.

MLM			
123	→	📄	📱
Start Pt	<input type="text"/>		
End Pt	<input type="text"/>		
Meas.	Call	Input	Calc.


**[F4] Calc.:** Calculate the horizontal distance, vertical distance, slope distance and horizontal angle between the selected points

**[F4] Next:** Add the third point.

MLM	
HA	45°00'00"
HD	70.711 m
VD	0.000 m
SD	70.711 m
Back	Next

## 7.6 REM

When you need the information of a target which is hard to reach or hang in the air, REM can help you measure the point. Set a reflector perpendicular to target to finish the job.



**[F1] Meas.:** Input the reflector height before measure the prism.

Then loosen the vertical tangent screw, rotate the telescope to aim the target and check difference in vertical height (Z).

REM		123	→	📄	📱	🔋
R.HT	1.25					m
VA		52°26'47"				
HD		2.353				m
VD		1.409				m
Eleva.(Z)		1.650				m
Meas.						

## 8. STAKE OUT

This program calculates the required elements to stakeout points from reference line, coordinates or angles, horizontal distances and heights.

S.O.			
1.Coordinate			
2.Angle & Distance			
3.Reference Line			
Back			

### 8.1 Guide Light

Red/Yellow guide lights are built into the telescope as a standard feature, enhancing working efficiency in a range of 20m to 200m (in best conditions)

**[F1] Cancel:** Cancel the guide light

**[F4] OK:** Activate the guide light.

Guide Light			
Open Guide Light?			
Cancel			OK

### 8.2 Coordinate

The coordinate can be inputted, created or selected from data list.

**[F1] Input:** Input coordinate directly

**[F2] New:** Create and save a new point with coordinate to stake out

**[F3] Call:** Call/Select point from data list

Adjust the horizontal angle to find the

Coordinate			
123			
Pt N 2			
R.HT 0.000 m			
Input	New	Call	S.O
Adjust HA			
HA	45°00'03"		
dHA	- 0°00'03"		
Azimuth	45°00'00"		
HD	70.711 m		
Back			Next

direction until it becomes 0.

**[F1] Meas.:** Measure to find the stake out point on site based on the guidance

**Far/Near:** The reflector should move far or near to the station

**Move R/L:** The reflector should move right or left to the station

**Up/Down:** The reflector should move up or down to the station

Coordinate S.O		→   [ ]   [ ]   [ ]	
Turn L	0°00'03"		
Far	69.219 m		
Move R	0.001 m		
Down	3.308 m		
Meas.	Back	1/3	Next Pt

### 8.3 Angle & Distance

Stake out the angle (azimuth) and distance (HD, VD) by inputting the relative position between stakeout point and station point.

Angle & Dist.		123 →   [ ]   [ ]   [ ]	
Azimuth	<input type="text" value="45"/>		
HD	<input type="text" value="10"/>	m	
VD	<input type="text" value="1"/>	m	
R.HT	<input type="text" value="0.000"/>	m	
Back			S.O

Adjust the horizontal angle to find the direction until the value of dHA becomes 0.

Adjust HA		→   [ ]   [ ]   [ ]	
HA	45°00'00"		
dHA	0°00'00"		
Azimuth	45°00'00"		
HD	10.000 m		
Back			Next

**[F1] Meas.:** Measure to find the stake out point on site based on the guidance

**[F2] Back:** Back to previous page


**[F3] 1/3:** Switch the display of guidance

**[F4] Next Pt:** Start to stake out the next point

Coordinate S.O		→   [ ]   [ ]   [ ]	
Turn L	0°00'00"		
Far	8.507 m		
Move L	0.000 m		
Down	2.308 m		
Meas.	Back	1/3	Next Pt

## 8.4 Reference Line

This function calculates the coordinate of unknown point through two known points (P1, P2) and the offset distance from reference line (P1-P2).



P1 and P2 can be measured, inputted or selected from data list.

**[F1] Meas.:** Measure the point as P1, P2

**[F2] Call:** Select the point from memory

**[F3] Input:** Input the coordinate as P1, P2

Reference Line	123	→			
P1	<input type="text"/>				
P2	<input type="text"/>				
Meas.	Call	Input	Next		

**R+/L-:** The latitudinal deviation from target to reference line

**Fr+/Nr-:** The longitudinal deviation from target to reference line

**Up+/Dw-:** The elevation deviation from target to reference line

Reference Line	123	→			
R+/L-	<input type="text" value="15"/>	m			
Fr+/Nr-	<input type="text" value="-1"/>	m			
Up+/Dw-	<input type="text" value="-2"/>	m			
From P1->P2					
Back				Next	

Find the stake-out point until the guidance becomes 0.

Coordinate S.O	→			
Turn R	0°00'01"			
North	5.578 m			
East	9.367 m			
Up	1.966 m			
Meas.	Back	3/3	Next Pt	

## 9. COGO

COGO in N3 total station included the functions of coordinate calculation, inverse calculation, area & girth, point to line and point projection.

COGO			
1.Calc. XYZ			
2.Inverse			
3.Area & Girth			
4.Point to Line Inverse			
5.Point Projection			
Back			

### 9.1 Calc. XYZ (Coordinate)

Calculate the unknown coordinate of target based on the known relationship (azimuth, HD, VD) from two points.

The start point can be measured [F1], inputted [F3] or selected [F2] from data list.

**[F4] Save:** Save the coordinate as a new point

Cal.XYZ 123			
Start Pt	<input type="text"/>		
Azimuth	<input type="text"/>		
HD	<input type="text" value="0.000"/>	m	
VD	<input type="text" value="0.000"/>	m	
Meas.	Call	Input	Calc.

Coordinate Calcula	
N	100.645 m
E	98.776 m
Eleva.(Z)	13.812 m
Back	Save

### 9.2 Inverse

Calculate the unknown relationship (azimuth, HD, SD, VD and slope rate) between two known points.

Inverse 123			
Start Pt	<input type="text" value="PT1"/>		
End Pt	<input type="text" value="PT3"/>		
Meas.	Call	Input	Calc.

Those two points can be measured, inputted or selected from data list.

Result	
Azimuth	185°00'51"
HD	5.446 m
SD	5.994 m
VD	2.505 m
Slope	0.460:1
OK	

### 9.3 Area & Girth

Calculate the area and girth by at least 3 points.

The points can be added by measurement, data select or manual input.

**[F1] Add:** Add a new point in the list

**[F2] Delete:** Delete the selected point

**[F4] Calc.:** Calculate the area and girth

Area Calculation	
1	@input
2	@input
3	@input
Add   Delete   Calc.	

Result	
Area	7500.000 m2
Girth	495.289 m
OK	


*Note:*

*Area calculation in this function calculates area of the graphic which created by all of the projection points onto the horizontal plane*

## 9.4 Point to Line Inverse

Define a straight line by start point P1 and P2, then P3 as offset point.

This function calculates the coordinate and horizontal distance of the perpendicular point P4 between offset point P3 and Line P1-P2.



The known point P1, P2 and P3 can be measured, inputted or selected from data list.

**[F4] Calc.:** Calculate the coordinate and distance between P1-P4/P3-P4.

**[F4] Save:** Save the coordinate of P4.

*Note: The result actually is calculated the horizontal distance of P1-P4 and P3-P4.*


Point to Line Inver 123			
Start P1	<input type="text"/>		
Start P2	<input type="text"/>		
Offset P3	<input type="text"/>		
Meas.	Call	Input	Calc.

Result	
N	80.000 m
E	50.000 m
Z	0.000 m
P1-P4	-70.000 m
P3-P4	30.000 m
Back	Save

## 9.5 Point Projection

Define a straight line by start point P1 and P2, then P3 as offset point.

This function calculates the coordinate and distance of perpendicular point P4 between offset point P3 and line P1-P2.



The known point P1, P2 and P3 can be measured, inputted or selected from data list.

**[F4] Calc.:** Calculate the coordinate and distance between P1-P4/P3-P4.

Point to Line Inver 123			
Start P1	@Meas.	<input type="text"/>	
Start P2	@Meas.	<input type="text"/>	
Offset P3	@Meas.	<input type="text"/>	
Meas.	Call	Input	Calc.

**[F4] Save:** Save the coordinate of P4.


Result	
N	-0.339 m
E	1.189 m
Z	1.989 m
P1-P4	0.741 m
P3-P4	0.971 m
Back	Save

Save 123	
Pt N	10001
Code	<input type="text"/>
Back	OK



## 2) Straight Line

The parameter of straight line only included the length.




*Note: The value should be positive*

Line		123	→	🗑️	📄	☑️
Length		120	m			
Back			OK			

HZ Alignment		→	🗑️	📄	☑️
StakeNo.	220.000 m				
Azimuth	45°00'00"				
N	184.853 m				
E	184.853 m				
Back	Line	Curve	Trans.		

## 3) Curve

The parameter of curve included the radius and length.



*Note:*

*The value of radius depending on the direction. When the curve turns right, the value should be positive; otherwise, it should be negative.*


*The value of length cannot be negative, also cannot be larger than the radius.*

Curve		123	→	🗑️	📄	☑️
Radius		200	m			
Length		100	m			
Back			OK			

HZ Alignment		→	🗑️	📄	☑️
StakeNo.	320.000 m				
Azimuth	73°38'52"				
N	235.341 m				
E	269.966 m				
Back	Line	Curve	Trans.		

#### 4) Transition Curve

The parameter of transition curve included parameter of transition, start and ending radius.



Transition		123	→	🔍	📄	☐
Para.	<input type="text" value="10"/>					
Start R	<input type="text" value="500"/>	m				
End R	<input type="text" value="0.000"/>	m				
Back						OK

HZ Alignment		→	🔍	📄	☐
StakeNo.	320.200 m				
Azimuth	73°39'33"				
N	235.398 m				
E	270.158 m				
Back	Line	Curve	Trans.		

Note:

When the value of radius is positive, the transition parameter A will be a symbolic number. The value of parameter A is depending on the forward direction of curve. When the curve turns right, the value should be positive; Otherwise, it should be negative.

If the radius is  $\infty$ , please keep 0 as it's value.

#### 10.1.2 Edit Horizontal Alignment

View and edit the existed elements of road.

**[F1] First:** Check the first page

**[F2] Last:** Check the last page

**[F3] Search:** Search the element

**[F4] View:** View the selected element

**[F4] Edit:** Edit the selected element

Edit HZ AL		🔍	☐
1	Start		
2	Line	←	
3	Curve		
4	Trans.		→
First	Last	Search	View

Start Pt		→	🔍	📄	☐
StakeNo.	100.000 m				
Azimuth	45°00'00"				
N	100.000 m				
E	110.000 m				
Back					Edit


### 10.1.3 Import Horizontal Alignment

**[F2] Call:** Select the file from USB




### 10.1.4 Clear Horizontal Alignment

Clear all the horizontal alignment



## 10.2 Vertical Alignment

A vertical alignment consists of a series of intersections, including a chainage, elevation and curve length. The length of start point and end point must be zero.



Stake	1000	1300	1800	2300
Height	50	70	60	90
Length	0	300	300	0

Vertical alignment can be defined by stake number, height and length.


## 10.3 Road S.O

In the Roads stake-out, user should stake-out points on the center line at first, then the chainage for both sides.

**Interval:** Interval between the current stake to next stake.

**Differ.:** The left and right difference (offset) from the central line

**VD:** Vertical difference between left and right chainage and the center line



**Start S:** Starting point for road stake-out.

**Stake No.:** The current point

**[F2] +PEG:** Next stake out point on center line.

**[F3] -PEG:** Last stake out point on center line

Finish the stake out of each chainage based on the guidance.

*Note: The vertical alignment data is unnecessarily to be defined, unless it is required to compute dig and fill.*

Road S.O.	123	→	📄	📄	📄
Start S	300		m		
Interval	50		m		
Back				Next	

Road S.O.	123	→	📄	📄	📄
StakeNo.	300.000		m		
Differ.	10		m		
VD	1		m		
R.HT	0.000		m		
Back	+PEG		-PEG	Next	

Coordinate S.O.	→	📄	📄	📄
Turn L	0°00'03"			
Far/Near			m	
L/R			m	
Up/Down			m	
Meas.	Back	1/3	Next Pt	

## 10.4 Calculation

### 10.4.1 Calculate the coordinate of single point

Enter the mileage and point name to calculate the coordinate of point

COGO  			
1.Single Point			
2.Batch Points			
Back			

### 10.4.2 Calculate the coordinate of multi-points

Enter the mileage of start point and end point, with interval and point number. N3 will calculate the coordinate of all the points which matches the requirements in once.

Batch Calc. 123   			
Start Pt	<input type="text" value="100.000"/>	m	
End Pt	<input type="text" value="6300.000"/>	m	
Interval	<input type="text" value="10.000"/>	m	
Pt N	<input type="text" value="7"/>		
Back			Calc.

# 11. STATION

## 11.1 Known Point

Input, create or select a point from the memory with instrument height as the station point.

If your N3 features the LPDM module, you can activate the auto height function by [F3].

**[F4] Next:** Click to select the orientation method (by coordinate or angle).

### 11.1.1 By Coordinate

Input, create or select a point from memory as backsight point.

**[F4] Orient:** Aim the backsight point and the current HA will be set by the azimuth.

Station			
1.Known Pt			
2.Resection			
3.Point to Line			
4.Height Transfer			
5.BS Check			
Back			

Station Pt			
123 → [ ] [ ] [ ]			
Pt N	6		
Code	STN		
Inst.Ht	1.911		m
		Meas.HT	Next

Set Backsight			
1.Coordinate			
2.Angle			
Back			

BS Pt			
123 → [ ] [ ] [ ]			
Pt N	8		
Code			
R.HT	0.000		m
Input	New	Call	Next

Aim Target			
→ [ ] [ ] [ ]			
Azimuth	0°00'00"		
HA	225°09'00"		
			Orient

If necessary, measure the backsight with angle, distance and coordinate for double check.

Aim Target		→ [Icons]	
Azimuth	0°00'00"		
HA	0°00'00"		
Meas.			OK

### 11.1.2 By Angle

Input the point name, code, azimuth angle and reflector height as backsight.

**[F4] Orient:** Sight the HA of current HA as azimuth.

Ang Orientation		123	→ [Icons]	
Pt N	<input type="text" value="1"/>			
Code	<input type="text"/>			
Azimuth	<input type="text" value="45"/>			
R.HT	<input type="text" value="0.000"/>		m	
Back				Next

If necessary, measure the backsight with angle, distance and coordinate for double check.


Aim Target		→ [Icons]	
Azimuth	45°00'00"		
HA	45°00'01"		
Meas.			OK

## 11.2 Resection

A resection sets up the station by using the angle and distance measurements from 7 points in maximum.

--- Calculation will start automatically when enough measurements are taken.

--- The intersection angle among known points should be less than 180 degrees.



Input, select or measure the points for calculation.

**[F4] OK:** Confirm to add the next point.

Resection		123	→	⊗	⊞	⊞
Pt1	<b>11</b>					
R.HT	0.000					m
Azimuth	22°54'28"					
HD	5.270					m
SD	5.507					m
Input	Call	Meas.	OK			

After calculation:

**[F1] Add:** Add another point for resection

**[F2] View:** View the details

**[F3] Save:** Save the result as station

**[F4] 1/2, 2/2:** Switch the display of result between coordinate and the deviation


Resection		→	⊗	⊞	⊞	⊞
N	-0.001					m
E	-0.001					m
Eleva.(Z)	1.916					m
Add	View	Save	1/2			

## 11.3 Point to Line

This function calculates the coordinate of unknown occupied point from two known points.

Measure two known points A & B to define a coordinate system.

Point A as (0,0,0), and Line A-B as N axis.



**[F1] Meas.:** Measure two points to define the axis N.

Meas. P1		123	→	📄	🗑️
Inst.Ht	1.911				m
R.HT	0.000				m
HD	2.707				m
VD	1.336				m
SD	3.019				m
Meas.					Next

**[F2] Coord.:** View the coordinate of occupied point

Point to Line		→	📄	🗑️	🔍
Pt N	20				
HA	222°01'03"				
dHD	1.201				m
Back	Coord.				Set

**[F4] Set:** Save point and set the station

Coord.		→	📄	🗑️	🔍
N	-1.278				m
E	2.386				m
Eleva.(Z)	-1.336				m
Back					

## 11.4 Height Transfer

This function is used for adjusting the height of station, transferred by the coordinate of known point.

The known point can be inputted, created or selected from the data list.

Height Transfer 123			
Known Pt <input type="text"/>			
R.HT <input type="text" value="0.000"/> m			
Input	New	Call	Next

**[F1] Meas.:** Measure the value of horizontal and vertical distance.

Height Transfer	
HA	244°06'17"
VD	1.376 m
HD	2.491 m
Meas.	Back OK

**[F4] OK:** Save the changes and set the station with the calculated instrument height.

Station 123	
Pt N	3
Inst.Ht	<input type="text" value="0.980"/> m
N	-0.206 m
E	1.384 m
Eleva.(Z)	-0.356 m
Back	OK

## 11.5 BS Check

Double check the backsight by angle.

**BS Angle:** the preset angle of backsight

**HA:** current horizontal angle

**dHA:** the difference between current angle and backsight angle

BS Check	
BS Angle	244°10'26"
HA	244°10'27"
dHA	0°00'00"
Back	Reset

## 12. DATA

### 12.1 Job

Click or use the navigation key to select the job.

Data			
1.Job	2.Meas. Data		
3.Coord. Data	4.Code Data		
5.Data Export	6.Data Import		
7.Memory	8.Format		
Back			

**[F1] Delete:** Delete the selected job

**[F2] New:** Create a new job

**[F3] Search:** Search the job in memory

**[F4] Edit:** Edit the selected job

Job Manage			
20011400			
0101		←	
0102			
0103			
			→
Delete	New	Search	Edit

### 12.2 Meas. Data

Click or use the navigation key to select the measured data.

**[F1] First:** Switch to the first page

**[F2] Last:** Switch to the last page

**[F3] Search:** Search the point in memory

**[F4] View:** View the details

**[F3] Edit:** Edit the selected job

**[F4] 1/2:** View the further information

Meas.Data			
1,Stn,1,			
2,Stn,1,		←	
3,Stn,1,			
4,Stn,2,			
5,Stn,3,			→
First	Last	Search	View

Station		←		
Pt N	1			
Code				
N	-0.249 m			
E	1.356 m			
Eleva.(Z)	-1.417 m			
Back		Edit	1/2	

## 12.3 Coord. Data

Click or use the navigation key to select the coordinate data.

**[F1] View:** View the details.

**[F2] Search:** Search the point in memory

**[F3] Add:** Add a new point with coordinate

**[F4] 1/2, 2/2:** Switch to the next/last page

Coord. Data			
1,1,			
2,2,			←
3,PT1,			
4,PT2,			
5,PT3,			→
View	Search	Add	1/2

**[F1] First:** Switch to the first page

**[F2] Last:** Switch to the last page

**[F3] Delete:** Delete the selected point

Coord. Data			
1,1,			
2,2,			←
3,PT1,			
4,PT2,			
5,PT3,			→
First	Last	Delete	2/2

**[F3] Edit:** Edit the selected point

Coord. List	
Pt N	PT3
Code	
N	93.921 m
E	97.550 m
Eleva.(Z)	14.317 m
Back	Edit

## 12.4 Code Data

**[F1] Delete:** Delete the selected point

**[F2] New:** Add a new code

**[F3] Search:** Search the code in memory

**[F4] Edit:** Edit the selected code

Code Data	
01 TREE	
02 ROAD	←
03 LAMP	
	→
Delete	New
Search	Edit


## 12.5 Data Export

This function is used to transfer the coordinate data or raw data, via USB or Bluetooth.

Use 1.USB Stick as an example.




Input the file name, which will be saved under the root directory of USB Stick.




Select the data type between raw data and coordinate data. The coordinate data can be selected by the order below:

- Point number, N, E, Z, Code
- Point number, E, N, Z, Code
- Point number, Code, N, E, Z
- Point number, Code, E, N, Z



Select the job you want for data export.

**[F4] OK:** Start to export the data under the selected job



## 12.6 Data Import

Import the data from USB

**[F1] Back:** Return to last page

**[F2] Call:** Select the file

**[F4] OK:** Confirm the type and order

Select the job to import the data from USB stick to the internal memory.

Data Import			
Import	234.TXT		
Type	Coord. Data		
Format	Pt.N,N,E,Z,Code		
Back	Call		OK

Choose Job			
20011400			
0101			
0102			
0103			
Back			OK

## 12.7 Memory

Check the status of internal memory, with the information of used, unused and total capacity.

Memory Manage	
Total	1994 KB
Used	7 KB
Unused	1987 KB
Back	

## 12.8 Format

Clear all the format of internal storage, or clear all the codes.

Format			
1.Format Internal Storage			
2.Clean the Code			
Back			

# 13. SETTINGS

## 13.1 Measurement

Change the setting of angle, distance and coordinate measurement.

<b>Angle</b>	<b>Z0/H0</b>	Horizontal 0
		Zenith 0
	<b>Tilt</b>	X-ON
		XY-ON
Off		
<b>Distance</b>	<b>TP Sensor</b>	Temperature
		Pressure
		PPM
		Auto: On/Off
	<b>Other</b>	Scale
		Elevation (Z)
		Grid
		TP Sensor
		Constant K
	<b>Measure Mode</b>	Mode
		Times
<b>Target</b>	Prism/ Sheet/ Non-prism	
<b>Coordinate</b>	<b>NEZ/ENZ</b>	N-E-Z
		E-N-Z
	<b>L/R</b>	Same
		Symmetry

Settings	
1.Measurement	2.Unit
3.Bluetooth	4.Backlight
5.Time & Date	6.Others
7.Data Collect	8.Choose Job
9.Touch Screen	
Back	

Angle Set	
Z0/H0	Z0
Tilt	XY-on
Back	OK

Distance Set	
1.TP Sensor	
2.Other Correction	
3.Measure Mode	
4.Target	
Back	

Coordinate Set	
NEZ/ENZ	N-E-Z
L/R	Same Coord.
Back	OK

## 13.2 Unit

Change the setting of display unit, including angle, distance, temperature and pressure unit.

<b>Unit</b>	<b>Angle</b>	Degree
		Gon
		Mil
	<b>Dist.</b>	M
		ft
	<b>Temp.</b>	C°
		F°
	<b>Pressure</b>	hPA
		mmHg
		inHg

<b>Unit Set</b>				→	⊕	📶	🔋
Angle	Degree	◀	▶				
Dist.	m	◀	▶				
Temp.	°C	◀	▶				
Pressure	hPa	◀	▶				
Back				OK			

## 13.3 Bluetooth

Change the setting of Bluetooth.

<b>Bluetooth</b>	<b>On/Off</b>	On
		Off
	<b>Name</b>	Input Name
	<b>PW</b>	Password

<b>Bluetooth</b>				📶	🔋	
On/Off	On	◀	▶			
Name	SOUTH					
PW	123456789					
Back		Default	OK			

**[F3] Default:** Reset the settings of Bluetooth as default.

**[F4] OK:** Confirm the settings.

## 13.4 Backlight

Change the setting of backlight, including battery manage, backlight of display unit and the reticle illumination

<b>Battery Manage</b>	<b>Sleep</b>	0-9 mins
	<b>Power Off</b>	0-60 mins
<b>Display Unit</b>	<b>Auto</b>	On
		Off
	<b>Dual Side</b>	On
		Off
	<b>Keypad</b>	On
		Off
<b>Class</b>	0-7	
<b>Reticle Illumination</b>	<b>On/Off</b>	On
		Off
	<b>Class</b>	Optional

Backlight			
1. Battery Management			
2. Display Unit			
3. Reticle Illumination			
Back			

Battery Manage			
Sleep <b>0</b> ◀▶			
PowerOff <b>0</b> ◀▶			
Back			OK

Display Unit			
Auto <b>Off</b> ◀▶			
Dual Side <b>On</b> ◀▶			
Keypad <b>On</b> ◀▶			
Class <b>7</b> ◀▶			
Back			OK

Reticle			
On/Off <b>On</b> ◀▶			
Class 			
Back			

## 13.5 Time & Date

Change the setting of date (Year/ Month/ Day) and time (Hour / Month/ Second).

Time & Date		123	→	⊕	☰	☒
Date	2020	.	01	.	20	
Time	10	:	13	:	45	
Back						OK

## 13.6 Others

The others included the setting of Factory Reset, Voice (on or off), First View (after power on), Quick Code (on or off) and Display.

<b>Factory Reset</b>	Resume to default factory mode.	
<b>Voice</b>	<b>Status</b>	On Off
	<b>Volume</b>	Optional
<b>First View</b>	<b>First View of N3</b>	Angle
		Dist.
		Coord.
<b>Quick Code</b>	<b>Quick Code</b>	On Off
		<b>Display</b>

Others		☰	☒
1.Factory Reset			
2.Voice			
3.First View			
4.QuickCode			
5.Display			
Back			OK

Voice Set		→	☰	☒
Status	On	◀▶		
Volume				
Back				OK

First View		☰	☒
First View	Angle	◀▶	
Back			OK

QuickCode		☰	☒
QuickCode	Off	◀▶	
Back			OK

## 13.7 Data Collect

Change the settings of data collect by manual or measurement.

<b>Data Collect</b>	<b>Collect By</b>	Measure
		Input
	<b>Save By</b>	Manual
		Auto

Settings

Collect by **Meas.** ◀▶

Save by **Manual** ◀▶

Back OK

## 13.8 Choose Job

Change the setting of job chosen. When activate the function of job chosen, N3 will pop-up the job list before each steps. It will be useful when you need to select the data via the other job.

Choose Job

Pop-up **On** ◀▶

Back OK

## 13.9 Touch Screen

Turn on or off the sensor of touch screen.

Touch Screen

On/Off **On** ◀▶

Back OK

## 14. AUTO HEIGHT

In order to eliminate the errors of manual reading and typing, auto height enables operators to get the instrument height with a simple press. This revolutionary function is now available in South N3 Series total station.

The function can be activated under the setting page of laser plummet, instrument height and station set-up.

Laser Plummet	
Diameter	2.0mm
Coincidence	0.6mm
Wavelength	635nm
Laser Class	Class 2; P<1mW
Auto Height	
Working Range	0.5m-3m
Min. Reading	1mm
Accuracy	±1.5mm *

\* Under good conditions, Kodak Gray card, 90% reflectance

Laser Plummet

Status On

Class 5

Inst.Ht 1.911 m

Meas.HT OK

► Star Key, chapter 1.6.7

Inst.Ht 123

Inst.Ht 1.911 m

Back Meas.HT OK

► Inst. Ht, chapter 5.5

Station Pt 123

Pt N 6

Code STN

Inst.Ht 1.911 m

Meas.HT Next

► Station, chapter 11.1


## 15. INSPECTION & ADJUSTMENT

The instrument has passed the procedure of inspection and adjustment before shipping to your side. However, after long periods of transportation or the changeable environment, some influences may occur to the internal structure. Before the instrument is used for the first time, please check and adjust the functions we introduced in this session to ensure the precision of the job.

### 15.1 Plate Vial

#### Inspection

Rotate the instrument after set-up (Refers to Chapter 2.2) to see whether the bubble is in center, if not, please adjust the vial bubble.



#### Adjustment

1. If the bubble of the plate vial moves away from the center, bring it half way back to the center by adjusting the screws, which is parallel to the plate vial. Adjust the remaining half by adjusting pin.
2. Rotate the instrument in  $180^\circ$  to check whether the bubble is in the center. If not, repeat Step 1.
3. Rotate the instrument in  $90^\circ$ , adjust the third screw. Repeat the steps until the bubble remains in the center in any direction.

## 15.2 Circular Vial

### Inspection

It is not necessary to adjust the circular vial, except the bubble is not in the center after the adjustment of plate vial.

### Adjustment


If the bubble of the circular vial is not in the center, adjust the bubble to the center by using the adjusting pin or hexagon wrench.

First, loosen the screw opposite to the offset side, and then tighten the other adjusting screw on the offset side, bringing the bubble to the center. When the bubble stays in the center, keep the tightness of the three screws uniformly.

## 15.3 Compensator

### Inspection

1. Leveling instrument accurately.
2. Turn on the setting page of e-bubble
3. Read the value of X & Y as X1 & Y1;  
Check the position of bubble.
4. Rotate 180° to read the value of X & Y  
as X2 & Y2.



5. Calculate the value of deviation as below:

$$\text{Average Deviation of X} = (X1 + X2) / 2$$

$$\text{Average Deviation of Y} = (Y1 + Y2) / 2$$

It is not necessary to adjust the compensator if the value is under  $\pm 20''$ ;  
Otherwise, please adjust it as below steps.

## Adjustment

1. Enter the page of tilt adjustment under Menu.8 Adjustment.

Adjustment		
1.Tilt Adjustment		
2.V0 Adjustment		
3.EDM Constant		
4.LPDM Constant		
Back		

2. Aim at a target in Face 1 (HL)

Tilt Adjustment		
1. Face 1 (HL) to Target		
X:	-01'40"	
Y:	-00'31"	
Back		OK

3. Aim at the same target in Face 2 (HR)

Tilt Adjustment		
2. Face 2 (HR) to Target		
X:	01'26"	
Y:	-00'06"	
Back		OK

4. If the value of X and Y are within the adjustment range, then press **F4 [OK]** to update the correction value; Otherwise, please contact your local dealer for further help.


5. Repeat the steps 1-4 for double check. If the deviation value still overrange, please contact your local dealer for further help.

## 15.4 Inclination of Reticle

### Inspection


1. Sight object A after leveling the equipment, lock the horizontal and vertical tangent unit and confirm the target A is in the center of reticle.

2. Move object A to the edge of the field of view, point A' by rotating the vertical tangent screw.
  3. Adjustment is not necessary if object A moves along the vertical line of the reticle and point A' still in the vertical line. Otherwise, as picture shown, A' is deviate to the center of the vertical cross-hair, it is necessary to adjust.
- Otherwise, as picture shown, A' is deviate to the center of the vertical cross-hair, it is necessary to adjust.



### **Adjustment**


1. Remove the eyepiece cover to expose the four reticle adjusting screws, as picture shown.
2. Loosen the four reticle adjusting screws uniformly by the adjusting pin. Rotate the reticle around the sight line and align the vertical line of the reticle with point A'.
3. Tighten the adjusting screws slightly. Repeat the previous steps to see whether the position is correct.
4. Assemble the eyepiece cover back.



## 15.5 Perpendicularity between Sight of View & Horizontal Axis (2C)

### Inspection

1. Set object A at a far distance at the same height as the instrument, leveling the instrument and turn on the power (e.g. HL=10°13'10").
2. Sight object A in horizontal left and read value of HA. (e.g. HR=190°13'40").
3. Loosen the vertical and horizontal tangent unit and rotate the telescope. Sight object A in horizontal right and read the HA.
4.  $2C = HL - HR \pm 180^\circ = -30'' \geq \pm 20''$ , overrange. So it is necessary to adjust 2C.



### Adjustment

1. Use the tangent screw to adjust the horizontal angle to the right reading which has been eliminated C:  
 $R + C = 190^\circ 13' 40'' - 15'' = 190^\circ 13' 25''$
2. Take off the cover of the reticle between the eyepiece and focusing screw. Adjust the left and right adjusting screws by loosening one and tightening the other. Move the reticle to sight object A exactly.
3. Repeat inspection and adjustment until  $|2C| < 20''$ .
4. Replace the cover of the reticle.

*Note: After adjustment, please check the photoelectricity coaxially.*

## 15.6 Vertical Index (I Angle) & V0 Adjustment

Inspect this parameter after chapter 15.3 and 15.4

### Inspection

1. After leveling the instrument, collimate at any target A in HL. Record the value as L.
2. Rotate the EDM and aim at the target A in HR. Record the value as R.
3. If the vertical 0° in zenith,  $I = (L + R - 360^\circ)/2$ . If the vertical 0 in horizon,  $I = (L + R - 180^\circ)/2$  or  $(L + R - 540^\circ)/2$ .
4. If  $|i| \geq 10''$ , it's necessary to adjust the Vertical 0.

### Adjustment

1. Enter the page of V0 adjustment under Menu.8 Adjustment.

Adjustment  			
1.Tilt Adjustment			
2.V0 Adjustment			
3.EDM Constant			
4.LPDM Constant			
Back			


2. Aim at a target in Face 1 (HL)

V0 Adjustment    			
1. Face 1 (HL) to Target			
V:		49°19'11"	
Back			OK

3. Rotate the telescope and then aim at the same target in Face 2 (HR)

V0 Adjustment    			
1. Face 1 (HL) to Target			
V:		49°19'13"	
2. Face 2 (HR) to Target			
V:		310°40'29"	
Back			OK

4. Press [F4]OK to confirm the revised I-Angle



5. If the Index Difference does not meet your requirements, please redo the steps above.

Please carefully repeat these steps to ensure the proper result. Or contact your local dealer for further help.

## 15.7 Optical Plummet


### Inspection

1. Set the instrument on the tripod and place a piece of white paper with a cross lines on it below the equipment.
2. Adjust the focus of optical plummet. Move the paper until the intersection point of the crossline on the paper comes to the center of optical plummet.
3. Adjust the leveling screws and keep the center mark of the optical plummet coincides with the intersection point of the crossline precisely.
4. Rotate the instrument and check whether the position of center mark coincides with the intersection point of the crossline in every 90°.
5. If the center mark always coincides with intersection point, it is not necessary to adjust.

### Adjustment

1. Take off the protective cover between the plummet eyepiece and focusing knob.
2. Rotate the instrument and mark the point of the center of optical

- plummet which falls on the paper in every  $90^\circ$ . Point A, B, C, and D.
3. Draw lines that attach AC and BD and mark the intersection point of the two lines as O.
  4. Adjust the four adjusting screws of the optical plummet with an adjusting pin until the center mark coincides with Point O.
  5. Repeat the steps to make the instrument meets the requirements.



## 15.8 Laser Plummet

### Inspection

1. Activate the laser plummet, from star key - 7.Plummet
2. Repeat the steps as Chapter 15.7
3. If the laser point always coincided with the intersection point, it is not necessary to adjust.

### Adjustment


If the laser plummet was broken, please contact your local dealer to change a new one.

## 15.9 Instrument Constant (K)

The Instrument constant has been checked and adjusted in the factory, and  $K=0$ . Please do not modify the constant without permission.

### Inspection

1. Mount and level the instrument on Point A on flat ground. Use the vertical hair to mark Point B and Point C with the distance of 50m on the same line, and collimate the reflector accurately.
2. After setting temperature and pressure value, measure the horizontal distance of AB and AC accurately.
3. Setup the instrument on Point B and center it accurately. Measure the horizontal distance of BC.
4. Then you can get the Instrument Constant:  $K = AC - (AB + BC)$ . The value of K should be close to 0. If  $|K| > 5\text{mm}$ , the instrument should be strictly inspected on the base alignment, and adjust it according to the inspection value.



### Adjustment


If Constant K was changed, the operator should modify the constant by manual (after the precise inspection). Press [Menu] - 8. Adjustment - 3. EDM Constant to change the settings.

EDM Constant		123	←	⊞	⊞	⊞
SD		m				
HD		m				
VD		m				
Prism	0	mm				
NonPrism	0	mm				
Cancel		Meas.		OK		

## 15.10 Coincidence between Sight of View & Emitting Axis

### Inspection

1. Set a target 50m away from the instrument.
2. Aim and measure the center of target.
3. Rotate the tangent screw to launch electric collimation and make the light path of EDM unblocked. In the bright zone, find the center of emitting photoelectric axis.
4. Check whether the center of reticle coincide with the center of emitting photoelectric axis. If yes, the instrument is eligible.



### Adjustment

If there is any difference between sight of view and emitting axis, please send the instrument to your local dealer for repair and maintenance.

## 15.11 Levelling Screws on Tribrach

If any one of those leveling screws was loosed, please tighten the adjusting screws on the side of leveling screw appropriately.

## 16. SPECIFICATIONS

<b>TELESCOPE</b>		
Image	Erect	
Tube length	152mm	
Effective aperture	45mm (DTM: 47mm)	
Magnification	30x	
Field of view	1°30'	
Resolving power	3"	
Minimum focus	1.5m	
Reticle illumination	10 brightness level	
<b>ANGLE MEASUREMENT</b>		
Accuracy	2"	
Measuring method	Absolute encoding	
Diameter of disk	79mm	
Minimum reading	1"	
Detection method	Horizontal: dual; Vertical: dual	
Unit	360 degree/ 400 gon/6400 mil	
Vertical angle 0°	Horizontal 0/ Vertical 0	
<b>DISTANCE MEASUREMENT</b>		
Range	Reflectorless	1000m
	Prism	5000m
Accuracy	Reflectorless	3+2ppm
	Prism	2+2ppm
	Sheet	3+2ppm
Measure interval	Fine: 1.2s; Tracking: 0.2s	

Atmospheric correction	Manual input, auto correction
Prism constant	Manual input, auto correction
Temperature correction	Sensor reading
Distance reading	Max: 99999999.999m; Min: 1mm

### COMPENSATOR

System	Liquid, dual axis
Working range	±6'
Accuracy	1"

### GUIDE LIGHT

Wave Length	635nm/590nm
Color	Red/ Yellow

### PLUMMET

Laser plummet	Accuracy	±1.5mm @1.5m
	Brightness	5 brightness level
	Wavelength	635nm
	Laser class	Class 2
	Laser power	0.5mW
LPDM module	Range	0.5m-3m
	Min. reading	1mm
	Accuracy	±1.5mm*
Optical plummet	Image	Erect
	Magnification	3x
	Min. Focusing	0.5m
	Field of view	5°

### KEYBOARD AND DISPLAY

Keyboard	Alphanumeric 30 keys
----------	----------------------

Display	3.0 inches, color touch
Resolution	240*400 dpi
Position	Face 1, face 2
<b>INTERFACE</b>	
Data interface	USB flash disk, Bluetooth
<b>BATTERY</b>	
Type	Lithium, 7.4V
Operating time	8 hours
<b>VIAL</b>	
Plate vial	30"/2mm
Circular vial	8'/2mm
<b>GENERAL</b>	
Storage	16000 points
IP	IP54
Size	206*195*353mm
Weight	Approx. 6.0kg

*\* Under good conditions, Kodak Gray card, 90% reflectance*

## **17. SAFETY GUIDE**

### **17.1 INTERNAL DISTANCE METER (VISIBLE LASER)**

#### **Warning**

The total Station is equipped with an EDM of Laser Class 3A/III a and it is verified by these labels as follows:

There's an indication label "CLASS III LASER PRODUCT" above the vertical clamp screw on Face Left as well as on the Face Right.

The product is classified as Class 3A laser product, according to the standards as follows:

IEC60825-1:2001 "SAFETY OF LASER PRUDUCTS"

The product is classified as Class III a laser product according to the standards as follows:

Class 3A/III a laser product: It is harmful to observe the laser beam continuously. Users should avoid staring at the laser directly. It can reach as much as 5 times the emitting limit of Class 2 / II with a wavelength between 400nm and 700nm.

#### **Warning**

It is dangerous to continuously look straight at the laser beam.

#### **Prevention**

Do not stare at the laser beam, or point the laser beam at others. Reflecting laser beam is also valid.

#### **Warning**

When the laser beam emits on prism, mirror, metal surface, window, it might be dangerous to look directly by the reflecting light.

### **Prevention**

Do not stare at the direction which the laser beam might reflects. When the laser is opened, do not look at it near to the optical path or the prism. It is only allowed to observe the prism through the telescope of the total station.

### **Warning**

It is dangerous to make improper use of the Class IIIa laser equipment.

### **Prevention**

To avoid injury, all the users should take safety precautions, and must make sure that everything is under control within the distance that might bring dangers (according to IEC60825-1:2001)

There are explanations of some principle points of related standard as follows:

Class 3R laser product is used in outdoors and construction site (measuring, defining alignment, leveling, etc.). The laser equipment can only be installed, adjusted and operated by those persons who have taken related training course and got the authentication.

- a. Set related laser warning marks on site.
- b. Prevent anyone from looking straight at the laser beam directly or through optic instrument.
- c. To avoid the harm brought by laser, users should block the laser beam at the end of the working route. When the laser beam passes through the restricted area (harmful distance\*), and there are persons

taking activities, users must stop the laser beam in time.

d. The optical path of the laser beam should be set higher or lower than the line of sight.

e. When the laser instrument is not in use, users should keep it well. It is not allowed for operation unless the user is authenticated.

f. Prevent the laser beam from accidentally emitting at mirror, metal surface, window, etc. Especially pay attention to the surface of plane mirror or concave mirror.

\* Harmful distance suggests that the maximum distance from the start point of the laser beam to the point which the laser beam is weakened to a certain degree that doesn't harm people.

The internal distance measure product which is equipped with a Class3R/III a Laser Product has a harmful distance of 1000m (3300ft). Beyond this distance, the laser strength is weakened to Class I (It is not harmful to look straight at the laser beam).

## **17.2 LASER PLUMMET**

The internal laser plummet sends out a ray of red visible laser beam from the bottom of the instrument.

This product is classified as Class 2/II laser product.

Class 2 laser product is in accordance with the following standard:

IEC 60825-1:2014 "SAFETY of LASER PRODUCTS"

EN 60825-1:12014 "SAFETY of LASER PRODUCTS".

Class 2/II Laser Product:

Do not stare at the laser beam or point it at others. Users should prevent the laser beam and the strong reflecting light from impinging into eyes so as to avoid incurring harm.