TcpMDT

Digital Terrain Model – V8.5

Standard

aplitop

Introduction

This application is ideal for all kind of surveying projects, modeling the terrain, drawing profiles, calculating volumes and visualizing the terrain in 3D. Its main users are public administrations, construction companies, engineering, architecture and town planning studies and companies involved in earthworks, running quarries, mining, the environment etc. as well as free-lance professionals.

MDT is an application that is installed as a plugin on AutoCAD, BricsCAD, GstarCAD or ZWCAD. It offers a powerful set of tools for easy learning and has a modular structure. It shows great versatility through the import and export of files in the most common formats, such as LandXML, DWG and many more. In addition, APLITOP is a pioneer in the integration of topographic and road data in OpenBIM workflows, through the IFC format and the extensions IFC Alignment and IFC Road.

Topographic Points

The program starts to run from coordinates obtained by total stations or GNSS receivers, converting files from field applications. If TcpET or TcpGPS has been used, in addition to the coordinates, the raw data of the observations are imported, as well as the linked photographs and voice notes.



It is also possible to create new points from CAD entities drawn by other programs. If codes have been assigned to points in the field, the program will automatically draw the planimetry and blocks defined by the user. In addition, we can run all kinds of editing and filtering operations.

Surfaces

Break lines can be defined graphically, by sequence of points, codes or by importing files. Triangulation can be created from points, with or without break lines and by applying angle or maximum length controls. There are also options for flat triangles minimization and automatic gap repair.

Topographic surfaces of natural terrain and geotechnical layers can be created from survey data or seismic profiles. There are commands for interactive editing of the surface, and it also offers tools to detect and repair errors. The surfaces can have multiple boundaries or islands, and can be drawn as lines, 3D faces or meshes.



The program includes the import and export of the most common formats, including CAD applications, BIM, machine control, 3D modeling and virtual reality.

Cartography and Contour Lines

MDT can generate contours with an interval or at special elevations and they are updated automatically with each change in triangulation. The contours can be labelled manually or automatically with style, and additional labels to be placed anywhere on the surface.

There are also other commands for interpolating, breaking and joining contours, adding vertices, editing contours, discretizing polylines and splines, detecting elevation errors etc. Other tools allow to import and export point, lines and polygon GIS files in shape, GML, GeoJSON and more formats. You can also import vector data from entity web services (WFS).



Meshes

Meshes may be created from a surface, contours, 3D entities or mesh files in various known formats (Arc/Info, LAS, GeoTIFF, etc.) or web coverage services (WCS). Large files can be converted from LiDAR or photogrammetry applications, with the possibility of resampling and without the need to draw them in CAD.

It also has commands for mesh processing such as joins, filtering and resampling, smoothing, removing peaks, filling gaps, etc. They may be represented as 3D faces, polyface mesh or image, all being suitable for export to realism and animation programs.



Alignments

The horizontal alignments which will be used on longitudinal profiles and cross sections may be created easily from polylines or by importing files in the most common commercial formats as LandXML, IFC, etc.

Profiles

Longitudinal profiles and cross sections may be calculated from a surface, 3D cartography or by regression of points near the alignment. The drawing is totally customizable: model or paper space, sheet templates, text style and size, labels and numeric data, customized blocks, etc.

The profiles may be updated automatically when the original alignment or surface have changed. Furthermore, it has a powerful profile interactive editor. You can simultaneously draw several profiles on different layers to show the different evolution stages of a terrain. It also has tools for projecting 3D polylines or points in the profiles, viewing in real time of cross sections based on the position of the cursor on the ground plan and many more tools.




ZWCAD 2020 Trial version (Limited) - [E:\Proyectos MDT\2020\MDT 8.5\perfiles.dwg]
File Edit View Insert Format Tools Draw Dimension Modify Express Window Help MDT8-PointCloud MDT8
Drawing1.dwg
perfiles.dwg*
Model Layout1 Layout2 TRA_topografico1 TRA_topografico2 TRA_topografico3 TRA_topografico4 TRA_topografico5 TRA_topografico6 TRA_topografico7 TRA_topografico8 TRA_topografico9 TRA_topografico10
Command: <switch to: TRA_topografico1>
Command:


CrossSection editor
Settings Help About us
TERRENO.TRA
Distance Height Code
-7.310 568.560 TRI
-7.247 568.574 TRI
0.000 570.036 Eje
7.604 570.795 TRI
8.411 570.771 TRI
Station : 300.000
570
565
Items : 5 PK: 300.000
TERRENO.TRA RASANTE.TRA FIRME.TRA
Station : 1.549 - Height : 573.743

Volumes

Cut and fill volumes can be calculated from a comparison between meshes, surfaces or cross sections. The results of meshes and surfaces are represented by areas using color palettes, with a customizable legend and interval.

Calculation by profiles allows the application of the curvature corrections in line with the geometry of the alignment on the ground plan and excluding intervals that do not take part of the measurement.



Images

MDT has commands for inserting georeferenced images and orthophotos in their real position on the terrain and assigning them to a surface or assigning predefined textures to surfaces, and place photos with position at their real location on the map.

It also allows access to the web map services (WMS, WMTS) provided by public and private entities in such a way that the user must only specify a window, choose the service and the program will automatically insert the image in the right place on the drawing. Another utility enables the user to export points, surface and layers of the drawing to Google Earth.


Autodesk AutoCAD 2021 Ortofotos.dwg
Insert Images
Insert with location
Insert WMS Map
Mode
Rotate
Adjust
Image size
Delimit image
Cut image in sheets
Paste images
Split window
One window
Reference lines
Marks
Link marks to poins
Edit links
Geo-Reference image
Save Geo-Reference
Image deformation
TcpImage
MDT8
Close
Start
Ortofotos
N
W
TOP
E
S
WCS
Model
Layout1
Layout2


Google Earth Pro
Archivo
Editar
Ver
Herramientas
Añadir
Ayuda
Buscar
Obtener indicaciones
Historial
Sitios
Mis sitios
Tour de lugares destacados
Sitios temporales
Ejemplo1
ACERA
ALAMBRADA
BORDILLO
CAMINO
CV-MAESTRAS
CV-NORMALES
FACHADA
Capas
Base de datos principal
Anuncios
Fronteras y etiquetas
Lugares
Fotografías
Carreteras
Edificios 3D
Tiempo
Galería
Más
Relieve
Google Earth

Maps - Render

MDT can draw a 3-D mesh based on contours or surface and maps of heights, slopes, orientations or visibility from a point can be generated. It includes a powerful terrain viewer in which the lighting conditions can be changed and simulate phenomena such as fog, rain, wind, etc.

It includes a ready-to-use library of textures to apply to models, and another of 3D objects with trees, vegetation, rocks, signs, street furniture, etc. useful to enhance presentations. Another interesting feature is the total immersion in the field through Virtual Reality technology, using Oculus Rift headset and moving freely with the X-Box gamepad.





Plots

This menu includes options for creating and editing plots and buildings. It also has tools for plot division by area, parallel and perpendicular to one side, azimuth, length of facade, etc. Other utilities allow you to dimension parcels, label vertices coordinates and length of sides, generate reports and presentations, etc.

The data can be exported to standard formats such as GML and LandXML, shape for GIS projects and other specific ones required by the Cadaster in countries such as Spain, France, etc.



BIM

APLITOP is actively collaborating with buildingSMART International for the development and implementation of the IFC Alignment and IFC Road formats, which aim to simplify the exchange of road and infrastructure data though the BIM methodology.

MDT can import IFC (Industry Foundation Classes) format files having surfaces and alignments. Properties and properties set can be defined as established in the technical specifications and BIM Execution Plans, as well as applying classifications of objects.

It is makes possible to use data generated by MDT in applications such as BIM Vision, Solibri Model Checker, Revit, ArchiCAD, Navisworks, Infraworks, BIMserver center, etc.



Utilities

MDT has multiple additional tools for the presentation of drawings such as the numbering of objects, draw coordinates and grids, slope drawing, division onto sheets, layer control, entity elevation etc.

The feature elevation utility allows you to quickly assign elevations to features drawn in 2D, using a surface or indicating extreme values to interpolate the rest. The support submenu offers options to open the help system and training videos, report issues or suggestions, check for updates, etc.



Reports

The results offered by MDT can be customized by the user, including its graphic representation and reports. In these you can define the header and footer content, font types, sizes and colors, add company logo, configure margins, line spacing…In addition, the reports can be exported directly to Word, Excel, text, PDF and drawing as a table in the CAD itself.



Requirements [1]

CAD	AutoCAD versions 2007 to 2022 and compatible versions BricsCAD Pro/Platinum versions 15 to 22 GstarCAD Professional versions 2021 to 2022 ZWCAD Professional/Enterprise versions 2012+ to 2022
Operating System	Windows XP / Vista / 7 / 8 / 8.1 / 10 in 32 and 64 bits [2]
Peripherals	Mouse or pointing device
Graphic Card	CD-ROM Reader 1280x720 pixels, compatible with OpenGL Nvidia or ATI chipset recommended
Drive	10 Gb free space
Memory	Minimum 3 Gb
Processor	Dual-core 2 Ghz or superior

(1) Consult the website for further details

(2) Operation via a remote desktop and similar services are not guaranteed, nor on virtualization platforms. Write to support@aplitop.com to ask about these special cases.

More information in https://www.aplitop.com/products/mdt-standard

APLITOP S.L.
Sumatra,9 – Urb. El Atabal
E-29190 Málaga (España)
Tlf: *+34 95 2439771*
e-mail: *info@aplitop.com*
Web: *www.aplitop.com*